

SFP Optical Converters 1310NM-DRL, 1310NM-DTL, 1310NM-TRL OPTIONS

Installation Manual

071848900 DECEMBER 2006



CERTIFICATE

Certificate Number: 510040.001

The Quality System of:

Grass Valley, Inc.

400 Providence Mine Road Nevada City, CA 95945 United States

United States
Weiterstadt 0

10 Presidential Way 3rd Floor, Suite 300 Woburn, MA 01801 United States

Nederland B.V. 4800 RP BREDA The Netherlands Weiterstadt, Germany Brunnenweg 9 D-64331 Weiterstadt Germany Rennes, France Rue du Clos Courtel Cesson-Sevigne, Cedex

Technopole Brest Iroise CS 73808 29238 Brest Cedex 3 France 17 rue du Petit Albi-BP 8244 95801 Cergy Pontoise Cergy, France

15655 SW Greystone Ct.

Beaverton, OR 97006

2300 South Decker Lake Blvd. Salt Lake City, UT 84119 United States

7140 Baymeadows Way Suite 101 Jacksonville, FL 32256 United States

Including its implementation, meets the requirements of the standard:

ISO 9001:2000

Scope:

The design, manufacture and support of video hardware and software products and related systems.

This Certificate is valid until:
This Certificate is valid as of:
Certified for the first time:

June 14, 2009 August 30, 2006 June 14, 2000

H. Besine So)h

H. Pierre Sallé President KEMA-Registered Quality

The method of operation for quality certification is defined in the KEMA General Terms And Conditions For Quality And Environmental Management Systems Certifications. Integral publication of this certificate is allowed.

KEMA-Registered Quality, Inc.

4377 County Line Road Chalfont, PA 18914 Ph: (215)997-4519 Fax: (215)997-3809 Accredited By: ANAB





SFP Optical Converters 1310NM-DRL, 1310NM-DTL, 1310NM-TRL OPTIONS **Installation Manual** 071848900 **DECEMBER 2006**



Contacting Grass Valley

International Support Centers	France 24 x 7	+800 8080 2020 or +33 1 48 25 20 20 +800 8080 2020 or +33 1 48 25 20 20	United States/Canada 24 x 7	+1 800 547 8949 or +1 530 478 4148		
Local Support Centers (available during normal business hours)	Asia	Hong Kong, Taiwan, Korea, Macau: +852 2531 3058 Indian Subcontinent: +91 22 24933476 Southeast Asia/Malaysia: +603 7805 3884 Southeast Asia/Singapore: +65 6379 1313 China: +861 0660 159 450 Japan: +81 3 5484 6868				
	Australia and New Zealand: +61 1300 721 495			Central/South America: +55 11 5509 3443		
	Middle East: +971 4 299 64 40 Near East and Africa: +800 8080 2020 or +33 1 48 25 20 20					
	Europe	Belarus, Russia, Tadzikistan, Ukraine, Uzbekistan: +7 095 2580924 225 Switzerland: +41 1 487 80 02 S. Europe/Italy-Roma: +39 06 87 20 35 28 -Milan: +39 02 48 41 46 58 S. Europe/Spain: +34 91 512 03 50 Benelux/Belgium: +32 (0) 2 334 90 30 Benelux/Netherlands: +31 (0) 35 62 38 42 1 N. Europe: +45 45 96 88 70 Germany, Austria, Eastern Europe: +49 6150 104 444 UK, Ireland, Israel: +44 118 923 0499				

Copyright © Grass Valley. All rights reserved. This product may be covered by one or more U.S. and foreign patents.

Grass Valley Web Site

The <u>www.thomsongrassvallev.com</u> web site offers the following:

Online User Documentation — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

FAQ Database — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

Software Downloads — Download software updates, drivers, and patches.



END-OF-LIFE PRODUCT RECYCLING NOTICE

Grass Valley's innovation and excellence in product design also extends to the programs we've established to manage the recycling of our products. Grass Valley has developed a comprehensive end-of-life product take back program for recycle or disposal of end-of-life products. Our program meets the requirements of the European Union's WEEE Directive, the United States Environmental Protection Agency, and U.S. state and local agencies.

Grass Valley's end-of-life product take back program assures proper disposal by use of Best Available Technology. This program accepts any Grass Valley branded equipment. Upon request, a Certificate of Recycling or a Certificate of Destruction, depending on the ultimate disposition of the product, can be sent to the requester.

Grass Valley will be responsible for all costs associated with recycling and disposal, including freight. However, you are responsible for the removal of the equipment from your facility and packing the equipment to make it ready for pickup.

For further information on the Grass Valley product take back system please contact Grass Valley at + 800 80 80 20 20 or +33 1 48 25 20 20 from most other countries. In the U.S. and Canada please call 800-547-8949 or 530-478-4148, and ask to be connected to the EH&S Department. Additional information concerning the program can be found at: www.thomsongrassvalley.com/environment



Contents

SFP Optical Converter Submodule Op	tions
Introduction	
Kameleon 2000 Fiber Ready Module	es
	Modules
Installation	

Contents

Preface

This manual describes the features of a fiber optic submodule option in the Kameleon Media Processing System and the 8900 Series used in the GeckoFlex frame. Refer to the laser compliance information in the *GeckoFlex Frames Instuction Manual* for safety information

As part of this module family, it is also subject to Safety and Regulatory Compliance described in the 2000 Series and 8900 GeckoFlex frame and power supply documentation (see the 2000 Series Frames Instruction Manual and the GeckoFlex Instruction Manual).

Preface

SFP Optical Converter Submodule Options

Introduction

This manual accompanies the optical/electrical converter submodule options for fiber ready modules in the Kameleon 2000 Series and the GeckoFlex 8900 Series. The low power, single mode SFP (Small-form Factor Pluggable)/LC 1310nm optical converters include the following models:

- 1310NM-DRL Dual receiver (2 inputs),
- 1310NM-DTL Dual transmitter (2 outputs), or
- 1310NM-TRL Transceiver (1 input/1 output).

The fiber ready modules currently available in the Grass Valley Kameleon 2000 and GeckoFlex 8900 Series are listed below:

Kameleon 2000 Fiber Ready Modules

- 2031RDA-SM SD Reclocking DA with Single-Mode Fiber I/F
- 2031RDA-MM SD Reclocking DA with Multimode Fiber I/F
- 2040RDA-FR Fiber Ready Wideband DA
- 2040RDA-16FR Fiber Ready Wideband DA (16 outputs)

GeckoFlex 8900 Series Fiber Ready Modules

- 8947RDA-FR SD/HD Distribution Amplifier
- 8949MDA-CFR SD/HD Monitoring Distribution Amplifier
- 8949MDA-SFR SD/HD Monitoring Distribution Amplifier
- 8985FSP HD/SD Frame Sync, Proc Amp
- 8985FS SD/HD Frame Sync
- 8985PRC SD/HD Proc Amp
- 8995UPC SD to HD Upconverter
- 8995DNC HD to SD Downconverter

Kameleon 2000 Fiber Ready Modules

This section describes the installation and cabling of the SFP fiber optic submodules for the fiber ready modules in the Kameleon 2000 Series.


Installation

CAUTION The Fiber Optic submodule is static sensitive. Use static handling precautions when installing or removing the submodule.

The SFP submodule installs in the connector cage on the rear module corresponding to the front module in the 2000 frame. Figure 1 illustrates a rear module using the 2040RDA-16FR as an example.

The submodule is hot-pluggable and may be installed or removed with power applied to the main module. The submodule type is identified by name on the label or can be identified by the direction of the two arrows on the label (Rx-Rx, Tx-Tx, or Tx-Rx).

Figure 1. Rear Module Installation for 2040RDA-16FR




To install the optional SFP submodule, refer to Figure 2 on page 11.

- 1. Locate the cage connector on the top right of the rear module corresponding to the front module.
- **2.** With the submodule handle in the up position, slide the metal casing, label side up, into the cage connector on the rear module.

Note When installed properly, the front end of the submodule will line up with the BNCs. Do not try to force it in further.

Figure 2. Installing SFP Submodule



Cabling

All cabling to the 2040RDA module sets is done on the corresponding rear module at the back of the 2000 frame. Cabling to each of the submodule types is described below.


Dual Optical Receiver

With a dual optical receiver (1310NM-DRL) submodule installed, one of the optical inputs can be configured as the module input (instead of the coax BNC).

With the submodule handle in the up position, connect an optical input to the left (Optic 1) or right (Optic 2) side of the optical connector as shown in Figure 3.

Use local or remote controls to configure one of the optical inputs as the module input as described in the instruction manual for the specific module.

Figure 3. Dual Receiver Optical Inputs




Dual Optical Transmitter

With a dual optical transmitter (1310NM-DTL) submodule installed, the output signal can be accessed from both optical outputs, Optic 1 (left) and Optic 2 (right), in addition to the coax BNC outputs.

With the submodule handle in the up position, connect optical cables to one or both outputs as shown in Figure 4.

These outputs must then be enabled with either local or remote configuration controls.

Figure 4. Dual Transmitter Optical Outputs




Optical Transceiver

With the optical transceiver (1310NM-TRL) submodule installed, the Optic 2 input (right) can be configured as the module input (instead of the coax BNC input) and the Optic 1 output (left) can be enabled as a module output (in addition to the coax BNC outputs).

For an optical input to the module, place the submodule handle in the up position and connect the fiber cable to the Optic 2 input (right) as shown in Figure 5. Use local or remote controls to configure this as the module input.

The output signal can also be accessed from the Optic 1 (left) connector shown in Figure 5. Place the submodule handle in the up position and connect an optical cable to this output. This output must be enabled with local or remote configuration controls.

Figure 5. Dual Transceiver Optical Input and Output



GeckoFlex Fiber Ready Modules

This section of the manual describes the installation and cabling of the SFP fiber optic submodule for the fiber ready modules in the GeckoFlex 8900 frame. The front and rear modules must be installed first according to the instructions in the specific GeckoFlex 8900 manual.

Installation

CAUTION The Fiber Optic submodule is static sensitive. Use static handling precautions when installing or removing the submodule.

After the front and rear modules have been installed, install the SFP Fiber Optic submodule option into the rear module metal cage labeled FIBER (Figure 6 on page 14). The SFP submodule is hot-pluggable and may be installed or removed with power applied to the module.

Note The submodule type is identified by name on the label or can be identified by the direction of the two arrow indicators on the label.


- 1. Slide the fiber optic device into the metal fiber cage with the label and handle to the right.
- 2. Push the device in as far as it will go without forcing it. It will not go completely into the cage.
- **3.** Cable the fiber optic connectors according to the instructions given in *Cabling* on page 11.


Cabling

Cabling to the fiber optic submodule is the same for all GeckoFlex modules as shown in Figure 6.

Note 8985FSP modules shipped before June/2006 have the fiber inputs and outputs reversed. Refer to the 8985FSP Instruction Manual for verion 1.0.0 software for cabling information.

Figure 6. Installing Fiber Optics Submodule





Configuration

Once the submodules have been installed and cabled, refer to the specific 2000 and 8900 module instruction manuals for configuration and operation information. In most cases, the fiber inputs and outputs must be enabled using onboard local controls or through the web page GUI.

Manuals are available on-line at no cost at this link:

http://www.thomsongrassvalley.com/docs/

From this location, select Broadcast Products, then Modular Products.

Specifications

Table 1. Optical Submodule Specifications

Parameter	Value	
Fiber Inputs		
Connector	Up to two LC	
Fiber mode	Single mode, 1310 nm nominal	
Minimum input power	-20 dBm	
Input signal formats	Serial digital component video conforming to the following formats: SMPTE 292M (1.485 Gb/s and 1.485 Gb/s/1.001) SMPTE 259M (143 Mb/s, 177 Mb/s, 270 Mb/s, 360 Mb/s) SMPTE 310M (MPEG to 40 Mb/s) SMPTE 347M (540 Mb/s) 4 Mbps to 1.5 Gb/s DVB-ASI	
Fiber Outputs		
Connector	Up to two LC	
Fiber mode	Single mode, 1310 nm nominal	
Output power	-12 to -7.5 dBm (average @ 1310 nm)	
Signal type	Serial digital component video conforming to the following formats: SMPTE 292M (1.485 Gb/s and 1.485 Gb/s/1.001) SMPTE 259M (143 Mb/s, 177 Mb/s, 270 Mb/s, 360 Mb/s) SMPTE 310M (MPEG to 40 Mb/s) SMPTE 347M (540 Mb/s) 4 Mbps to 1.5 Gb/s DVB-ASI	

Specifications

Index

Numerics	on 8900 module 13
1310NM-DRL on 2000 module 11 on 8900 module 14	instruction manuals finding online 15
overview 9	0
1310NM-DTL on 2000 module 12 on 8900 module 14	online documentation 4
overview 9	R
1310NM-TRL on 2000 module 12 on 8900 module 14 overview 9	rear module 2000 module 11
	S
C cabling	software download from web 4 specifications 15
on 2000 module 11 on 8900 module 14	W
configuration 15	web site documentation 4
D	web site FAQ database 4 web site Grass Valley 4
documentation online 4	web site software download 4
F	
FAQ database 4 fiber ready modules Gecko Flex 8900 Series 9 Kameleon 2000 Series 9 frequently asked questions 4	
G	
Grass Valley web site 4	
I	
installation on 2000 module 10	

Index