

# NewsBrowse

DESKTOP BROWSING SYSTEM

Installation and Configuration Guide

● → SOFTWARE VERSION 3.0

071-8424-00  
AUGUST 2005

*the most watched worldwide*

## Copyright

Copyright © 2005 Thomson Broadcast and Media Solutions, Inc. All rights reserved. Printed in the United States of America.

This document may not be copied in whole or in part, or otherwise reproduced except as specifically permitted under U.S. copyright law, without the prior written consent of Thomson Broadcast and Media Solutions, Inc., P.O. Box 59900, Nevada City, California 95959-7900

## Trademarks

Grass Valley, NewsBrowse, NewsEdit, NewsQ, NewsShare, NewsQ Pro, Media Manager, and Profile are either registered trademarks or trademarks of Thomson Broadcast and Media Solutions, Inc. in the United States and/or other countries. Other trademarks used in this document are either registered trademarks or trademarks of the manufacturers or vendors of the associated products. Thomson Broadcast and Media Solutions, Inc. products are covered by U.S. and foreign patents, issued and pending. Additional information regarding Thomson Broadcast and Media Solutions, Inc. trademarks and other proprietary rights may be found at [www.thomsongrassvalley.com](http://www.thomsongrassvalley.com).

## Disclaimer

Product options and specifications subject to change without notice. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Thomson Broadcast and Media Solutions, Inc. Thomson Broadcast and Media Solutions, Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in this publication.

## U.S. Government Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7013 or in subparagraph c(1) and (2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19, as applicable. Manufacturer is Thomson Broadcast and Media Solutions, Inc., P.O. Box 59900, Nevada City, California 95959-7900 U.S.A.

## Revision Status

Rev Date	Description
January 31, 2003	Release to part number 071-8217-00
July 21, 2003	Release for software version 1.5 to part number 071-8217-01
May 25, 2004	Release for software version 2.0. Part number 071-8307-00.
December 16, 2004	Release for software version 2.7. Added information about Advanced Encoder, FlashNet archive, and DIVArchive. Part number 071-8307-01.
August 2, 2005	Release for software version 3.0. New content for NewsShare NAS. Part number 071-8424-00.

# Contents

---

	<b>Preface</b> .....	7
	Grass Valley Product Support .....	8
<b>Chapter 1</b>	<b>System Overview</b>	
	Functional description .....	9
	System diagram - NewsShare NAS .....	11
	Design considerations - NewsBrowse with NewsEdit .....	11
	System diagram - Profile XP Open SAN .....	13
	NetTime system .....	14
	Legacy systems.....	14
<b>Chapter 2</b>	<b>Installing NewsBrowse</b>	
	Rack-mount hardware components .....	16
	About cabling hardware components .....	16
	Cable hardware: MediaFrame support .....	17
	NewsBrowse server instructions: Dell platform .....	17
	NewsBrowse server instructions: HAFT platform .....	19
	MDI Server instructions .....	21
	Cable hardware: Proxy support.....	22
	Advanced Encoder instructions .....	23
	SmartBin Encoder instructions .....	24
	NAS instructions - Fastora.....	25
	NAS instructions - Serial ATA network platform .....	26
	Live monitor encoder instructions .....	27
	Cable hardware: Profile XP ingest support .....	28
	Single-channel encoder instructions.....	28
	RS-422 Cable Pinouts .....	29
	Router Gateway instructions .....	30
	Install NewsBrowse software .....	31
	Other software installation considerations.....	33
<b>Chapter 3</b>	<b>Configuring the NewsBrowse System</b>	
	Configuration overview - NewsShare NAS.....	36
	Establish conventions.....	37
	Machine naming convention.....	37
	MDI and Encoder logical names convention .....	37
	Ports and services mapping .....	40
	Configure network .....	41
	Set up IP addresses and name resolution.....	41
	Configure network settings on Production network machines.....	42
	Configure HAFT platform.....	42
	Configure network settings on Client network machines.....	42
	Firewall considerations .....	43
	Prepare for core configuration stages .....	44
	Prepare NetTime .....	44
	Prepare NetTime servers.....	44
	Prepare NetTime clients .....	45
	Prepare Profile Media Servers .....	46
	Prepare DSM .....	46
	Prepare SmartBins .....	46
	Prepare Advanced Encoders.....	47
	Prepare NAS - Windows Fastora .....	47
	Prepare NAS - Serial ATA network platform .....	50
	Verify NAS access.....	52
	About the nbadm account.....	53

- Accessing services ..... 54
- Accessing system configuration pages ..... 54
- Stop services ..... 56
- MediaFrame stage ..... 57
  - Configure Media Frame ASK: Register components ..... 58
  - Prepare MDI server ..... 60
  - Configure ASK Location: MDI server ..... 61
  - Configure Proxy MDI ..... 62
  - Configure Profile MDIs ..... 63
  - Configure News MDIs ..... 64
  - Configure M-Series MDIs ..... 65
  - Test: MediaFrame stage ..... 66
  - Checklist: MediaFrame stage ..... 66
- SmartBin encoder stage ..... 67
  - Configure ASK Location: SmartBin encoder ..... 68
  - Configure Media Frame Core ASK: SmartBin encoder ..... 68
  - Configure SmartBin Encoder Control ..... 68
  - Configure Proxy Asset (NAS): SmartBin encoder ..... 69
  - Configure MPEG encoder: SmartBin encoder ..... 69
  - Configure Real Media Encoder: SmartBin encoder ..... 70
  - Test: SmartBin encoder ..... 70
  - Checklist: SmartBin stage ..... 70
- Advanced encoder stand-alone stage ..... 71
  - Configure ASK Location: Advanced encoder ..... 72
  - Configure Advanced Encoding Control ..... 73
    - Configuring Encoder Mode ..... 73
  - Configure Proxy Asset (NAS): Advanced encoder ..... 75
  - Configure MPEG encoder: Advanced encoder ..... 75
  - Configure Real Media Encoder: Advanced encoder ..... 76
  - Test: Advanced encoder stand-alone stage - high-res source ..... 76
  - Test: Advanced encoder stand-alone stage - MPEG proxy source ..... 78
  - Checklist: Advanced encoder stand-alone stage ..... 80
- Advanced encoder + Server stage ..... 81
  - Configure Media Frame Core ASK: Advanced encoder ..... 81
  - Configure Rules Automation: Advanced encoder ..... 82
    - About configuring rules ..... 83
    - Tips for configuring rules ..... 83
  - Configure Asset Manager ..... 84
  - About expired assets ..... 84
  - Test: Advanced encoder + Server stage - high-res source ..... 84
  - Test: Advanced encoder + Server stage - MPEG proxy source ..... 85
  - Checklist: Advanced encoder + Server stage ..... 86
- EDL Export, Save, Conform stage ..... 87
  - Configure NTFS MDI ..... 88
  - Configure Media Frame Core ASK: NTFS ..... 88
  - Configure Conform Services ..... 89
  - Configure Export Services ..... 90
  - Configure Save EDL settings ..... 91
  - Test: EDL stage ..... 92
  - Checklist: EDL stage ..... 92
- Archive stage ..... 93
  - Add archive MDI ..... 94
  - Verify archive preparations ..... 95
    - Avalon archive preparations ..... 95
    - FlashNet preparations ..... 95
    - DIVA preparations ..... 96
    - Network connectivity - all archive types ..... 97

	Configure ASK Location: Archive MDI host .....	98
	Configure Media Frame Core ASK: Archive .....	98
	Configure Avalon Archive MDI .....	99
	Configure FlashNet MDI .....	100
	Configure DIVA MDI .....	101
	Configure Archive Services .....	102
	Test: Archive stage .....	102
	Checklist: Archive stage .....	103
	Deploy remaining machines for full system .....	104
	Add live monitor encoders .....	104
	Test system level interactions .....	104
	Multiple scavenge test .....	105
	Profile XP ingest test .....	105
	Purge test .....	106
	Add NewsBrowse Clients .....	106
	Connect server and NAS to customer LAN .....	106
	Set up client PCs .....	107
	Configure NewsBrowse Licenses .....	107
	Administering NewsBrowse user access .....	109
	Configure NewsBrowse Groups .....	109
	Configure NewsBrowse Users .....	110
	Managing NewsBrowse User sessions .....	112
	Adding custom fields .....	112
	Testing NewsBrowse client operations .....	114
<b>Chapter 4</b>	<b>Recovery Planning</b>	
	Encoder failure considerations .....	115
	Server failure considerations .....	115
	Database maintenance and administration .....	115
	Repairing a database that is unusable due to transaction log size .....	116
	How to determine the size of the transaction log .....	116
	Manually controlling transaction log growth .....	117
	Back up the transaction log .....	117
	Shrink the transaction log .....	117
	Setting up a database maintenance plan .....	118
	Database Restoration .....	120
<b>Chapter 5</b>	<b>Troubleshooting the NewsBrowse system</b>	
	Troubleshooting tools .....	121
	MediaFrame troubleshooting tools .....	121
	Proxy troubleshooting tools .....	122
	Proxy troubleshooting tips .....	123
	NewsBrowse application troubleshooting tips .....	125
<b>Appendix A</b>	<b>Component Interaction Diagrams</b>	
	External Ingest Application .....	127
	SmartBin Ingest .....	128
	Metadata .....	129
	NewsBrowse Ingest: Proxy MPEG Creation .....	130
	Scavenge .....	131
	EDL Export as Text File .....	132
	EDL Export to News database .....	133
	EDL NewsBrowse save .....	134
	EDL Conform on Profile .....	135
	EDL Conform via NewsEdit .....	136
	Archive operations on Profile XP .....	137
	Archive operations on News system .....	138

Purge..... 139  
Consolidate ..... 140

**Appendix B Legacy systems**

Three tier system diagram ..... 141  
Two tier system diagram version 2.0 ..... 142  
Configuration overview - Profile XP/Open SAN ..... 143  
Encoder stand-alone stage ..... 144  
    Configure ASK Location: Single-channel encoder ..... 145  
    Configure Ingest Control: Single-channel encoder ..... 145  
    Configure Proxy Asset (NAS): Single-channel encoder ..... 146  
    Configure media server: Single-channel encoder ..... 147  
    Configure MPEG encoder: Single-channel encoder ..... 148  
    Test: Encoder stand-alone stage ..... 148  
    Checklist: Encoder stand-alone stage ..... 150  
Encoder + Server stage ..... 151  
    Configure ASK Location: NewsBrowse server ..... 152  
    Configure Media Frame Core ASK: Single-channel encoder ..... 152  
    Configure Ingest Scheduler: NewsBrowse server ..... 153  
    Set up NewsBrowse client for configuration stage tests ..... 154  
    Test: Encoder + Server stage ..... 154  
    Checklist: Encoder + Server stage ..... 155  
Router Gateway stand-alone stage ..... 156  
    Add Router Gateway ..... 156  
    Configure ASK Location: Router Gateway ..... 157  
    Configure Router Gateway ..... 157  
    Test: Router Gateway stand-alone stage ..... 157  
    Checklist: Router Gateway stand alone stage ..... 158  
Router Gateway + Server stage ..... 159  
    Add Router Gateway to Ingest Scheduler ..... 160  
    Test: Router Gateway + Server stage ..... 161  
    Checklist: Router Gateway + Server stage ..... 161  
    Configure Profile MDI: Conform to air settings ..... 162  
    NewsBrowse server instructions: Axiom platform ..... 163  
Sequential encoder instructions ..... 164  
Image Support Server (ISS) instructions ..... 165  
Prepare NAS - Linux Fastora ..... 166  
Host table files ..... 166  
  
**Index** ..... 169

# Preface

---

This NewsBrowse Installation and Configuration Guide is part of a full set of support documentation for the NewsBrowse system, described as follows:

- **NewsBrowse Installation and Configuration Guide** — Provides explanations and procedures for installing and configuring the NewsBrowse system at a customer site. Includes recovery planning and troubleshooting sections. This document is available in printed form as part of the product bundle when you receive your new system. It is also available in electronic form (PDF file) on the NewsBrowse Application CD-ROM.
- **NewsBrowse Online Help** — Provides instructions for using the NewsBrowse application. This document is available from the NewsBrowse application Help menu.
- **NewsBrowse Release Notes** — Contains the latest information about the NewsBrowse hardware and the software release shipped on your system. The information in this document includes upgrade instructions, feature changes from the previous releases, helpful system administrative information, and any known problems. You receive this document in electronic form (PDF file) on the NewsBrowse Application CD-ROM.

## Grass Valley Product Support

To get technical assistance, check on the status of problems, or report new problems, contact Grass Valley Product Support via e-mail, the Web, or by phone or fax.

### Web Technical Support

To access support information on the Web, visit the product support Web page on the Grass Valley Web site. You can download software or find solutions to problems by searching our Frequently Asked Questions (FAQ) database.

**World Wide Web:** <http://www.thomsongrassvalley.com/support/>

**Technical Support E-mail Address:** [gvgtechsupport@thomson.net](mailto:gvgtechsupport@thomson.net).

### Phone Support

Use the following information to contact product support by phone during business hours. Afterhours phone support is available for warranty and contract customers.

United States	(800) 547-8949 (Toll Free)	France	+33 (1) 34 20 77 77
Latin America	(800) 547-8949 (Toll Free)	Germany	+49 6155 870 606
Eastern Europe	+49 6155 870 606	Greece	+33 (1) 34 20 77 77
Southern Europe	+33 (1) 34 20 77 77	Hong Kong	+852 2531 3058
Middle East	+33 (1) 34 20 77 77	Italy	+39 06 8720351
Australia	+61 1300 721 495	Netherlands	+31 35 6238421
Belgium	+32 2 3349031	Poland	+49 6155 870 606
Brazil	+55 11 5509 3440	Russia	+49 6155 870 606
Canada	(800) 547-8949 (Toll Free)	Singapore	+656379 1390
China	+86 106615 9450	Spain	+ 34 91 512 03 50
Denmark	+45 45968800	Sweden	+46 87680705
Dubai	+ 971 4 299 64 40	Switzerland	+41 (1) 487 80 02
Finland	+35 9 68284600	UK	+44 870 903 2022

### Authorized Support Representative

A local authorized support representative may be available in your country. To locate the support representative for your country, visit the product support Web page on the Grass Valley Web site.

### Profile Users Group

You can connect with other Profile XP Media Platform users to ask questions or share advice, tips, and hints. Send e-mail to [profile-users@thomson.net](mailto:profile-users@thomson.net) to join the community and benefit from the experience of others.



---

# System Overview

NewsBrowse is a media management and editing system. NewsBrowse supports the complete newsroom workflow — from ingest to editing to distribution to archive.

This chapter includes the following topics:

- “Functional description” on page 9
- “System diagram - NewsShare NAS” on page 11
- “System diagram - Profile XP Open SAN” on page 13
- “NetTime system” on page 14
- “Legacy systems” on page 14

## Functional description

NewsBrowse allows the user to browse a low-resolution proxy copy of video material from the desktop. NewsBrowse provides a rich metadata search engine that allows you to search for clips using various criteria. You can also use the NewsBrowse application to edit stories using the low-resolution proxy, which is accessible from the journalist’s desktop. NewsBrowse creates various low-resolution proxy formats for high-resolution material. Proxy formats include MPEG-1, video thumbnails, and storyboards. From the NewsBrowse application you can also archive and restore high-resolution material. Archived assets are still visible from the NewsBrowse application.

With version 3.0 the NewsBrowse system is compatible with the NewsShare NAS architecture. For these systems, NewsBrowse provides a NewsShare “view” of the assets in the system. NewsBrowse systems built previous to version 3.0 access high-resolution material on a Profile XP or Open SAN. These systems continue to use the Profile view of the assets. There are no significant functional differences for an Open SAN system running with NewsBrowse 3.0.

In the NewsShare NAS environment, ingest is controlled by a non-NewsBrowse application, such as Ingest Station, and can incorporate the M-Series iVDR as the video server. The NewsBrowse SmartBin encoder transfers an incoming feed into two formats: a proxy low-resolution (MPEG-1) format stored on the NewsBrowse proxy NAS, and a high-resolution format stored on the NewsShare NAS. NewsBrowse also monitors the NewsShare NAS to create proxy for new high-resolution material. In this way NewsEdit master clips, subclips and sequences are represented in the NewsBrowse system for editing and manipulation. The NewsBrowse EDL export feature creates a News sequence directly in NewsEdit target bin.

In the Profile XP/Open SAN environment, ingest can be controlled by the NewsBrowse application, using a Profile XP as the video server. NewsBrowse processes an incoming feed and simultaneously encodes it into two formats: a proxy low-resolution (MPEG-1) format stored locally on the NewsBrowse proxy NAS, and a high-resolution format stored on the Profile XP or Open SAN. NewsBrowse also monitors the Profile XP or Open SAN to create proxy for new high-resolution material. In this way the high-resolution material is represented in the NewsBrowse


system for editing and manipulation, but there is no direct view of NewsEdit clips. Once you complete a sequence with the NewsBrowse editor, NewsBrowse can use that sequence to pull the corresponding high-resolution video from the Profile XP and assemble an on-air quality sequence. NewsEdit can also use the sequence in a similar way.

For descriptions of the machines used as platforms for the NewsBrowse system, refer to “About cabling hardware components” on page 16.

For descriptions of software components, refer to Appendix A, *Component Interaction Diagrams* on page 127.

## System diagram - NewsShare NAS

This diagram illustrates an example version 3.0 architecture for a system that uses IngestStation for ingest and that accesses the NewsShare NAS.



This diagram illustrates the recommended architecture for version 3.0. Refer to Appendix B, *Legacy systems* on page 141 for previous versions.

The system illustrated here demonstrates the full range of hardware platform types. Smaller systems might not include all types of hardware platforms. Consult the system design for your specific system to determine the hardware platforms you must install.

## Design considerations - NewsBrowse with NewsEdit

Take the following into considerations when establishing the workflow for your use of NewsBrowse on the NewsShare NAS:

**Minimize proxy creation for short-lived material** — The editing process generates multiple pieces of transitional media, but there is no need to create proxy representations of this transitional media. To do so creates an unnecessary load on the system and affects performance.

To avoid this, create at least three designated locations in which material resides to match your workflow, as follows:


- **Inbox** — This is the location in which newly acquired material arrives. Use a

SmartBin—or configure NewsBrowse rules—to automatically create proxy for this material, so you can use NewsBrowse to evaluate and select material for further editing.

- **Workspace** — This is the location in which you store material undergoing the editing process. Do not configure any NewsBrowse rules to create proxy for this material. This saves encoding resources.
- **Outbox** — This is the location in which you place material that has been edited and is usable in its current state. You might have one outbox for on-air material and one outbox for review material. Configure NewsBrowse rules to create proxy for this material, so you can use NewsBrowse to select and use this material.

## System diagram - Profile XP Open SAN

This diagram illustrates the recommended version 3.0 architecture for a system that uses NewsBrowse for Profile XP ingest and that access high-resolution material on a Profile XP or Open SAN.




This diagram illustrates the recommended architecture for version 3.0. Refer to Appendix B, *Legacy systems* on page 141 for previous versions.

The system illustrated here demonstrates the full range of hardware platform types. Smaller systems might not include all types of hardware platforms. Consult the system design for your specific system to determine the hardware platforms you must install.

## NetTime system

The following diagram illustrates the NetTime system required for the Profile XP/ Open SAN environment. Refer to “Prepare NetTime” on page 44.



For the NewsShare NAS environment there is not an exacting requirement for clock synchronization, but you can use NetTime to keep logging entry times in sync on Production Network machines. Client machines do not need NetTime.

## Legacy systems

This manual primarily documents NewsBrowse systems on the NewsShare NAS that are built new for version 3.0 or higher. While existing Profile XP/Open SAN systems can be upgraded to version 3.0 software, their hardware platforms, network architecture, and other elements might not match the systems documented in this manual.

You can find information about systems built before version 3.0 in Appendix B, *Legacy systems* on page 141. If you need the entire overview and task flow for working on a legacy system, you should refer to the version of this manual that corresponds to the software version around which your system was originally built. Refer to “Revision Status” on page 2 of this manual for information about previous manual versions.

---

## ***Installing NewsBrowse***

This chapter provides instructions for installing the hardware platforms and software components that support the NewsBrowse system. Use the instructions that are appropriate for your NewsBrowse system.

The instructions in this chapter are as follows:

- “Rack-mount hardware components” on page 16
- “About cabling hardware components” on page 16
- “Cable hardware: MediaFrame support” on page 17
- “Cable hardware: Proxy support” on page 22
- “Cable hardware: Profile XP ingest support” on page 28
- “Install NewsBrowse software” on page 31
- “Other software installation considerations” on page 33

When you are done installing the hardware and software, continue with [Chapter 3, \*Configuring the NewsBrowse System\*](#) and [Chapter 4, \*Recovery Planning\*](#) to complete the installation of your NewsBrowse system.

## Rack-mount hardware components

Follow the instructions you received with the rack-mount hardware to install each component of the NewsBrowse system. One rack-unit spacing is recommended between components for ventilation.

## About cabling hardware components

Refer to the system design for your particular NewsBrowse system and the appropriate system diagram in [Chapter 1, \*System Overview\*](#) to identify the hardware components and cabling for your NewsBrowse system. Then turn to the appropriate cabling instructions and connect cables as required.

Be aware of the following as you cable your system:

- When connecting the network, use 100Tx cabling and switches (or Gigabit uplink in the case of the NAS). Zoning is not required on the switch if five or less clients are active. If more than five clients are using the system, it is strongly recommended that you use an isolated switch or a shared, zoned switch to isolate the client-side LAN. Network traffic from the NewsBrowse internal LAN is minimized.
- You may want to postpone cabling to external networks until after configuring respective IP addresses.
- Single-channel encoders and live monitor encoders require analog video and audio feeds. Digital to Analog conversion of signals may be required.
- Single-channel encoders require timecode feeds.



## Cable hardware: MediaFrame support

The following sections provide instructions for hardware pieces that support MediaFrame components. Use the instructions that apply to your system design.

- “[NewsBrowse server instructions: Dell platform](#)” on page 17
- “[NewsBrowse server instructions: HAFT platform](#)” on page 19
- “[MDI Server instructions](#)” on page 21

### NewsBrowse server instructions: Dell platform

The central component of the NewsBrowse system is the NewsBrowse server. Depending on the design of your system, it can host the following software components:

- The web-application for user interaction
- The Ingest Scheduler which drives the encoders
- The Rules Wizard for background processing
- The database and Managed Device Interface services for holding and relating assets in the system.

The server connects to all encoders and the Network Attached storage via the network. Refer to the system diagrams in [Chapter 1, System Overview](#). The client network is available for access to the web application.


For the NewsBrowse server you have the option of the Dell platform, as explained in this section, or the HAFT platform, as explained in “[NewsBrowse server instructions: HAFT platform](#)” on page 19.

Platform Specifications are as follows:

- P4, 3GHz, 2 CPU
- 1 GB RAM- CD-ROM Drive
- Minimum 18GB Program Drive
- Windows 2000 Server (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- Flash Player 6 (6.0.65.0 update)
- Microsoft SQL Server (SP3)
- Gb LAN (x2)
- Windows Direct X 9.0c

Cable as illustrated.

#### Dell platform (2850)



Cable as illustrated and as follows:

- For systems with one unified Production Network, connect port 1 to the Production

Network.

- For systems with a Production Network consisting of a media network and a control network, connect port one to the control network.
- For three tier networks, connect port 1 to the Private Network.
- Connect port 2 to the Client Network.


## NewsBrowse server instructions: HAFT platform

For the NewsBrowse server you have the option of the High Availability, Fault Tolerant (HAFT) platform, also known as the Marathon platform. This platform is made up of two interconnected Dell 2850 servers.

Platform Specifications are as follows:

- P4, 3GHz, 2 CPU
- 1 GB RAM- CD-ROM Drive
- Minimum 18GB Program Drive
- Windows 2000 Server (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- Flash Player 6 (6.0.65.0 update)
- Microsoft SQL Server (SP3)
- Gb LAN (x4)

**NOTE: It is no longer recommended to install Windows Media Player on the HAFT platform because of compatibility problems, so you can not run the NewsBrowse application locally on the HAFT platform.**



Cable as illustrated and as follows:

- For systems with one unified Production Network, connect port 1 and the CoServer Management port to the Production Network.
- For systems with a Production Network consisting of a media network and a control network, connect port one and the CoServer Management port to the control network.
- For three tier networks, connect port 1 and the CoServer Management port to the Private Network.
- Connect port 2 to the Client Network.

- Interconnect CoServer Link ports with cross-over cables.
- Connect power cables to a power supply.

Power supply units are hot-swappable.

To power up the HAFT platform, use the normal procedures for the Dell server and log in to the Windows operating system as normal. The virtual server runs in a full screen window. To get to the Dell server desktop, press **Ctrl + Shift + F12**.

To power down the HAFT platform, right-click the system tray icon and select **Manage Endurance Configuration | Shutdown**. This does an orderly shutdown of the virtual server and the Dell server.

Also refer to [“Configure HAFT platform” on page 42](#) for network configuration procedures.

## MDI Server instructions

The MDI server is host for the Managed Device Interface (MDI) services, through which the NewsBrowse system gets its visibility of the assets on the various machines in the system.


The MDI server is an optional component. On systems without a MDI server, the MDI services can run on the NewsBrowse server or other NewsBrowse machine.

Platform Specifications are as follows:

- P4, 3GHz, 2 CPU
- 1 GB RAM- CD-ROM Drive
- Minimum 18GB Program Drive
- Windows 2000 Server (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- Flash Player 6 (6.0.65.0 update)
- Microsoft SQL Server (SP3)
- Gb LAN (x2)

Cable as illustrated.

### Dell platform (2850)



Cable as illustrated and as follows:

- For systems with one unified Production Network, connect port 1 to the Production Network.
- For systems with a Production Network consisting of a media network and a control network, connect port one to the control network.
- For three tier networks, connect port 1 to the Private Network.
- Connect port 2 to the Client Network.

## **Cable hardware: Proxy support**

The following sections provide instructions for hardware pieces that support the processing and storage of proxy media. Use the instructions that apply to your system design.

- [“Advanced Encoder instructions” on page 23](#)
- [“SmartBin Encoder instructions” on page 24](#)
- [“NAS instructions - Fastora” on page 25](#)
- [“NAS instructions - Serial ATA network platform” on page 26](#)
- [“Live monitor encoder instructions” on page 27](#)

## Advanced Encoder instructions

The following components are hosted by the Advanced encoder:

- Thomson Proxy Transfer service.
- News FTP service.


The Advanced Encoder does the following:

- Creates MPEG-1 proxy versions of high-resolution video assets that already exist or are actively being recorded on a video server
- Processes MPEG-1 proxy content and extracts thumbnail images to be used for proxy identification
- Extracts dynamic scene detection images for storyboard creation

The Advanced Encoder processes entirely in the digital domain.

Platform Specifications:

- 2.8 GHz Pentium
- 512 MB RAM
- CD-ROM Drive
- Minimum 40GB Program Drive
- Minimum 250GB Drive (not used)
- Windows 2000 Professional Service Pack 4
- .NET Framework 1.1
- Internet Explorer 6 (SP1)



Cable as illustrated and as follows:

- For systems with one unified Production Network, connect Gigabit port 1 to the Production network. Gigabit port 2 is unused.
- For systems with a Production Network consisting of a media network and a control network, connect Gigabit port 1 to the media network and Gigabit port 2 to the control network.

## SmartBin Encoder instructions

The following components are hosted by the SmartBin encoder:

- Thomson SmartBin Proxy Transfer service. Refer to [“Install NewsBrowse software” on page 31](#).
- SmartBins Service and News FTP service. Refer to [“Other software installation considerations” on page 33](#).


The SmartBin Encoder does the following:

- Creates MPEG-1 proxy versions of high-resolution material
- Processes high-resolution material and extracts thumbnail images to be used for proxy identification
- Extracts dynamic scene detection images for storyboard creation

The SmartBin Encoder processes entirely in the digital domain.

Platform Specifications:

- 2.8 GHz Pentium
- 512 MB RAM
- CD-ROM Drive
- Minimum 40GB Program Drive
- Minimum 250GB Media Cache Drive
- Windows 2000 Professional SP 4
- .NET Framework 1.1
- Internet Explorer 6 (SP1)



Cable as illustrated and as follows:

- For systems with one unified Production network, connect Gigabit port 1 to the Production network. Gigabit port 2 is unused.
- For systems with a Production network consisting of a media network and a control network, connect Gigabit port 1 to the media network and Gigabit port 2 to the control network.




## NAS instructions - Fastora

The NewsBrowse Network Attached Storage (NAS) unit provides storage for MPEG-1 proxy video, storyboards, and thumbnails. It may also be configured to store Edit Decision Lists (EDL) that are saved to the NewsBrowse system. Encoders are configured to write to specific locations on the NAS via 100Tx connections over the network. Client access is provided via Gigabit Ethernet uplink to the Client Network.

Platform Specifications are as follows:

- Microsoft Windows Server 2003
- Redundant Power Supplies
- 1000BaseT LAN
- 100Tx LAN (x2)
- RAID protected drives

For instructions on the Linux version of the Fastora NAS, refer to [“Prepare NAS - Linux Fastora” on page 166](#). If necessary, you can mix Linux versions and Windows versions of the NAS on a single NewsBrowse system.



Cable as illustrated and as follows:

- For systems with one unified Production network, connect LAN port 1 to the Production network.
- For systems with a Production network consisting of a media network and a control network, connect LAN port 1 to the media network and LAN port 2 to the control network.
- Connect Gigabit port 1 to the Client network.
- Connect both power cables from the back of the NAS to a power supply.


Power supply units are hot-swappable. Once power is applied using switches on the rear panel, use the power switch on the front panel to power down. Failure to use the front switch will cause the disk array to rebuild on the next power up.

## NAS instructions - Serial ATA network platform

For the NewsBrowse Network Attached Storage (NAS) unit you have the option of the Serial ATA network (a.k.a. Ciprico 1700 or DiMedia) platform.

Platform Specifications are as follows:

- Redundant Power Supplies.
- 100BT LAN (x2)
- RAID protected drives



Make cable connections as illustrated.

Power supply units are hot-swappable. If the power supply fails or when power is cycled, an alarm will sound. To disable the alarm, press the power alarm reset button to the In position.

Power up the appliance by pressing the small, round On/Standby switch on the front left of the machine. Once the electrical cables are connected, the system has electrical power. Turning the On/Standby switch to standby does not remove power. To remove power, hold down the On/Standby switch for at least five seconds or disconnect the electrical cables.


## Live monitor encoder instructions

The NewsBrowse live monitor encoder converts an audio/video input into network streaming media. The NewsBrowse web application is configured to create pages that point to this streaming media feed. This device accepts audio/video feeds and connects directly to the Client Network. The steaming video is a real-time conversion of the feed being received by a single-channel encoder.

A live monitor encoder is an optional component; it may be absent if there is no need for real-time monitoring, or multiple live monitor encoders may be present to stream different video feeds.

Platform Specifications:

- Pentium 3 1Ghz or better (1 or 2 CPU)
- 256 MB RAM
- CD-ROM Drive
- Minimum 20GB Program Drive
- Windows 2000 Workstation (SP3)
- 100Tx LAN (x2)
- Osprey 220 Streaming Media Encoder.



Cable as illustrated and as follows:

- Connect LAN port 1 to the Client network.
- Connect Analog Audio and Video harness to the source that corresponds to the desired feed for web-based monitoring.

## Cable hardware: Profile XP ingest support

The following sections provide instructions for hardware pieces that support NewsBrowse controlled ingest on a Profile XP system. Use the instructions that apply to your system design.

- “Single-channel encoder instructions” on page 28
- “Router Gateway instructions” on page 30


### Single-channel encoder instructions

The single-channel encoder creates MPEG-1 proxy versions of high-resolution video in parallel with ingest into a video server. A NewsBrowse system may contain multiple single-channel encoders.

If a NewsBrowse system uses Advanced encoders for the creation of MPEG, the single-channel encoder can be an optional component.

Platform Specifications:

- P 3, 1Ghz or better (1 or 2 CPU)
- Windows 2000 Server (SP3)
- 512 MB RAM-
- .NET Framework 1.1
- CD-ROM Drive
- Internet Explorer 6 (SP1)
- Minimum 20GB Program Drive
- 100Tx LAN (x2)



Cable as illustrated and as follows:

- Connect a cable from the Video In port on the Encoder to the analog video feed source.
- Connect a cable from the Audio In port on the Encoder to the analog audio feed source.
- Connect a Timecode cable from the Timecode In port (RCA port) to the house timecode feed.
- For systems with one unified Production network, connect LAN port 1 to the Production network.
- For systems with a Production network consisting of a media network and a control network, connect LAN port 1 to the media network and LAN port 2 to the control network.


network.

- Make sure the LAN port 1 is connected to the network where the Profile exists. Also make sure that the IP address for LAN port 1 is the host tables. A single-channel encoder can be configured to control up to two Profiles simultaneously using Ethernet API.
- Optionally connect a RS-422 control cable from the COM2 port on the encoder to the RS-422 port on the Profile Media Server (only if API is not used). See below for cable pinouts.
- Optionally connect a RS-422 control cable from the COM2 port on the encoder to a backup VTR. See below for cable pinouts.

### RS-422 Cable Pinouts

The RS-422 cable that connects the single-channel encoder and the sequential encoder to a VDCP record channel on the Profile Media Server is a special cable. It needs to use the pinouts described below.

Encoder DB9-F		Profile DB9-M	
1	Tx-	8	Rx-
2	Tx+	3	Rx+
3	Rx+	7	Tx+
4	Rx-	2	Tx-
5	ground	4	ground




## Router Gateway instructions

The NewsBrowse Router Gateway is the host platform for the Router Gateway Service. The NewsBrowse system supports SMS7000 router control and Encore router control via SMS7000 Native Protocol over Ethernet. This device is driven from the Ingest Scheduling process on the NewsBrowse server. The Router Gateway lets NewsBrowse schedule and control ingest services by communicating with your existing router, allowing you to have more ingest feeds than NewsBrowse channels. The Router Gateway provides the bridge between the NewsBrowse Network environment and the Audio/Video Router Control environment.

The Router Gateway is an optional component of the NewsBrowse system. Systems without a stand-alone Router Gateway platform can install the Router Gateway software components on another NewsBrowse system platform, such as the MDI server.

Platform Specifications:

- Pentium 3 1Ghz or better (1 or 2 CPU)
- 256 MB RAM
- CD-ROM Drive
- Minimum 20GB Program Drive
- Windows 2000 Workstation (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- 100Tx LAN (x2)



Cable as illustrated and as follows:

- Connect LAN port 1 to the Production network.
- Connect LAN port 2 to the network where the Router Control system can be accessed.

## Install NewsBrowse software

Do not install NewsBrowse software on new systems. In a new NewsBrowse system, the hardware platforms come from the factory with software pre-installed, so you should not need to install the software.


If you need to install software, refer to the instructions listed below for NewsBrowse software installation. For version-specific instructions, check *NewsBrowse Release Notes*. Also refer to section “[Other software installation considerations](#)” on page 33.

The following installation programs are on the NewsBrowse Application CD:

- ...\*SingleChannelEncoder*\Setup.exe — Use this setup file to install NewsBrowse software on a single-channel encoder.
- ...\*AdvancedEncoder*\Setup.exe — Use this setup file to install NewsBrowse software on an Advanced encoder.
- ...\*SmartBinEncoder*\Setup.exe — Use this setup file to install NewsBrowse software on a SmartBin encoder.
- ...\*Server*\Setup.exe — Use this setup file to install NewsBrowse software on the NewsBrowse server as well as other NewsBrowse machines. The following table indicates the machines on which the software components are typically installed. You might install components differently, depending on the design of your particular NewsBrowse system.

Install Components	NB Server	MDI server	Router Gateway	DSM
Core Services	✓			
Managed Devices: FlashNet Archive		✓		
Profile		✓		
Proxy		✓		
NTFS	✓			
Avalon Network Archive		✓		
DIVArchive		✓		
News				✓
M-Series		✓		
NewsBrowse Application	✓			
Ingest	✓			
Router Gateway			✓	

To install the software components listed in the preceding table, run the NewsBrowse server install program and when you arrive at the Custom Setup screen, do the following:



If a component that you want to install displays a red X, click the component and select **This feature will be installed on local hard drive.**

If a component that you do not want to install does not display a red X, click the component and select **This feature will not be available.**

To upgrade NewsBrowse software from a previous version, refer to *NewsBrowse Release Notes* for version-specific instructions.

**NOTE:** When upgrading NewsBrowse software, read messages and respond carefully. Do not accept the default “Yes” when prompted to delete databases.



## Other software installation considerations

- Before installing the Profile MDI, install Profile client software.
- For the NewsBrowse on NewsShare NAS system, you must install NewsFTP on the Advanced Encoder.
- To support archive functionality on a NewsBrowse on NewsShare NAS system, you must install a unique NewsFTP on a platform somewhere in the system.
- On the SmartBin encoder, in addition to installing NewsBrowse software, you must also install software as follows:

SmartBins Service — Make the following selections in the installation wizard:

On this screen...	Do this...
Select Type of Shared Database	Select <b>NAS</b> .
Select SmartBin Option	Select <b>SmartBins Encoder</b> .
Specify the Servers for the Shared Database	Enter the names of the primary and secondary (if applicable) Database System Managers.
Specify Directory for AV Cache files	Leave set at the default location.
Specify the shared drive(s) in use with this system	Leave set at the default location.

The SmartBins installation also installs NewsFTP. Also refer to [“Prepare DSM” on page 46](#).

For complete instructions refer to the *SmartBins Instruction Guide*.



---

# Configuring the NewsBrowse System


You can use the topics in this chapter in the following ways:

- **Initial configuration** — After your NewsBrowse system components are rack mounted, cabled, and the physical installation process is complete, continue with the configuration instructions in this chapter to create a working system. You can follow the **Basic** path or the **Advanced** path through the core configuration stages, as explained “[Configuration overview - NewsShare NAS](#)” on page 36.
- **Customizing** — After the system is functioning, you can go back to the configuration pages and modify the settings documented in this manual as **Advanced** ✓ to customize the system to fit any special workflow requirements.

The topics in this chapter include the following:

- “[Configuration overview - NewsShare NAS](#)” on page 36
- “[Establish conventions](#)” on page 37
- “[Configure network](#)” on page 41
- “[Prepare for core configuration stages](#)” on page 44
- “[Stop services](#)” on page 56
- “[MediaFrame stage](#)” on page 57
- “[SmartBin encoder stage](#)” on page 67
- “[Advanced encoder stand-alone stage](#)” on page 71
- “[Advanced encoder + Server stage](#)” on page 81
- “[EDL Export, Save, Conform stage](#)” on page 87
- “[Archive stage](#)” on page 93
- “[Deploy remaining machines for full system](#)” on page 104
- “[Add live monitor encoders](#)” on page 104
- “[Test system level interactions](#)” on page 104
- “[Add NewsBrowse Clients](#)” on page 106
- “[Administering NewsBrowse user access](#)” on page 109
- “[Adding custom fields](#)” on page 112
- “[Testing NewsBrowse client operations](#)” on page 114

## Configuration overview - NewsShare NAS



This flowchart illustrates the major tasks required for configuring a NewsBrowse system for the NewsShare NAS.

Before beginning this task flow make sure that the NewsEdit system is fully functioning on the NewsShare NAS. You should have at least one SmartBin Encoder as part of the NewsEdit/NewsShare system. In this role, the SmartBin Encoder is not yet being used as a NewsBrowse machine. Rather, it is just used to host the SmartBins service.

Core configuration tasks are broken down into stages. You can work through the configuration stages in different ways, as follows:

If you are new to the NewsBrowse system, follow the **Basic** path. At each configuration page, configure only those settings documented in this manual as **Basic** ✓. This path allows you to learn the system and resolve configuration problems in stages, with a minimal number of configuration variables and machines added to the system at each stage. Then, after you have gained the understanding to make each stage of the system work properly, configure the remainder of the system and add all machines.

If you are experienced with the NewsBrowse system and you want the fastest possible configuration, follow the **Advanced** path and configure the entire system in one pass, adding all machines at each stage. At each configuration page, you can configure settings documented as **Advanced** ✓ as well as those documented as **Basic** ✓.

You can also choose a combination of Basic and Advanced paths to suit your level of understanding and the design of the particular NewsBrowse system you are configuring.

Refer to the topics in the remainder of this chapter for detailed instructions on each task.

Refer to [Appendix B, Legacy systems](#) for the task flow for Profile XP/Open SAN systems.

## Establish conventions

The following conventions are recommended to make your NewsBrowse system easier to work on and understand. Refer to these sections as necessary as you configure your system.

### Machine naming convention

Choose a root name (based on the site, etc.) and use the following convention for naming machines.

Machine type	Name
<b>MediaFrame machines</b>	
NewsBrowse server	<i>root-nb-svr</i>
Managed Device Interface (MDI) Server	<i>root-nb-mdi</i>
<b>Proxy machines</b>	
Advanced Encoder	<i>root-nb-adv-1...n</i>
SmartBin Encoder	<i>root-nb-sbe-1...n</i>
Network Attached Storage (NAS) <sup>a</sup>	<i>root-nb-nas-1...n</i>
Live monitor encoder	<i>root-nb-live-1...n</i>
<b>Ingest machines</b>	
Stand-alone Profile Media Server	<i>pvs-1...n</i>
Open SAN Profile Media Server	<i>mpvs-1...n</i>
M-Series iVDR	<i>ivdr-1...n</i>

<sup>a</sup> Some NAS devices have restricted characters for naming. For example, the Fastora NAS can't have underscores, while the Ciprico NAS can't have dashes.

If you use a UIM in your system, make sure you follow the UIM naming convention.

### MDI and Encoder logical names convention

As you configure your NewsBrowse system you must create and enter logical names for the various software components (services) that provide NewsBrowse functionality. These logical names provide a mapping of the functionality of the standard NewsBrowse services to the specific machines in your particular system. For this reason you should take care to create logical names that are easy to identify and interpret as they appear in the various configuration pages.

It is especially important that you distinguish between the logical name of a software component and the hostname of the machine to which the software component relates. In the conventions suggested in this manual, machine names are lower case and logical names are upper case to make this distinction.

The software components that require logical names are as follows:

- MDIs — The NewsBrowse system uses a Managed Device Interface (MDI) to manage a device that is not a platform for NewsBrowse software. Typically these are the machines on which media resides, such as Media Servers, NAS devices, and archive devices. Each type of device has its own MDI. The MDI software

component is usually hosted on the NewsBrowse server or an MDI server, rather than being hosted on the same machine that it manages.

- Encoder services — The NewsBrowse system uses services to manage the media processing that takes place on the NewsBrowse encoder machines. Typically these are a type of “transfer” service, such as the Thomson SmartBin Proxy Transfer service. This type of software component is hosted on the machine that it manages.

Also refer to “[Ports and services mapping](#)” on page 40.

The following table demonstrates how logical names for software components are mapped to the machines of your NewsBrowse system and provides a suggested naming convention.

Machine type	Service that manages the machine	MDI/Encoder logical name(s)	Comments
Advanced Encoder	Thomson Proxy Transfer	ADV1, ADV2, ADV3...	One logical name is required for each Advanced encoder.
Avalon Archive	Thomson Avalon Archive MDI	ARCHIVE1	Most NewsBrowse systems have but one archive MDI—of the appropriate type for the archive product—that manages their entire archive system.
DIVA Archive	Thomson DIVA MDI		
FlashNet Archive	Thomson FlashNet MDI		
Image Support Server	Thomson Proxy Transfer	ISS1, ISS2, ISS3...	One logical name is required for each Image Support Server.
M-Series	Thomson MSeries MDI	M-SERIES1, M-SERIES2, M-SERIES3,...	One logical name is required for each M-Series iVDR that integrates with the NewsBrowse system.
News	Thomson News MDI	NEWS1	There is but on News MDI in the system. It manages the NewsShare NAS.
NTFS	Thomson NTFS MDI	NTFS1	There is but one NTFS MDI in the system. It manages NTFS storage on one or more machines—typically the server and the NAS machines.
Profile	Thomson Profile MDI	SAN1	When this MDI manages an Open SAN system, it manages one designated Profile on an Open SAN. One logical name per Open SAN system is required.
		PROFILE1, PROFILE2, PROFILE3,...	When this MDI manages a stand-alone Profile XP system, there is one MDI for each Profile XP. One logical name is required for each stand-alone Profile XP system that integrates with the NewsBrowse system.
Proxy	Thomson Proxy MDI	PROXY1	There is but one Proxy MDI in the system. It manages the storage locations on all the NAS machines.
Sequential Encoder	Thomson Proxy Transfer	SEQ1, SEQ2, SEQ3...	One logical name is required for each Sequential Encoder.
SmartBin Encoder	Thomson SmartBin Proxy Transfer	SBE1, SBE2, SBE3...	One logical name is required for each SmartBin Encoder.

<b>Machine type</b>	<b>Service that manages the machine</b>	<b>MDI/Encoder logical name(s)</b>	<b>Comments</b>
Single Channel Encoder	Thomson Ingest Control	INGEST-CH1, INGEST-CH2, INGEST-CH3...	One logical name is required for each Single Channel Encoder.

***NOTE: If you are exporting NewsBrowse EDLs to NewsEdit, the NewsEdit workstation must be able to resolve the Profile MDI name (present in the EDL) to the IP address of the Profile XP system to which the MDI connects. The recommended solution is to map the MDI name to the Profile IP address in the NewsEdit workstation's host table. Another option is to name the Profile MDI name the same as the Profile host name, but this is only an option for systems in their initial configuration, before any customer assets have been added.***

## Ports and services mapping

NewsBrowse software components run as Windows services, which communicate over designated ports. As you configure the NewsBrowse system, you must correctly designate port numbers. Topics later in this manual provide specific instructions for entering port numbers on each configuration page. Do not create your own convention for port usage. Designate ports as specified in the following table:

Services	Port	Comments
<b>MediaFrame Services</b>		
Thomson Ask	9010	—
Thomson Asset Manager	9022 and 9023	—
Thomson Avalon Archive MDI	9120	—
Thomson DIVA MDI	9122	—
Thomson FlashNet MDI	9124	—
Thomson Metadata	9014	Not visible on a configuration page
Thomson MSeries MDI <sup>a</sup>	9140	—
Thomson News MDI	9150	—
Thomson NTFS MDI	9115	—
Thomson Profile MDI <sup>b</sup>	9130	—
Thomson Proxy MDI	9110	—
Thomson Resolver	9016	Not visible on a configuration page
<b>Proxy Services</b>		
Thomson Proxy Transfer	9230	Starting range for first control. Version 1.5 default port number was 8070.
Thomson RulesWizard	9018 and 9019	Not visible on a configuration page
Thomson SmartBin Proxy Transfer	9230	—
<b>Profile XP Ingest Services</b>		
Thomson Ingest Control (single-channel encoder)	9330	Version 1.5 default port number was 8045.
Thomson Ingest Scheduler	8055	Starting range for first remote control. Not visible on a configuration page.
Thomson Router Gateway	8065	—

<sup>a</sup>. The MSeries MDI Service manages a number of host processes, one for each M-Series iVDR that is being managed. These host processes require ports 9140 - 9149. Stopping/starting the MSeries MDI Service stops/starts all of the host processes.

<sup>b</sup>. The Profile MDI Service manages a number of host processes, one for each Profile that is being managed. These host processes require ports 9130 - 9139. Stopping/starting the Profile MDI Service stops/starts all of the host processes. The version 1.5 default port number for these processes was 8022, with no range.

These services are distributed on different machines in the system. They would not normally run on any one machine, as explained in [“Accessing services” on page 54](#).

The NewsBrowse system also depends upon Microsoft Internet Information Services (IIS) and SQL services. SmartBin encoders also need vbrCacheService and vbrSmartBinsService



## Configure network

Unless otherwise indicated, all information in this chapter refers to a two tier network, which is the supported architecture for this version. Also refer to the system diagrams in [Chapter 1, System Overview](#).

Systems upgrading from version 1.5 may retain the three tier network (which was required for version 1.5) as NewsBrowse 2.0 and higher supports both the three tier architecture and the two tier architecture. Refer to [“Three tier system diagram” on page 141](#). If you are upgrading from version 1.5 to version 2.0 or higher, refer to *NewsBrowse Release Notes* for three tier network configuration instructions.

The recommended networking for new version 3.0 systems is explained in the following sections. Networking strategies used on systems previous to version 3.0, such as host table files, are also compatible with version 3.0. Refer to [“Host table files” on page 166](#).

Also refer to *NAS Security Instruction Guide* and *SAN Security Instruction Guide*.

## Set up IP addresses and name resolution

NewsBrowse systems new for version 3.0 use Microsoft DNS for name resolution and must have a DNS server. The domain controller should provide this service. If the NewsBrowse system does not have a domain controller, another machine may be configured to provide this service. Properly configuring all client network interfaces is extremely important to make DNS name resolution work correctly.

The following applies to the control network on systems expanded to contain two networks—control and media:

- The control network should be set to use dynamic host configuration protocol (DHCP) to assign network IP addresses. All interfaces on this network should be configured to register connections with DNS automatically.

The following applies to the media network on control/media network systems and to the Production network overall on systems with a single, unified Production network:

- Network interfaces should be configured with static IP addresses. These interfaces must also be configured not to automatically register their connections with DNS; each interface on the media network should be manually added as a host entry with “\_he0” appended to the host name. These entries ensure that high-priority network traffic is routed over this network.

**NOTE:** *If you are exporting NewsBrowse EDLs to NewsEdit, the NewsEdit workstation must be able to resolve the Profile MDI name (present in the EDL) to the IP address of the Profile XP system to which the MDI connects. The recommended solution is to map the MDI name to the Profile IP address in the NewsEdit workstation’s host table.*

Refer to [“Host table files” on page 166](#) for an example of a host table.

## Configure network settings on Production network machines

Use the instructions in this section to configure Production network machines, which are all those of the following types:

- Single-channel encoder
- Advanced Encoder
- Router Gateway

From the factory, the machines are set with static IP and as members of “WORKGROUP”. Change the IP addresses, using standard Windows procedures.

## Configure HAFT platform

To configure the HAFT platform for the NewsBrowse networks, do the following:

1. On either CoServer 1 or CoServer 2, configure the virtual server’s network settings as follows:
  - a. Configure PCI-2 A for the Production network. This is the CoServer Management port.
  - b. Configure PCI-2 B for the Production network.
  - c. Configure PCI-1 A for the Client network.
2. Copy these configurations onto the virtual server.

Do not modify the IP addresses of the CoServer Link ports. They are used only for communication between the servers. Refer to [“NewsBrowse server instructions: HAFT platform” on page 19](#).

## Configure network settings on Client network machines

Use the instructions in this section to configure Client network machines, which include the following types:

- NewsBrowse server
- Managed Device Interface (MDI) Server
- Live monitor encoder

NAS machines are also on the Client network. You configure NAS machines in [“Prepare NAS - Windows Fastora” on page 47](#).

DHCP/DNS will provide IP addresses and name resolution for the NewsBrowse devices attached on the client Domain. Refer to [“Set up IP addresses and name resolution” on page 41](#).

You will need the following information from the customer's IT department:

- Verify that the subnet mask for the NewsBrowse machines should be 255.255.255.0.
- Extra IP addresses for future growth
- The IP address for the DNS server and alternate

- The name of the Domain connected on the client side (i.e. *mycorp.com*)
- The IP address for the WINS server if applicable

In addition, the customer IT department must add these computers to their Domain.

Proceed with Client network machines as follows. Use standard Windows procedures:

1. Name computer and add computer to Domain
2. Set IP address for each port, DNS servers
3. Set DNS settings

## **Firewall considerations**

Some sites require that there be a firewall between the Production Network and the Client Network. The firewall should allow incoming HTTP (TCP ports 80 and 280) connections for client and configuration connections to the NewsBrowse Server inside the private network. Additionally, ports should allow incoming packets so requests to the Proxy NAS can be properly processed. The port that needs to be open is port 445 for TCP and UDP for Windows and SAMBA shares

## Prepare for core configuration stages

Do the following tasks in preparation for the configuration of core system functionality.

### Prepare NetTime

This section provides instructions for NetTime on the Profile XP/Open SAN NewsBrowse system. On the NewsShare NAS NewsBrowse system, the requirement for clock synchronization is only to keep log entries matching on production network machines. On the NewsShare NAS NewsBrowse system, you do not need to install NetTime on NewsBrowse clients.

NetTime keeps the system clocks on NewsBrowse machines in sync. Since the Profile Media Servers and single-channel encoders use the house timecode feeds, the other machines need to be kept in sync as well. On systems that control ingest and have single-channel encoders, the primary purpose of NetTime is to keep the Ingest Scheduler, which runs on the NewsBrowse server, and the NewsBrowse client machines synchronized to house time. On systems that do not control ingest, NetTime is still useful to keep clocks synchronized so that system logs can be correlated.

The following procedure uses a single-channel encoder as the Adrienne Absolute Time Server. If your system does not control ingest and has no single-channel encoders, you can use any machine as the Adrienne Absolute Time Server.

The single-channel encoder runs the Adrienne Absolute Time Server. NetTime clients on the production network reference the Adrienne Absolute Time Server. A NetTime server runs on the NewsBrowse server, which rebroadcasts the time to the client network. NetTime clients on the client network reference the NetTime server.

Refer to “[NetTime system](#)” on page 14 for a diagram of the NetTime system.

Set up NetTime with the following procedures:

- “[Prepare NetTime servers](#)” on page 44
- “[Prepare NetTime clients](#)” on page 45

### Prepare NetTime servers


You use one single-channel encoder as the primary Adrienne Absolute Time Server, and another single-channel encoder as the secondary (redundant) Adrienne Absolute Time Server. A LTC connection to house timecode is required for single-channel encoders functioning as Adrienne Absolute Time Servers.

**NOTE:** *Make sure that the Thomson Ingest Control service is off before starting this procedure. If the service is on and you run `AecPciPoll.exe`, the single-channel encoder locks up.*

To prepare a single-channel encoder as a Adrienne Absolute Time Server, do the following:

1. On the single-channel encoder, run the following:

```
C:\AecPciPoll.exe
```



This verifies that the Adrienne card is properly installed and the house timecode is valid.

2. Run *C:\Load Service.bat* and in Task Manager, verify that *NtPciClk.exe* is running.
3. Restart the encoder and verify that *NtPciClk.exe* restarted automatically.
4. Open *C:\ATCSIO.exe* and click **Yes** to install.
5. Restart the encoder and verify that the Absolute Time Server icon appears in the system tray.
6. The encoder is now functioning as the primary Adrienne Absolute Time Server. Repeat this procedure on a second single-channel encoder, to make it the secondary Adrienne Absolute Time Server.

### Prepare NetTime clients

You can also optionally prepare encoders and other NewsBrowse machines as NetTime clients, in case you want to use them to run the NewsBrowse application for test purposes or to keep the PC clock in sync with the rest of the system for the log files.

Some clients need special configuration to ensure time synchronization throughout the NewsBrowse system. Since your single-channel encoder Adrienne Absolute Time Server is on the Production Network, only NetTime clients on the Production Network have access. You must provide access for the external (Client Network) NetTime clients as well. To do this, you configure a NetTime client machine (in this case, the NewsBrowse server) which has access to both Production and Client Networks to rebroadcast the time sync to external networks. NetTime clients on external networks can then look to the NewsBrowse server as their NetTime server.

To prepare a NetTime client, do the following:

1. Open the following folder:  
*C:\Time Sync Software\Client*
2. Open *NetTime-2b6.exe* and click **Yes** to install. Choose the defaults, including **configure as service**.
3. Set Net Time options as follows:
  - a. Enter the host name for the primary and secondary server according to the following table:

NetTime Client	Primary Server	Secondary Server
A Production Network Client	First Encoder	Second Encoder

NetTime Client	Primary Server	Secondary Server
NewsBrowse server	First Encoder	Second Encoder
External (Client Network) Client	NewsBrowse server	—

- b. Select the **RFC868(TCP)** protocol for both servers
  - c. For the NewsBrowse server, select **Allow other computers to sync to this computer.**
  - d. Leave other fields at the defaults and click **Okay.**
4. The PC clock should automatically update to match the server. If not, check network connectivity and review install steps. All machines must be set for the same time zone to function properly.

## Prepare Profile Media Servers

On each Profile Media Server that is to interact with the NewsBrowse system, check the following configurations and modify settings as necessary.

1. Set up as a NetTime client. Refer to preceding procedures.
2. Click **Start | Run**, enter *regedit* and press **Enter**. The Registry Editor opens.
3. In the Registry Editor open the following key:  
HKEY\_LOCAL\_MACHINE/SOFTWARE/Tektronix/Profile/ShuttleAtMode  
Set the key to **TRUE**.
4. On the Profile XP, start **PortServer**.
5. Add a shortcut to PortServer to the startup folder. This ensures that PortServer always runs on the Profile XP, as it is required for NewsBrowse operation.
6. Verify that the following account has been added to the Profile system:
  - username: nbadmin
  - password: \*\*\*\*\*

## Prepare DSM

By convention, the News MDI runs on the DSM. If this is true in your system, you must map the V: drive on the DSM. If the News MDI is not on the DSM, you must map the V: drive on whatever machine is hosting the News MDI.

## Prepare SmartBins

If your NewsBrowse system has SmartBin encoders, refer to *SmartBins Instruction Guide* and do the following:

- Configure the SmartBins service on the News NAS system
- Verify that the mapped drive is V:, unless there are multiple volumes, in which case the mapped drives are V:, W:, X:, Y:.
- Verify configuration to transfer one stream only.
- Create SmartBins in NewsEdit

## Prepare Advanced Encoders

On your Advanced Encoders, in the NewsFTP configuration, make sure that the drive is mapped to the NewsShare storage. Verify that the mapped drive is V:, unless there are multiple volumes, in which case the mapped drives are V:, W:, X:, Y:.

## Prepare NAS - Windows Fastora

For the Linux version, refer to [“Prepare NAS - Linux Fastora”](#) on page 166.

**NOTE: Procure IP addresses from the local network administrator prior to configuring the NAS unit.**

When you configure the Windows Fastora NAS for the NewsBrowse networks, you can make network settings in the following ways:

- **Use the remote Windows desktop**, as explained in step 4 of the following procedure, and then use standard Windows procedures to make all settings. If you do this, read the subsequent steps in the procedure to identify the required settings.
- **Use the Fastora configuration pages** (Web based), as documented in the following procedure, and make settings as instructed.

**NOTE: If you plan to change the name of the NAS unit and you intend to use the underscore character, such as in `root_nb_nas_n`, you must do so using standard Windows procedures via the remote desktop. The Fastora configuration page does not allow the underscore character.**

To configure the Windows Fastora NAS for the NewsBrowse networks, do the following:

1. From any Production network machine, enable the network to recognize the NAS by adding an IP address within the subnet range of 192.168.50.0.
2. For the first NAS machine (`nb-nas-1`), open the NAS configuration software in Internet Explorer by entering the following in the browser address bar:

`https://192.168.50.31:8098`

**NOTE: Notice the *s* in the `https`: address. Also, make sure your browser allows cookies and JavaScript (or JIT).**

Subsequent NAS machines (`nb-nas-2`, `nb-nas-3`) have IP addresses incremented accordingly (192.168.50.32, 192.168.50.33).


If you received your NAS unit directly from Fastora, the default Fastora IP address is 192.168.1.11.

3. Log on as follows:

Username: administrator

Password: triton

The Fastora Welcome page opens.



4. Do one of the following:

- To use the remote Windows desktop rather than the Fastora configuration pages, click **Maintenance | Remote Desktop**. This feature prompts you to again log on to the NAS unit, and then allows you to access the Windows desktop. Make settings with standard Windows procedures.
- To use the Fastora configuration pages, continue with this procedure.

5. Click **Set Server Name** and, if necessary, change the name, DNS suffix, and Domain/Workgroup setting. Work with IT at the customer site to add the NAS to a Domain.

If you make a change, click **OK**.


**NOTE:** After making changes on a configuration page, you must click **OK** or else your changes are lost.

6. Click **Set Administrator Password**.


Set a password according to the customer site requirements. Click **OK** to save settings.



7. Click **Network | Interfaces**. If required by the customer site network, change IP, DNS, and WINS settings. A recommended configuration is to use the Gigabit port for the Client network, use LAN Port 1 for the Production network and leave LAN Port 2 at the default static IP for system maintenance access. For systems with a Production network consisting of a media network and a control network, use LAN port 1 for the media network and LAN port 2 to for the control network.
8. Click **Administration Web Site**. If required by the customer site security policies, change the IP addresses and/or ports for encrypted and non-encrypted access used to access the administration Web site. If you make a change, click **OK** and then reconnect via the new port and/or IP address.
9. Click **Shares | Folders**. Share the media directory as follows:
  - a. Select **New Volume (E:)**
  - b. Click **Manage Folders**.
  - c. Select **media**.



- d. Click **Share Folder**.
- e. Enter the following:  
Share name: media
- f. Click **Windows Sharing**. After a pause, the Windows Sharing tab opens.



- g. User privileges for the media folder should be as follows:
    - Everyone — Read only access
    - nbadmin — Full Control
  - h. Click **OK**.
10. Close the NAS configuration pages.

## Prepare NAS - Serial ATA network platform

To configure the Serial ATA network (a.k.a. Ciprico 1700 or DiMedia) NAS for the NewsBrowse networks, check the following configurations and modify settings as necessary.

**NOTE: Procure IP addresses from the local network administrator prior to configuring the NAS unit. Access to configuration pages is dependent upon valid IP addresses.**

1. From any Production network machine, enable the network to recognize the NAS by adding an IP address within the subnet range of 192.168.50.0.
2. For the first NAS machine (*nb-nas-1*), open the NAS configuration software in Internet Explorer by entering the following in the browser address bar:
 

https://192.168.50.31:9890

**NOTE:** Notice the *s* in the *https:* address. Also, make sure your browser allows cookies and JavaScript (or JIT).

Subsequent NAS machines (*nb-nas-2*, *nb-nas-3*) have IP addresses incremented accordingly (192.168.50.32, 192.168.50.33)

The NAS Administration Tool window opens at the Welcome page.

3. Enter the password. The default password is *triton*. The Status page opens.
4. In the tree view click **Network | Network Ports**. The Configure Network Ports page opens.
5. Configure network ports as follows:
  - a. **Port 0 Client Network** - Set the IP address and subnet mask for the Client network as specified by the local network administrator.

**NOTE:** The DiMeda NAS requires a static IP address for the client port. Set this up with the local network administrator.

- b. **Port 1 Production Network** - Set the IP address for the production network as specified by the local network administrator, then set the subnet mask to 255.255.255.0.

**NOTE:** For detailed information about configuration options, click the Help icon (?) in the upper right corner of each window.

- c. Click **Save**, then select the **Restart** option to restart. Reboot takes 2-10 minutes. Do not power-down the enclosure during reboot.
6. After the NAS reboots, access the NAS configuration software as described earlier in step 2 and step 3, except this time, enter the following in the browser address bar:  
`https://<Client IP Address>:9890`  
The Status page appears.
7. In the Status page tree view, click **Network | Names/IPs**. The Names and IPs page opens.
8. Set the following:
  - **Domain name** - Enter the Client network Domain name.
  - **Gateway** - Enter the IP address for the Client network gateway. Consult the network administrator.
  - **Node Name** - For example: (*root-nb-nas-n*)
9. In the tree view click **System | System Administration | Date/Time**. The Date/Time page opens.
10. Select the correct time zone, date, and time.
11. Click **Save**, then select the **Restart** option to restart.  
Reboot takes 2-10 minutes. Do not power-down the enclosure during reboot.
12. After the NAS reboots, access the NAS configuration software again as described

- in step 6. The Status page appears.
13. In the Status page tree view, click **Storage | Shares | Create** and then click the **Next** button. The CIFS Share page opens.
  14. Specify CIFS options as follows:
    - a. Enter *Media* as the share name.
    - b. Set user privileges. Select all of the following options:
      - Writeable
      - Public
      - Browseable
      - Available(Do not select Case Sensitive)
    - c. Click **Save**.
  15. Close the NAS Administration Tool.

## Verify NAS access

Verify Proxy NAS access from production network machines, which are machines of the following types:

- NewsBrowse server
- Single-channel encoder
- Advanced encoder
- SmartBin encoder

To verify access, from each production network machine do the following:

1. Open Windows Explorer and navigate to the media directory on the NAS. You can do this with the following path:

\\root-nb-nas-1\Media

2. Verify basic read/write capabilities by creating, modifying, and deleting a simple text file.

To verify access from client network machines, choose a machine on the Client network that can represent a NewsBrowse client PC and that is convenient for testing. From this machine do the following:

1. Open Windows Explorer and navigate to the media directory on the NAS. You can do this with the following path:

\\root-nb-nas-1\Media

2. Verify that NewsBrowse client PCs will have read only rights.

## About the nbadmin account

The nbadmin account should be set up by default on NewsBrowse machines that you receive from the factory. This account is critical for most NewsBrowse proxy access, as explained in this section.

A local nbadmin account is required on the following machines:

- Proxy NAS machines
- Single-channel encoder
- Advanced encoder
- SmartBin encoder
- MDI server
- NewsBrowse server
- The News DSM
- M-Series iVDR
- Profile XPS

All NewsBrowse NAS machines require that an *nbadmin* account with a password of \*\*\*\*\* has permission to the folder on the NAS that the encoders write to, and that the web service running on the NewsBrowse server reads from.

The basic principle is that any service that requires write access to the Proxy NAS must run as the nbadmin account. This is a local machine account (NOT a domain account). This includes all encoders, the NewsBrowse server (which creates EDL files on the Proxy NAS), the News MDI (which writes/deletes a temporary EDL file off of the Proxy NAS), the Proxy MDI (which deletes files off of the Proxy NAS) and the Profile MDI (which deletes temporary EDLs off of the Proxy NAS).

On the M-Series iVDR and the single-channel encoder DCOM is used, meaning the DCOM security is invoked. On these devices administrator privilege is required in order to use the DCOM interfaces. This privilege comes from the nbadmin account, which is another way the nbadmin comes into play on these devices.


From a Windows networking perspective, when a user account is defined on a local computer rather than a Domain Controller, the account is a “local” account, whose complete name is <computer name>\<username>, rather than <domain>\<username>. For example, with an encoder named *Encoder1*, a NewsBrowse server named *Server1*, and a NAS named *NAS1*, there are three separate local accounts: *Encoder1\nbadmin*, *Server1\nbadmin*, and *NAS1\nbadmin*.

The Windows network automatically maps a local account from one computer onto the local account of another computer—as long as both the account name and the password are identical. To enable this mapping to occur, the Windows Domain Controller “synchronizes” the local accounts on computers **at the time they join the Domain**. Therefore, if the *nbadmin* account is added to the NAS machine **after** the Windows NAS has joined the Windows Domain, this synchronization does not occur. This should not be a problem on factory-prepared NewsBrowse machines, as they come with the *nbadmin* account pre-configured. However, if the proper sequence is not followed and the problem does occur, the workaround is to remove the NAS from the Windows Domain and then re-add it immediately thereafter.

## Accessing services

Software components are distributed among the machines that make up the system. These software components run as Windows services. A machine has the services that correspond to the software components it hosts.

When you change the configuration for a particular software component through the configuration pages, you must restart that software component's service to put the changes into effect. Click **Start | Settings | Control Panel | Administrative Tools | Services** to access the services. All service names start with "Thomson...", so they group together in the services list.



Refer to [“Ports and services mapping” on page 40](#) for a list of services.

## Accessing system configuration pages

Use Internet Explorer to browse to port 280 of a machine to access its configuration pages. You must have administrator permissions on the machine. For example, to log on to the configuration pages on the NewsBrowse server with administrator permissions, use the following:

Username: `root-nb-svr\nbadmin`

Password: `*****`

The settings you find on a particular computer's configuration pages depend on the software installed on the computer. For example, if the Proxy MDI component is hosted on a single-channel encoder, you find the Proxy Managed Device configuration settings at port 280 of that single-channel encoder. However, if the Proxy MDI component is hosted on a dedicated MDI server, you find the Proxy Managed Device configuration settings at port 280 of the MDI server machine.

You can access a computer's configuration pages as follows:

- From the local computer, use the following URL:  
`http://localhost:280`
- For configuration pages on the NewsBrowse server, you can also open the NewsBrowse launch page and then click the **Configuration** link. To open the NewsBrowse launch page, use the following URL:

`http://localhost/nbui`

The NewsBrowse launch page resides on the NewsBrowse server only.


- From a network-connected computer, substitute *localhost* in the URL with the computer's network name. For example, to access the configuration pages or the NewsBrowse launch page on a NewsBrowse server named *iron-nb-svr*, use the following URLs:

`http://iron-nb-svr:280`

`http://iron-nb-svr/nbui`

You must have network access to open configuration pages. You can access all NewsBrowse devices from the NewsBrowse server. However, devices on the Client Network, such as a NewsBrowse client PC, do not have access to all NewsBrowse devices. From a NewsBrowse client PC you cannot access devices that are on the Production network only, such as single-channel encoders.

To access configuration pages, do the following:



Some pages use Active X controls that require special browser settings, such as the following:

- In Internet Explorer, click **Tools | Internet Options**. The Internet Options dialog box opens. Click **Security | Local intranet | Custom Level**. The Security Settings dialog box opens. Under “Initialize and Script ActiveX Controls not marked as safe”, click **Enable**.

## Stop services


Before beginning your initial core configuration stages, you must stop all services. This prevents the creation of corrupt database records and other errors that result from a partially configured system.

Go to each machine and turn off all “Thomson...” services, as described in [“Accessing services” on page 54](#). Then, when you configure each stage, you start the appropriate services to put the settings into effect. This brings the system on-line in an orderly fashion that allows you to verify system interactions and identify configuration problems.

***NOTE: It is especially important that the Rules Wizard is not running during configuration stage tests that create media files. When a test media file is created, the Rules Wizard can trigger the creation of various types of proxy media. This causes problems because the partially configured system is unable to handle the proxy correctly.***



## MediaFrame stage



MediaFrame components make up the core platform on which NewsBrowse runs. The primary MediaFrame components that you need to configure are as follows:

- **ASK** — The ASK software component runs on the NewsBrowse server. It is the central registry for all the software components of the NewsBrowse system. As software components carry out tasks in a functioning system they regularly refer to the ASK component to establish communication and exchange commands and data. The configuration pages also refer to the ASK component to populate fields and lists and to validate the values you enter as you configure the system.
- **MDIs** — Devices have Managed Device Interfaces (MDIs) which represents the device's assets in a way that is understandable by the other components of the NewsBrowse system. This allows the NewsBrowse server to coordinate the activity of the NewsBrowse system.

In this configuration stage you add a MDI server and then set up logical names for software components that manage devices. This brings the machines of your NewsBrowse system on-line as managed devices.

To do the basic configuration and testing of the MediaFrame software component, do the following, as appropriate for the devices in your system:

- [“Configure Media Frame ASK: Register components” on page 58](#)
- [“Prepare MDI server” on page 60](#)
- [“Configure ASK Location: MDI server” on page 61](#)
- [“Configure Proxy MDI” on page 62](#)
- [“Configure Profile MDIs” on page 63](#)
- [“Configure News MDIs” on page 64](#)
- [“Configure M-Series MDIs” on page 65](#)
- [“Test: MediaFrame stage” on page 66](#)

## Configure Media Frame ASK: Register components

**http://localhost:280 → MediaFrameCore → ASK**      Open this configuration page locally on the NewsBrowse server machine.

Do not modify

Advanced

Basic

**ASK Settings**

Domain: DEFAULTDOMAIN

Port: 9010

Update

---

**Add MDI/Encoder**

MDI/Encoder Name: ADV1

MDI/Encoder Type: Advanced Encoder

Host Name or IP: iron-adv-1

Port: 9230

Add MDI/Encoder

---

**Existing MDIs/Encoders**

PROXY1 (Proxy, iron-nb-mdi:9110)

SAN1 (Profile, iron-nb-mdi:9130)

PROFILE1 (Profile, iron-nb-mdi:9131)

PROFILE2 (Profile, iron-nb-mdi:9132)

Delete MDI/Encoder    Validate MDIs/Encoders

All Domain names in the NewsBrowse system must be identical.

Port 9010 is required. See [“Ports and services mapping” on page 40.](#)

Saves changes. Changes are lost if you leave the configuration page without updating.

For the following settings, use the table below. Add each MDI and/or Encoder required by your system

Click to add an MDI/Encoder.

Lists currently added MDIs and Encoders.

Checks MDIs. Refer to [“Test: MediaFrame stage” on page 66](#)

Deletes the currently selected MDI or Encoder.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the ASK service on the NewsBrowse server.

For the conventions mentioned in the following table, refer to [“MDI and Encoder logical names convention” on page 37](#)

When you add an MDI or Encoder logical name for this type of machine/device...	Select “MDI/Encoder Type”...	Enter “MDI/Encoder Name”...	Enter “Host Name or IP”...	Enter “Port”...	Comments
Open SAN Profile <sup>a</sup>	Profile	As per convention.	Hostname of the machine hosting the Profile MDIs. Typically the MDI server	9130 - 9139	These are process ports, as explained in <a href="#">“Ports and services mapping” on page 40.</a> Assign numbers in an intentional sequence, so they are easy to match in <a href="#">“Configure Profile MDIs” on page 63.</a>
Stand-alone Profile	Profile				
M-Series	MSeries		Hostname of the machine hosting the M-Series MDIs. Typically the MDI server	9140 - 9149	These are process ports, as explained in <a href="#">“Ports and services mapping” on page 40.</a> Assign numbers in an intentional sequence, so they are easy to match in <a href="#">“Configure M-Series MDIs” on page 65.</a>

When you add an MDI or Encoder logical name for this type of machine/device...	Select "MDI/ Encoder Type" ...	Enter "MDI/ Encoder Name"...	Enter "Host Name or IP"...	Enter "Port"...	Comments
NewsEdit	News	As per convention.	Hostname of the machine hosting the News MDIs. This must be the DSM.	Leave field blank. Correct port number is automatically entered on "Add MDI". Refer to <a href="#">"Ports and services mapping" on page 40</a> to verify.	
NTFS storage on Windows machines	NTFS	NTFS1, as per convention.	NewsBrowse server hostname, as the server is the required NTFS MDI host.		
Single-channel encoder	Single Channel Encoder	As per convention.	Single-channel encoder hostname		
Advanced encoder	Advanced Encoder		Advanced encoder hostname		
Proxy	Proxy	PROXY1, as per convention.	Hostname of the machine hosting the Proxy MDI. Typically the MDI server.		
Archive device	... Archive	ARCHIVE1, as per convention.	Hostname of the machine hosting the archive MDI		
SmartBin Encoder	SmartBin Encoder	As per convention.	SmartBin encoder hostname		

<sup>a</sup>. Enter only one Profile per Open SAN. As per convention, name the MDI for the Open SAN, rather than for the Profile.

**NOTE: The NewsBrowse server must host the NTFS MDI.**

The ASK settings page registers the logical names for the MDIs and Encoders required by your NewsBrowse system with the ASK software component, which runs on the NewsBrowse server.

Note the following distinction when entering "Hostname or IP":

- For MDIs (Profile, M-Series, News, Proxy, NTFS, Archive) enter the hostname of the machine hosting the MDI software component, rather than the hostname of the machine being managed by the MDI.
- For Encoders (Advanced Encoder, SmartBin Encoder, Single-channel Encoder) you enter the hostname of the encoder itself.

## Prepare MDI server

A machine that hosts a MDI service takes the role of a MDI server. Refer to the following to identify the machines in your NewsBrowse system that take the role of MDI server, and make sure that the appropriate MDI services are installed. Refer to [“Install NewsBrowse software” on page 31](#).

**Dedicated MDI server** — For medium to large NewsBrowse systems, most MDI services are on a stand-alone MDI server machine, to ensure system performance. If your system has a dedicated MDI server, it comes from the factory with MDI services installed, so you do not need to do any further installation. The MDI server requires only network communication in preparation for its use in the NewsBrowse system.

**NewsBrowse server as MDI server** — For small NewsBrowse systems, the MDI services can reside on the NewsBrowse server. The NewsBrowse server comes from the factory with MDI service installed, to support these smaller systems, so you do not need to do any further installation. The NewsBrowse server also has the NTFS MDI service installed, as it is required to run on the server, regardless of the size of the system.

**DSM server as MDI server** — For all systems, the News MDI must be hosted on the DSM. You must install the News MDI on the DSM.

## Configure ASK Location: MDI server

**http://localhost:280 → ASK Location** Access this page locally on the MDI server.

Do not modify

Advanced

Basic ✓

ASK Location

ASK

Host: iron-nb-svr

Port: 9010

Update

Enter the name of the NewsBrowse server<sup>a</sup>

Port 9010 is required. See [“Ports and services mapping”](#) on page 40.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

It is not necessary to restart a service to put these settings into effect.

<sup>a</sup> If the MDI server is the NewsBrowse server, enter “localhost”.

This page tells the MDI server where to look for the ASK service, which runs on the NewsBrowse server. The function of the ASK is to store the location of the software components in the system, so the components can find one another.

## Configure Proxy MDI

**http://localhost:280 → Managed Devices → Proxy MDI** Access this page locally on the MDI server.

<p>Do not modify</p> <p>Advanced</p> <p>Basic</p>	<p>✓</p> <p>✓</p> <p>✓</p> <p>✓</p> <p>✓</p> <p>✓</p> <p>✓</p> <p>✓</p>	<p><b>Proxy MDI Settings</b></p> <p>Domain: DEFAULTDOMAIN</p> <p>MDI Name: PROXY1</p> <p>Port: 9110</p> <p>Update</p> <p><b>Add Monitored Storage Location</b></p> <p>Monitored Storage Location:</p> <p>Add Monitored Location</p> <p><b>Existing Monitored Storage Locations</b></p> <p>\\iron-nb-nas-1\Media          \\iron-nb-nas-1\Media\Enc 1          \\iron-nb-nas-1\Media\Enc 2          \\iron-nb-nas-1\Media\Scavenge          \\iron-nb-nas-2\Media</p> <p>Remove Monitored Location</p>	<p>All Domain names in the NewsBrowse system must be identical.</p> <p>Must be set to PROXY1, as per convention.</p> <p>Port 9110 is required. See <a href="#">“Ports and services mapping” on page 40.</a></p> <p>Saves changes. Changes are lost if you leave the configuration page without updating.</p> <p>For each Proxy NAS machine, enter the UNC path to the “Media” folder. This is the location to which the NewsBrowse system writes the proxy media.<sup>a</sup></p> <p>Click to add as a location.</p> <p>Lists the currently added locations. You can add multiple locations. You should have one or more locations listed for each NAS machine.</p> <p>Removes the currently selected location.</p>
---	---	---	---

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Proxy MDI Service on the MDI server.

<sup>a</sup> You can define multiple locations on a single NAS machine, but for each location you must enter and add the complete path.

This page configures the Managed Device Interface (MDI) for the NAS machines that store the low-res proxy. The NewsBrowse system depends on the Proxy MDI to make proxy visible across the system.

For the Proxy MDI, there is but one managed device, with the logical name PROXY1. This managed device can have multiple locations. The Media directory on each NAS machine is entered as a location. Other directories can be entered as locations as well. In this way the Proxy MDI knows where to look for the low-res proxy.

## Configure Profile MDIs

Do not modify  
Advanced  
Basic

<http://localhost:280> → **Managed Devices** → **Profile MDI**      Access this page locally on the MDI server.

**Profile MDI Settings**

- Port: 9130 — Port 9100 is required. See [“Ports and services mapping” on page 40.](#)
- Domain: DEFAULTDOMAIN — All Domain names in the NewsBrowse system must be identical.
- Update — Saves changes. Changes are lost if you leave the configuration page without updating.

**Add Profile MDI**

- MDI Name: PROFILE2 — Select a Profile MDI.
- Profile Host Name or IP: pvs-2 — Enter the hostname of the Profile for the MDI selected above.
- Secondary Profile Host Name/IP(s): — For Open SAN systems, enter here the names of the other Profile XP systems on the Open SAN that are managed by this MDI. Separate hostnames with commas.
- Asset System Dwell Time (mins): 2 — The time that the Profile MDI waits before it informs the NewsBrowse system that a clip has finished recording. Leave at 2.
- Port: 9132 — Automatically increments so each Profile MDI has a unique process port.
- Add Profile Managed Device — Click to add as an existing managed device. For stand-alone Profile Media Servers, add a MDI for each one. For Open SAN Profile Media Servers, add only one MDI per Open SAN.

**Existing Profile MDIs**

- 0 - SAN1 mpvs-1 2 9130
- 1 - PROFILE1 pvs-1 2 9131
- Remove Profile Managed Device — Click to remove the selected managed device.

**Add Transfer Target**      The transfer operation requires the fibre channel

- Profile MDI Name: PROFILE2 — Select the MDI for a Profile to which assets can be transferred.
- Profile Host Name: pvs-2 — Hostname of the Profile specified above.
- Add Transfer Target — Click to add as a transfer target. This makes the Profile available for selection from the NewsBrowse application as a transfer destination.

**Existing Transfer Targets**

- PROFILE1 pvs-1 — Profiles capable of receiving a Fibre Channel transfer.
- Remove Transfer Target — Click to remove the selected transfer target.

Always click **Update...** buttons after making changes  
To put changes into effect, start or restart Profile MDI Service on the MDI server.

This page configures the Managed Device Interfaces (MDI) for the Profile Media Servers. As you add Profile MDIs make sure that you associate Profile MDIs and Profile host names correctly.

Multiple Profile MDIs run on a single machine (the MDI server), but they each need their own process port number. For this purpose the “Port” field automatically increments. To use the automatically incremented port numbers, make sure you add Profile MDIs in the correct sequence. You can also manually enter port numbers. The MDIs and their port numbers must match settings as in [“Configure Media Frame ASK: Register components” on page 58.](#)

For configuring the basic MediaFrame stage, do not yet configure transfer targets.

## Configure News MDIs

Do not modify  
Advanced  
Basic

<http://localhost:280> → Managed Devices → News MIDI Access this page locally on the DSM.

Select a News MIDI.

Port 9150 is required. See [“Ports and services mapping” on page 40.](#)

The time that the News MIDI waits before it informs the NewsBrowse system that a clip has finished recording. Leave at 2.

Enter the machine that hosts the NewsShare database (the DSM).

Enter the machine that hosts the conform service.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart News MIDI Service on the MIDI server.

The V: drive must be mapped on the machine that hosts the News MIDI. By convention, the DSM hosts the News MIDI.

This page configures the Managed Device Interface (MDI) for the NewsShare system. MediaFrame depends on the News MIDI to make News assets visible across the system.

As you configure the News MIDI make sure that you associate the News MIDI and News host names correctly.



## Configure M-Series MDIs

Do not modify  
Advanced  
Basic

**http://localhost:280 → Managed Devices → MSeries MIDI** Access this page locally on the MDI server.

Select a M-Series MDI.

Automatically increments so each M-Series MDI has a unique process port.

Enter the M-Series managed by the MDI.

Click to add as an existing managed device.

Verify the MDIs currently on-line.

Click to remove the selected managed device.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart News MDI Service on the MDI server.

This page configures the Managed Device Interface (MDI) for the M-Series iVDR. MediaFrame depends on the M-Series MDI to make M-Series assets visible across the system.

As you configure the M-Series MDI make sure that you associate the M-Series MDI and M-Series host names correctly.

Multiple M-Series MDIs run on a single machine (the MDI server), but they each need their own process port number. For this purpose the “Port” field automatically increments. To use the automatically incremented port numbers, make sure you add M-Series MDIs in the correct sequence. You can also manually enter port numbers. The MDIs and their port numbers must match settings as in [“Configure Media Frame ASK: Register components” on page 58](#).

## Test: MediaFrame stage

The following test exercises system functionality exclusive to the MediaFrame core platform. A successful test verifies that the basic configurations are correct.

Run the test as follows:

On the Ask Settings configuration page, click **Validate MDIs**. The MediaFrame core system checks MDI mappings and devices for inconsistencies. This can take several minutes. A report is displayed.

<b>backup_15</b>	<b>nb-server1:9130</b>
Asset Service	Online
Transfer Service	Online
<b>Ingest1</b>	<b>nb-liveenc1:9330</b>
Ingest Service	Online
<b>NTFS</b>	<b>nb-server1:9115</b>
Asset Service	Online
Transfer Service	Online
<b>PROXY1</b>	<b>nb-server1:9110</b>
Asset Service	Online
<b>ISS1</b>	<b>nb-livemon1:9230</b>
Transfer Service	Online
<b>Sequential1</b>	<b>nb-liveenc2:9230</b>
Transfer Service	Online
<b>AdvancedEncoder</b>	<b>nb-750-eval:9230</b>
Transfer Service	Online

Make sure there are no errors displayed. To troubleshoot errors, check the following:

- Make sure services are running
- Make sure you have configured the correct host name for the MDI service.
- Ping machines to verify network communication.

## Checklist: MediaFrame stage

Use the following check list to verify that the basic configuration and testing of the MediaFrame stage is complete.


- All logical MDI names and Encoder service names are registered with ASK.
- All machines taking the role of MDI server have the appropriate MDI services installed and running.

## SmartBin encoder stage

Before starting this configuration stage you should have a working NewsEdit/ NewsShare system that uses at least one SmartBin Encoder. In this role, the SmartBin Encoder is not yet being used as a NewsBrowse machine. Rather, it is just used to host the SmartBins service. Refer to *SmartBins Instruction Guide*.

For this configuration stage you configure the SmartBin encoder to work together with the ingest video server, the Media NAS and the Proxy NAS. MDI services are also required, as configured in the MediaFrame stage.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to “[System diagram - NewsShare NAS](#)” on page 11 for a view of the entire NewsBrowse system.

To do the basic configuration and testing of the SmartBin, do the following:

1. “[Configure ASK Location: SmartBin encoder](#)” on page 68
2. “[Configure Media Frame Core ASK: SmartBin encoder](#)” on page 68
3. “[Configure SmartBin Encoder Control](#)” on page 68
4. “[Configure Proxy Asset \(NAS\): SmartBin encoder](#)” on page 69
5. “[Configure MPEG encoder: SmartBin encoder](#)” on page 69
6. “[Configure Real Media Encoder: SmartBin encoder](#)” on page 70
7. “[Test: SmartBin encoder](#)” on page 70

## Configure ASK Location: SmartBin encoder

Do not modify  
Advanced  
Basic

http://root-nb-sbe-n:280 → ASK Location

ASK Location

ASK  
Host: iron-nb-svr — Enter the name of the NewsBrowse server  
Port: 9010 — Port 9010 is required. See “Ports and services mapping” on page 40.  
Update — Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes  
It is not necessary to restart a service to put these settings into effect.

This page tells the SmartBin encoder where to look for the ASK service, which runs on the NewsBrowse server. The function of the ASK is to store the location of NewsBrowse components.

## Configure Media Frame Core ASK: SmartBin encoder

Make sure the SmartBin encoder is registered with the ASK software component with a logical name, as explained in “Configure Media Frame ASK: Register components” on page 58.

## Configure SmartBin Encoder Control

Do not modify  
Advanced  
Basic

http://root-nb-sbe-n:280 → SmartBin Encoder → SmartBin Encoder Control

Configure SmartBin Encoder Control

Configure SmartBin Proxy Transfer Control  
Remote Port: 9230 — Port 9230 is required. See “Ports and services mapping” on page 40.  
Update — Always click **Update...** buttons after making changes

Configure News Asset Information  
MDI Name: NEWS1 — Select the News MDI.  
Days to Expire Asset: 5 — Expired assets are purged from the system after this many days. Defines the age of the MPEG asset after which it is automatically deleted from the system the next time the purge rule runs. Leave blank to never expire. Refer to “About expired assets” on page 84.  
Update — Always click **Update...** buttons after making changes

Configure Proxy Types  
 MPEG-1  Thumbnail  Storyboard  Real Video — Select the proxy formats this SmartBin encoder creates.  
Update — Saves changes. Changes are lost if you leave the configuration page without updating

Always click **Update...** buttons after making changes  
To put changes into effect, start or restart the Thomson SmartBin Proxy Transfer service on the SmartBin encoder.

This page configures the SmartBin encoder.

## Configure Proxy Asset (NAS): SmartBin encoder

Do not modify  
Advanced  
Basic

<http://root-nb-sbe-n:280> → SmartBin Encoder → Proxy Asset Information

There is but one logical Proxy Managed Device in the system, named PROXY1.<sup>a</sup>

Select the path to the folder (\Media) on the NAS (or other storage location) that receives the MPEG this encoder creates.<sup>b</sup>

Validates the current configurations with the Proxy MDI settings and saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the SmartBin Proxy Transfer service on the SmartBin encoder.

<sup>a</sup>. PROXY1 can have multiple folders (on multiple machines) defined as locations for proxy files. These locations are defined on the Proxy MDI configuration page.

<sup>b</sup>. This location is used when in Rules, Proxy Storage Location is blank (\*).

This page specifies the default location (on a NAS machine) in which the SmartBin encoder places the MPEG, thumbnail, and storyboard proxy it creates.

When this page opens and when you click a ... button, fields and lists are populated with valid information as currently defined on the Proxy MDI settings page.

## Configure MPEG encoder: SmartBin encoder

Do not modify  
Advanced  
Basic

<http://root-nb-sbe-n:280> → SmartBin Encoder → MPEG Encoder

Leave at default of 1000000.

The MPEG encoder audio output. Adjust to calibrate Advanced Edit audio, or to improve the quality of the desktop audio (i.e. if the source is 'too hot')

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes


Restart the Thomson Proxy Transfer service on the Advanced encoder.

This page configures the parameters the encoder uses when it creates the MPEG proxy.

## Configure Real Media Encoder: SmartBin encoder

Do not modify  
Advanced ✓  
Basic ✓

http://root-nb-sbe-n:280 → SmartBin Encoder → Real Media Encoder



Select **56K**. Higher settings consume SmartBin encoder system resources and cause performance degradation.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the SmartBin Proxy Transfer service on the SmartBin encoder.

This page sets the resolution for the Real Media proxy created by the SmartBin encoder.

### Test: SmartBin encoder

The following test exercises system functionality exclusive creating MPEG, storyboard, and thumbnail proxy from a high-res source clip. A successful test verifies that the basic configurations are correct.

ASK configuration, as in [“MediaFrame stage” on page 57](#), is required for this test.

Test description: Trigger proxy creation by placing high-res material in the location monitored by the SmartBin Encoder.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. Start the Thomson Resolver service and the Thomson Metadata service on the NewsBrowse server.
3. Start the Thomson SmartBin Proxy Transfer service on the SmartBin encoder.
4. Click **Start | Programs | Thomson | Event Viewer** to open Event Viewer.
5. Use Ingest Station to record to a SmartBin on the M-Series iVDR.
6. Watch Event Viewer and verify that the MPEG, storyboard, and thumbnail proxy are created and copied to News NAS and NewsBrowse NAS.

### Checklist: SmartBin stage


Use the following check list to verify that the basic configuration and testing of the SmartBin encoder is complete.

- When high-res material appears in the location monitored by the SmartBin encoder, MPEG, thumbnail, and/or storyboard proxy are created.
- SmartBins Service writes to News NAS
- SmartBin encoder writes to NewsBrowse NAS

## Advanced encoder stand-alone stage

For this configuration stage you configure and test one Advanced encoder and one NAS to work together. The Advanced encoder functions as both an Image Support Server to create thumbnail, and storyboard assets, and as a Sequential (scavenge) encoder to create MPEG proxy assets.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to [“System diagram - Profile XP Open SAN”](#) on page 13 for a view of the entire NewsBrowse system.

To do the basic configuration and testing of a Advanced encoder stand-alone, do the following:

1. [“Configure ASK Location: Advanced encoder”](#) on page 72
2. [“Configure Advanced Encoding Control”](#) on page 73
3. [“Configure Proxy Asset \(NAS\): Advanced encoder”](#) on page 75
4. [“Configure MPEG encoder: Advanced encoder”](#) on page 75
5. [“Configure Real Media Encoder: Advanced encoder”](#) on page 76
6. [“Test: Advanced encoder stand-alone stage - high-res source”](#) on page 76
7. [“Test: Advanced encoder stand-alone stage - MPEG proxy source”](#) on page 78
8. [“Checklist: Advanced encoder stand-alone stage”](#) on page 80

## Configure ASK Location: Advanced encoder

This page tells the Advanced encoder where to look for the ASK service, which runs on the NewsBrowse server. The function of the ASK is to store the location of NewsBrowse components.



## Configure Advanced Encoding Control

http://root-nb-adv-n:280 → Advanced Encoder → Advanced Encoding Control

Do not modify	Configure Advanced Encoding Control	
Advanced	Configure Proxy Transfer Control	
Basic	Remote Port: 9230	Port 9230 is required. See “Ports and services mapping” on page 40.
	Update	Always click <b>Update...</b> buttons after making changes
	GXF Servers Info	
✓	GXF Server Host Name: UIM1_heo	Enter the host name of the UIM or the host of the NewsFTP service. If the Advanced Encoder is the host, you can enter <i>localhost</i> .
✓	Max. Startup Delay: 60	Enter the maximum time the encoder waits for recording to begin after a clip is created in the database. 60 seconds is the recommended setting. <sup>a</sup>
✓	Stream Timeout: 60	Enter the maximum time the encoder waits for a break in the media stream to be restored. 60 seconds is the recommended setting. <sup>b</sup>
✓	Add GXF Server	Click to add as a GXF server for this encoder.
✓	IP= UIM1_heo :Port=0:StartupDelay=60:StreamTimeout=60	GXF servers currently added for this encoder.
✓	Remove GXF Server	Remove the currently selected GXF server
	Encoder Mode Configuration	Refer to “Configuring Encoder Mode” on page 73 for the following settings.
✓	MDI Type: Material	Select <b>Material</b> to create proxy from a high-res source. Select <b>Proxy</b> to create additional proxy from an existing MPEG proxy source.
✓	MDI Name: *	The MDI of the device on which the source resides.
✓	Storage Location: *	The location of the source.
✓	Update	Saves changes. Changes are lost if you leave the configuration page without updating

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Proxy Transfer service on the Advanced encoder.

<sup>a</sup>. When you create a new clip name in the media database on the Profile XP, the encoder is notified and waits for the media file to appear. Set this value to be the maximum time allowed in your workflow between the creation of a clip name and the commencement of recording the clip.

<sup>b</sup>. If the high-res stream for which the encoder is creating proxy material is interrupted, the encoder waits this long for the stream to continue.

This page configures the connections between the Advanced encoder and the server from which it gets its media stream, such as a UIM.

### Configuring Encoder Mode

These settings allow you to set up the Advanced Encoder to generate proxy for high-priority Profile XP ingest material. This dedicated Advanced Encoder then only runs scavenge operations when new material appears in a specific ingest location. That way you can be assured that your high-priority ingest material is immediately processed, even if there are multiple other lower priority scavenge jobs that need to be done at the same time. Your other un-dedicated Advanced Encoders can do the low priority jobs without interfering with the availability of the dedicated Advanced Encoders.

To dedicate the Advanced Encoder to an ingest folder on a Profile XP system, do

the following:

- For MDI Type, select **Material**.
- For MDI Name, select a valid Profile MDI Name (other than “\*”).
- For Storage Location, select a valid Profile Storage Location (other than “\*”).

If the NewsBrowse system uses both Single Channel Encoders and Advanced Encoders, you must configure so as to guarantee the generation of Storyboard/ Thumbnails for the proxy generated by the Single Channel Encoder. In this case do the following:

- For MDI Type, select **Proxy**.
- For MDI Name, enter “\*” or select a valid Proxy MDI name.
- For Storage Location, enter “\*” or select a valid location name.

You can dedicate the Advanced encoder to a particular Proxy NAS location. This assumes that for a single Proxy MDI (PROXY1) there are multiple NAS locations.

- To configure the Advanced encoder to process proxy media on all locations, enter “\*”.
- To configure the Advanced encoder to process proxy media on one location, select that location as the Proxy Storage Location.


Configuration rules:

- If the MDI name is “\*”, the Storage Location must be “\*”.
- If the configuration file is manually updated (not recommended) to disable both Material Source and Proxy Source, the following occurs:
  - Proxy Transfer Service will log an error message “Error: Both Scavenge Mode and ISS Mode are disabled. This Encoder will not be able to do any encoding” in the log.
  - On the Advanced Encoding Control configuration page, red text “Error: Both Scavenge Mode and ISS Mode are disabled. This Encoder will not be able to do any encoding” is displayed.

## Configure Proxy Asset (NAS): Advanced encoder

Do not modify  
Advanced  
Basic

http://root-nb-adv-n:280 → Advanced Encoder → Proxy Asset Information



There is but one logical Proxy Managed Device in the system, named PROXY1.<sup>a</sup>

Select the path to the folder (\Media) on the NAS (or other storage location) that receives the MPEG this encoder creates.<sup>b</sup>

Validates the current configurations with the Proxy MDI settings and saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Proxy Transfer service on the Advanced encoder.

<sup>a</sup>. PROXY1 can have multiple folders (on multiple machines) defined as locations for assets. These locations are defined on the Proxy MDI configuration page.

<sup>b</sup>. This location is used when in Rules, Proxy Storage Location is blank (\*).


This page specifies the default location (on a NAS machine) in which the Advanced encoder places the MPEG proxy, thumbnail, and storyboard assets it creates.

When this page opens and when you click a ... button, fields and lists are populated with valid information as currently defined on the Proxy MDI settings page.

## Configure MPEG encoder: Advanced encoder

Do not modify  
Advanced  
Basic

http://root-nb-adv-n:280 → Advanced Encoder → MPEG Encoder



Leave at default of 1000000.

The MPEG encoder audio output. Adjust to calibrate Advanced Edit audio, or to improve the quality of the desktop audio (i.e. if the source is 'too hot')

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes


Restart the Thomson Proxy Transfer service on the Advanced encoder.

This page configures the parameters the encoder uses when it creates the MPEG proxy assets.

## Configure Real Media Encoder: Advanced encoder

Do not modify  
Advanced ✓  
Basic ✓

http://root-nb-adv-n:280 → Advanced Encoder → Real Media Encoder



Select **56K**. Higher settings consume Advanced encoder system resources and cause performance degradation.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Proxy Transfer service on the Advanced encoder.

This page sets the resolution for the Real Media assets created by the Advanced encoder.

### Test: Advanced encoder stand-alone stage - high-res source

The following test exercises Advanced encoder functionality for creating proxy using Profile high-res material as the source. A successful test verifies that the basic configurations are correct.

Test description: New proxy types (MPEG, thumbnail, storyboard) are created from high-res material and are transferred to a different location.


ASK configuration, as in [“MediaFrame stage” on page 57](#), is required for this test.

**NOTE:** Run this test only in the stand-alone stage, with machines that have not yet been added as managed devices (as in the + Server stage). Once the server is connected, this test can result in corrupt database records.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. Make sure the Rules Wizard Service, Thomson Resolver service, and the Thomson Metadata service are off on the NewsBrowse server.

- On the Advanced encoder, click **Start | Programs | Thomson | NewsBrowse | Diagnostic Tools | Proxy Transfer Client**. The Proxy Transfer Client application opens.



- Configure as follows to check the connection:
  - Host: **localhost**
  - Port: **9230**
- Click **Connect**. Verify that the "...Update..." and "...Transfer..." buttons become enabled, which means the connection is successful.
- Configure as follows to define the source clip on the Profile XP:
  - Source Type: Select **Material**.
  - MDI Name: Select the logical name of the MDI that manages the Profile.
  - MDI Type: Select **device/profile**
  - Location: Select the bin on the Profile that holds the test material.
  - Clip Name: Select the test clip.

- Clip Type: Select **video/profile.cmf**
7. Select the following to transfer/transcode proxy:
    - MPEG-1
    - Thumbnail
    - Story Board
  8. Click **Transfer (With Auto update)**. Watch the report in the State column to verify that the proxy creation is successful. The proxy files are written to the location configured on the Proxy Asset configuration page as “Default File System Folder”.
  9. Using Windows Explorer, verify the MPEG, storyboard, and thumbnail proxy is created. Open and play the MPEG clip. Validate video and audio.

### **Test: Advanced encoder stand-alone stage - MPEG proxy source**

The following test exercises system functionality exclusive to configurations for creating thumbnail and storyboard proxy from MPEG proxy. A successful test verifies that the basic configurations are correct.

Test description: Thumbnail and storyboard proxy are created from MPEG proxy.


ASK configuration, as in [“MediaFrame stage” on page 57](#), is required for this test.

***NOTE: Run this test only in the stand-alone stage, with machines that have not yet been added as managed devices (as in the + Server stage). Once the server is connected, this test can result in corrupt database records.***

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. Make sure the Rules Wizard Service, Thomson Resolver service, and the Thomson Metadata service are off on the NewsBrowse server.

- On the Advanced encoder, click **Start | Programs | Thomson | NewsBrowse | Diagnostic Tools | Proxy Transfer Client**. The Proxy Transfer Client application opens.



- Configure as follows to check the connection:
  - Host: **localhost**
  - Port: **9230**
- Click **Connect**. Verify that the "...Update..." and "...Transfer..." buttons become enabled, which means the connection is successful.
- Configure as follows to define the MPEG source on the NAS:
  - Source Type: Select **Proxy**.
  - MDI Name: Select the logical name of the Proxy MDI.
  - MDI Type: Select **device/proxy**.
  - Location: Select the directory on the NAS that holds the test proxy MPEG.
  - Clip Name: Select the test clip.

- Clip Type: Select **video/proxy.mpeg**
7. Select the following to transfer/transcode proxy:
    - Thumbnail
    - Story Board
  8. Click **Transfer (With Auto update)**. Track progress in the State column until it reports DONE. The proxy files are written to the location configured on the Proxy Asset configuration page as “Default File System Folder”
  9. Using Windows Explorer, verify that the thumbnail and storyboard test files were written to the proper directory.

### **Checklist: Advanced encoder stand-alone stage**

Use the following check list to verify that the basic configuration and testing of the stand-alone Advanced encoder is complete.


- Advanced encoder is connected to NAS
- Encoder writes to NAS
- MPEG created
- MPEG playback with audio
- Thumbnails files are created.
- Storyboard files are created.



## Advanced encoder + Server stage

For this configuration stage you configure the NewsBrowse server to work together with the Advanced encoder and NAS from the Advanced encoder stand-alone stage. MDI services are also required, as configured in the MediaFrame stage.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to [“System diagram - Profile XP Open SAN”](#) on page 13 for a view of the entire NewsBrowse system.

To do the basic configuration and testing of the encoder plus server, do the following:

1. [“Configure Media Frame Core ASK: Advanced encoder”](#) on page 81
2. [“Configure Rules Automation: Advanced encoder”](#) on page 82
3. [“Test: Advanced encoder + Server stage - high-res source”](#) on page 84
4. [“Test: Advanced encoder + Server stage - MPEG proxy source”](#) on page 85
5. [“Checklist: Advanced encoder + Server stage”](#) on page 86

### Configure Media Frame Core ASK: Advanced encoder

Make sure the Advanced encoder’s Proxy Transfer service is registered with the ASK software component with a logical name, as explained in [“Configure Media Frame ASK: Register components”](#) on page 58.

## Configure Rules Automation: Advanced encoder

http://root-nb-svr:280 → Media Frame Core → Rules Automation

Rules Automation Settings

**Proxy Creation Rule**

Source: Material — Select **Material** if this rule creates proxy from a high-res source. Select **MPEG-1** if this rule creates additional proxy from an existing MPEG proxy source. Refer to “About configuring rules” on page 83.

MDI Name: NEWS1 — Select the MDI for the machine monitored by the Advanced encoder.

MDI Storage Location: HoldForReview — Enter the location on the machine that the NewsBrowse system monitors for new material. *Note: You must use forward slashes for this path.*

Include Subfolders — Select to also monitor for material in folders nested in “MDI Storage Location”.

Proxy Types:  MPEG-1  Thumbnail  Storyboard  Real Video — Select the proxy types to be created by this rule. (MPEG-1 option appears only if Source = Material above.)

Proxy MDI Name: PROXY1 — Must be PROXY1. (This option appears only if Source = Material above.)

Proxy Storage Location: Wron-nas-1\media — Enter the location or \*, so the system can use any NAS and keep proxy assets together.<sup>a</sup> (This option appears only if Source = Material above.)

Transfer Priority: Normal — Set all rules to Normal to ensure all are processed in the order received. Higher or lower priority settings can cause a delay for the lower priority rules.

Options:  Create while Recording  Recreate Proxy if Content is Modified — Select one or both. Refer to “About configuring rules” on page 83. (These options appear only if Source = Material above.)

Expire Asset in 1 Days — Expired assets are purged from the system after this many days. Leave blank to never expire. Refer to “About expired assets” on page 84. (This option appears only if Source = Material above.)

— **Add Rule** adds the above settings as a new Proxy Creation rule. The **Update Rule** button only appears if an existing rule is selected in the Existing Rules box below, in which case the button puts into effect any changes you have made to the existing rule.

**Existing Rules**

Create Proxy from material. MDI: NEWS1.Conformed  
 Create Proxy from material. MDI: NEWS1.HoldForReview  
 Create Proxy from material. MDI: NEWS1.RestoreFromArc

— Removes the currently selected rule

**Rule Retry Policy**

Max Number Of Retries: 3 — Specifies how many times the system retries a failed rule. Keep this setting at 3 or below for most rules to prevent degradation of system performance.

Retry Priority: Increase — When a failed rule is retried, its priority can be changed in relation to other rules currently being processed. Set to **Increase** to promote timely processing.

— Save Retry setting changes

Always click **Update...** buttons after making changes

You must start or restart the Thomson Rules Wizard service on the NewsBrowse server to put changes into effect, but if you are doing the initial configuration of the Advanced encoder + Server stage, don't start the service until instructed to do so in the Advanced encoder + Server stage test.

<sup>a</sup>. When the Rule specifies “\*” as the Proxy Storage Location the Default File System Folder is used, as configured in “Configure Proxy Asset (NAS): Advanced encoder” on page 75

This page defines the rules for an Advanced Encoder creating proxy. The following sections explain rules.

## About configuring rules

The Rules Automation Settings page dynamically offers the appropriate options based on the currently selected source, as follows:

### Rules when the source is high-res material

These rules create MPEG, thumbnails, storyboards, and Real Media proxy from high-res material. This is also known as a “scavenge” operation and is similar to Sequential encoder functionality. Depending on the desired behavior of the system you may have to create multiple rules for the MPEG creation. There are two types of rules, as follows:

- **Create while Recording** — This rule causes MPEG to be created while the system is still encoding the high-res material.
- **Recreate Proxy if Content is Modified** — This rule will cause the system to delete the proxy associated with high-res material if the material has its content modified. It will then recreate the MPEG proxy for the material. Note: This rule is normally not configured for Open SAN systems. It should be configured for NewsShare NAS systems.

The following takes place by default with both these types of rules:

- When the Rules Wizard starts up, it traverses a high-res device MDI to see if there is any material that does not have MPEG proxy associated with it, according to the currently configured rules. The Rules Wizard will only check the system once after startup to see if it needs to create any of this proxy.

### Rules when the source is MPEG proxy

These rules create thumbnails, storyboards, and Real Media video from MPEG proxy. This is similar to Image Support Server (ISS) functionality. Most systems only create thumbnail and storyboard material.

## Tips for configuring rules

- Configure one rule per folder or “location”. Multiple overlapping rules that access the same folder can produce looping behaviors and other unexpected results.
- If using SmartBin Encoders or Single-channel Encoders for ingest, don’t use Advanced Encoder rules for ingest.

## Configure Asset Manager

Do not modify  
Advanced  
Basic

http://root-nb-svr:280 → MediaFrame Core → Asset Manager

Asset Manager Settings

Purge Expired Assets Period: 30

Asset Policy:  Delete asset if asset only contains proxy material.

Update

The time period in minutes Asset Manager service waits before it runs again.

When you select this option, if proxy media is found for which there is no counterpart high-res material, Asset Manager deletes all associated proxy.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

Restart the Thomson Asset Manager service on the NewsBrowse server.

When the Asset Manager service runs it looks for expired assets and orphaned assets that should be purged from the system. It also maintains the assets currently in the Resolver and if necessary initiates the creation of proxy to keep assets in synch. This page configures the frequency and rules by which the Asset Manager carries out its processes.

### About expired assets

When NewsBrowse assets are created, they can be assigned a “MetadataExpire” date. This is the value that you enter on the Rules Automation Setting configuration page or on the SmartBin Encoder Control configuration page. The “MetadataExpire” date is set to the current date plus the number of “Days to Expire Asset”. If you do not set a “Days to Expire Asset” value, the asset will never be purged automatically.

The NewsBrowse Asset Manager executes a periodic purge task that runs at the frequency (in minutes) that you configure on the Asset Manager Settings configuration page, starting from the last time the Asset Manager service is started. This task takes the current time of day date/time stamp and compares it to the “MetadataExpire” date, and if the date portion of the current timestamp is  $\leq$  the “MetadataExpire” date, the Asset Manager will attempt to delete the asset. Thus, the actual purge period can occur up to a day earlier than expected.

Recommendation:

Set the “Days to Expire Asset” to one more than required to ensure that assets are not deleted sooner than required.

For example, if you want assets to reside in the system approximately (but not less than) one day, the “Days to Expire Asset” value should be set to 2. This will result in actual asset lifetimes between 24 and 72 hours in the system. If you require the maximum period to be closer to 48 hours than 72, decreasing the Purge Period from 1440 (24 hours) to a smaller value should be effective.

### Test: Advanced encoder + Server stage - high-res source

The following test exercises system functionality exclusive to the rules for creating MPEG proxy, storyboard, and thumbnail assets from Profile high-res material. A successful test verifies that the basic configurations for the rules are correct.

Test description: Trigger rules by creating/modifying a clip on a Profile Media server while the Rules Wizard service is off, then on.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. Make sure the Thomson Rules Wizard service is off on the NewsBrowse server.
3. Start the Thomson Resolver service and the Thomson Metadata service on the NewsBrowse server.
4. Click **Start | Programs | Thomson | Event Viewer** to open Event Viewer.
5. On a Profile Media Server, copy a clip into a bin monitored by the Advanced encoder.
6. On the NewsBrowse server, start the Thomson Rules Wizard. Watch Event Viewer and verify that the MPEG, storyboard, and thumbnail proxy are created for the clip.
7. On the Profile Media Server, copy another clip into the bin. Watch Event Viewer and verify that the MPEG, storyboard, and thumbnail proxy are created for the clip.
8. In you have a "...if content is modified" rule configured for high-res clips, on the Profile Media Server, modify a clip (rename) in the bin. Watch Event Viewer and verify that the MPEG, storyboard, and thumbnail proxy are created for the modified clip.
9. If you have a "Create while recording" rule configured for high-res clips, on the Profile Media Server, record a clip into a bin monitored by the Advanced Encoder. Watch Event Viewer and verify that the MPEG, storyboard, and thumbnail proxy are created (in real-time) as the clip is recorded.

### **Test: Advanced encoder + Server stage - MPEG proxy source**

The following test exercises system functionality exclusive to the rules for creating storyboard and thumbnail proxy from MPEG proxy. A successful test verifies that the basic configurations are correct. This test assumes that you are using single-channel encoders for creating the MPEG proxy at ingest.

Test description: Trigger rules by creating a clip on a Profile Media server while the Rules Wizard service is off, then on.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.

***NOTE: Running these tests will tie up a channel and could collide with commands from the Ingest Schedule page. Inform operators that they must not use the channels under test.***

2. Stop the Thomson Rules Wizard service on the NewsBrowse server.
3. Start the Thomson Resolver service and the Thomson Metadata service on the NewsBrowse server.
4. From the NewsBrowse server, open the NewsBrowse application.
5. Ingest a short test clip. On the related tab, verify that only the MPEG proxy is created.
6. Start the Thomson Rules Wizard service on the NewsBrowse server. In the

NewsBrowse application on the related tab, verify that the thumbnail and storyboard proxy are created for the MPEG proxy, as per your currently configured rules. This could take a few minutes, depending on clip length.

7. Ingest a short test clip. On the related tab, verify that the MPEG proxy is created and the other proxy are created as well. This could take a few minutes, depending on clip length.
8. Stop the Thomson Rules Wizard service, Thomson Resolver service, and the Thomson Metadata service on the NewsBrowse server.

### **Checklist: Advanced encoder + Server stage**

Use the following check list to verify that the basic configuration and testing of the single-channel encoder plus NewsBrowse server is complete.

- When the Rules Wizard starts up, rules work as configured for the creation of MPEG, thumbnail, and storyboard proxy.
- When a clip is ingested, rules work as configured for the creation of MPEG, thumbnail, and storyboard proxy.
- When a Profile clip is copied into a monitored bin, rules work as configured for creation of MPEG, thumbnail, and storyboard proxy.
- When a Profile clip is modified, rules work as configured for creation of MPEG, thumbnail, and storyboard proxy.

## **EDL Export, Save, Conform stage**

For this configuration stage you configure the settings for the following Edit Decision List (EDL) features. These features are available in the NewsBrowse application when EDLs are created:

- **Export** — Exports an EDL to a pre-defined location.
- **Save** — Saves the EDL as a NewsBrowse system asset for future use.
- **Conform** — Creates a high-res asset that matches the EDL on a Profile XP or M-Series iVDR.
- **Conform to Air** — Creates a high-res asset that matches the EDL on one Profile XP, then transfers the asset to another Profile XP. This functionality is available for M-Series iVDRs as well.

Conform server requirements are as follows:

- V:\ should be mapped to the share1 on the NewsShare NAS.
- Host table should have an entry for the M-Series High Speed Ethernet connection, as in the following example:

```
192.168.18.8      kush-ivdr-1 kush-ivdr-1_he0
```

- If conforming to a Profile the host table should have an entry to the High Speed Ethernet connection on the UIM, as in the following example:

```
192.168.18.61   elm-xp-uim-1 elm-xp-1-uim_he0
```

To do the basic configuration and testing of the EDL stage, do the following:

1. [“Configure NTFS MDI” on page 88](#)
2. [“Configure Media Frame Core ASK: NTFS” on page 88](#)
3. [“Configure Conform Services” on page 89](#)
4. [“Configure Export Services” on page 90](#)
5. [“Configure Save EDL settings” on page 91](#)
6. [“Test: EDL stage” on page 92](#)
7. [“Checklist: EDL stage” on page 92](#)

## Configure NTFS MDI

Do not modify  
Advanced  
Basic

http://root-nb-svr:280 → Managed Devices → NTFS MDI

NTFS MDI Product Configuration Settings

MDI Name: NTFS1 — Name of NTFS MDI, as registered with ASK. Refer to “Configure Media Frame ASK: Register components” on page 58.

Port: 9115 — Port 9115 required. See “Ports and services mapping” on page 40.

Update — Saves changes. Changes are lost if you leave the configuration page without updating.

File System Folder Location: \\iron-nb-svr1\TempEDL — Machine (and folder) managed by the NTFS MDI. This must be a UNC path. The machine must have NTFS storage. You can optionally specify the folder.  
Example1: \\HostName  
Example2: \\HostName\Folder

Add Location — Adds the machine/folder as managed by the NTFS MDI.

Existing File System Folder Locations: \\iron-nb-nas1\EDLs  
\\iron-nb-nas1\Audio  
\\iron-nb-nas-2\Audio — Lists currently added machines/folders accessible by the NTFS MDI.

Remove Location — Removes the currently selected machine/folder from the list.

RegisteredType Mappings: xml-edl/xml — Defines the types of files accessible by the NTFS MDI. Follow the example syntax.  
Example1: bt-text/file  
Example2: wav-audio/wav

Add RegisteredType — Adds the file-type as accessible the NTFS MDI.

Existing RegisteredTypes: bt-text/file  
wav-audio/wav — Lists currently added file-types accessible by the NTFS MDI.

Remove RegisteredType — Removes the currently selected file-type from the list.

Always click **Update...** buttons after making changes  
Restart the Thomson NTFS MDI Service on the NewsBrowse server.

This page specifies the machines, directories, and file types that the NTFS MDI can access. The NewsBrowse application makes these available as selections for saving and managing assets, including EDLs.

- Enter a location for saving EDLs. Typically this would be on a NAS machine, such as \\root-nas-n\EDLs.
- Enter a location for temporarily saving EDLs as they are being conformed. Typically this would be on the NewsBrowse server, such as \\root-nb-svr\TempEDL.

**NOTE:** Configure different locations for EDL operations. Do not use the same locations for saving, temporary saving, conforming, and exporting EDLs.

- Enter a location for saving audio files. Typically this would be on a NAS machine, such as \\root-nas-n\Audio.
- Enter *xml-edl/xml* and *wav-audio/wav* as a file-types.

## Configure Media Frame Core ASK: NTFS

Make sure the NTFS MDI is registered with the ASK software component with a logical name, as explained in “Configure Media Frame ASK: Register components” on page 58.



## Configure Conform Services

Do not modify  
Advanced  
Basic

http://root-nb-svr:280 → NewsBrowse Application → Conform Services

When an EDL is conformed it is temporarily stored in the location specified by the following settings.

- Select the name for the NTFS MDI (NTFS1).
- Enter a full UNC path to the directory (on a machine with NTFS storage) in which the EDLs are temporarily stored.<sup>a</sup>
- Saves changes. Changes are lost if you leave the configuration page without updating.

The following settings specify a media server used to conform an EDL.

- Enter the label for display in the NewsBrowse application that identifies the service conforming an EDL.
- Select the MDI for the machine that does the conformance.
- The machine managed by this MDI is a play-to-air Profile or M-Series to which Conform-to-Air high-res assets are transferred.
- Location (bin) on the play-to-air machine where the Conform-to-Air high-res asset is stored.<sup>b</sup>
- Select to make the EDL available to NewsQPro.
- Add the service to conform EDLs.

Currently added services available to conform EDLs. You can add services using several machines, so that they can be selected in the NewsBrowse application when conforming an EDL.

- Removes the currently selected EDL service.

Always click **Update...** buttons after making changes

Restart the NewsBrowse application to put changes into effect.

<sup>a</sup>. This directory must be shared so it can be accessed by the NewsBrowse server.

<sup>b</sup>. This list is automatically populated by reading the volume and bin names from the Profile or M-Series indicated by "Target MDI Name" above.

This page tells the NewsBrowse application where to store EDLs that are to be conformed and specifies machines that are available to conform EDLs. You can add multiple machines as Conform Services, each of which is then available for selection from the NewsBrowse application.

**NOTE: Configure different locations for EDL operations. Do not use the same locations for saving, temporary saving, conforming, and exporting EDLs.**

For a Conform-To-Air service, one machine does the work of conforming the EDL, then the resultant high-res asset is transferred to an On-Air Profile (usually a stand-alone Profile) or M-Series iVDR for playout. You must define the NewsBrowse application display name, the media servers, and the locations to make this type of Conform-to-Air service available in the NewsBrowse application.

## Configure Export Services

http://root-nb-svr:280 → NewsBrowse Application → Export Services

Do not modify  
Advanced  
Basic ✓

Enter the label for display in the NewsBrowse application that identifies the location to which EDLs can be exported.

Select if EDLs are to be accessed by NewsEdit.

Select the News MDI.

Select<sup>a</sup> the directory to which the EDLs are exported.<sup>b</sup> This should be a working folder, not an “Inbox” or “Outbox” folder. Refer to “[Design considerations - NewsBrowse with NewsEdit](#)” on page 11.

Adds the location as an export location.

Currently added location available for exporting EDLs. You can add several locations, so that they can be selected in the NewsBrowse application when exporting an EDL.

Removes the currently selected location.

Always click **Update...** buttons after making changes

Restart the NewsBrowse application to put changes into effect.

<sup>a</sup>. If the Export Location button does not open a Browse dialog box, enable the Internet Explorer setting “Initialize and Script ActiveX Controls...”. Refer to “[Accessing system configuration pages](#)” on page 54 for procedures.

<sup>b</sup>. This directory must be shared so it can be accessed by the NewsBrowse server.

This page tells the NewsBrowse application the locations available for exporting EDLs. You can add multiple locations, each of which is then available for selection from the NewsBrowse application. Name locations and add them according to workflow needs.

**NOTE: Configure different locations for EDL operations. Do not use the same locations for saving, temporary saving, conforming, and exporting EDLs.**

## Configure Save EDL settings

Do not modify

Advanced

Basic ✓

http://root-nb-svr:280 → NewsBrowse Application → Save EDL

**Save EDL Settings**

EDL Storage Location:  — EDLs are saved to this location, usually a NAS machine.

Default Days to Expire Asset:  — After this many days, a saved EDL is deleted. Enter 0 to never delete.

— Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

Restart the NewsBrowse application to put changes into effect.

This page tells the NewsBrowse application where to save EDLs and how long to keep them in the system.

**NOTE:** *Configure different locations for EDL operations. Do not use the same locations for saving, temporary saving, conforming, and exporting EDLs.*

## **Test: EDL stage**

The following test exercises system functionality exclusive to the EDL configurations. A successful test verifies that the basic configurations are correct.

Test description: Using the NewsBrowse application, create an EDL, then export, save, and conform it.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. Load a clip in the NewsBrowse application.
3. Mark in/out region of the clip and press the Insert to Timeline button to add to the timeline. Do this a couple of times with this and other assets.
4. Select Save from the timeline control. Enter and take note of the name used for saving. The save should be successful.
5. Refresh the results list by clicking the Go button with no criteria selected. The EDL asset name should appear in the results list.
6. Select the Export button from the timeline control. Select a destination and choose export.
7. Select Conform from the timeline control. Enter and take note of the name used for conforming. Select a target (not a Conform to Air target) and choose Conform.
8. Select Conform again from the timeline control. Enter and take note of the name used for conforming. Select a Conform to Air target and choose Conform.
9. To verify export, go to the NewsEdit system and check for the exported sequence in the expected location.

## **Checklist: EDL stage**


Use the following check list to verify that the basic configuration and testing of the EDL functionality is complete.

- EDL is created and saved.
- Saved EDL available as asset from NewsBrowse application
- EDL exports to specified location

## Archive stage

For this configuration stage you configure your archive MDI, NewsShare NAS, and the NewsBrowse server to work together. This assumes that the archive devices are already installed and connected.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



To support archive functionality on a NewsBrowse on NewsShare NAS system, you must install a unique NewsFTP on a platform somewhere in the system.

To configure and test the Archive stage, do the following:

1. [“Add archive MDI” on page 94](#)
2. [“Verify archive preparations” on page 95](#)
3. [“Configure ASK Location: Archive MDI host” on page 98](#)
4. [“Configure Media Frame Core ASK: Archive” on page 98](#)
5. [“Configure Avalon Archive MDI” on page 99](#)
6. [“Configure FlashNet MDI” on page 100](#)
7. [“Configure DIVA MDI” on page 101](#)
8. [“Configure Archive Services.” on page 102](#)
9. [“Test: Archive stage” on page 102](#)
10. [“Checklist: Archive stage” on page 103](#)


## Add archive MDI

The archive MDI software component runs as a service. The archive MDIs that are available for the different types of archive devices are as follows:

- Avalon Archive MDI — runs as the Thomson Avalon Archive MDI service
- FlashNet MDI — runs as the Thomson FlashNet MDI service
- DIVA MDI — runs as the Thomson DIVA MDI service

The archive MDI software component must be installed on a network connected computer. Similar to the other MDIs in the NewsBrowse system, the archive MDI can be installed on a MDI server or on the NewsBrowse server, depending on the size and design of your NewsBrowse system.

You can install the archive MDI software component from the NewsBrowse server installation program. Select the component for your archive from the Custom setup page.



## Verify archive preparations

If archiving via Fibre Channel from a Profile XP or Open SAN system, be aware that a single Profile XP system provides a maximum of four streams for concurrent transfers. Keep this mind when configuring the archive device for concurrent transfers. If the archive is configured such that it can request more than four streams simultaneously from any single Profile XP system, the additional transfers will error out.

For the type of archive device you use, check the following to verify proper operation with the NewsBrowse system.

## Avalon archive preparations

Check the following on the machine which runs Avalon IDM Software (Archive):

1. Login to the machine and go to /avalon/aam/utlils
2. Run stataam and verify all services running properly.
3. Make sure host tables are set correctly. Verify for the machine name/IP which IDM will talk to.
4. If archiving from a Profile XP or Open SAN system, make sure the Fiber channel interfaces are configured so that Avalon IDM can talk to the Profiles.

Consider the following when preparing to integrate Avalon archive with NewsBrowse:

- Avalon archive has no fixed limit for concurrent transfers.

## FlashNet preparations

Check the following on the machine which runs the FlashNet software:

1. Login to the machine.
2. If archiving from a Profile XP or Open SAN system, verify that you can telnet to the Profile XP Ethernet IP address on port 8192 (`telnet keystone2_1e0 8192`).
3. Verify that you can FTP from the FlashNet server to the high-res storage machine:
  - If archiving from a Profile XP or Open SAN, verify that you can FTP from the FlashNet server to the Profile on the Fibre Channel address and login as user *movie*.
  - If archiving from a NewsShare NAS, verify that you can FTP from the FlashNet server to the NewsShare NAS on Gigabit Ethernet and login as user *vmfmovie*.
4. Make sure the “FlashNet Socket Listener” and “FlashNet Automation” services are up and running.
5. Use the FlashNet “Jukebox” application to test that a drive can be successfully accessed from FlashNet. Refer to “*User Guide for FlashNet running on Windows NT and Windows 2000 platforms*”.

Consider the following when preparing to integrate FlashNet with NewsBrowse:

- The FlashNet MDI does not take any user specified name for a full restore. The

clips are restored using the original clip name (from archive). The FlashNet MDI does, however, allow a user specified name for a partial restore.

- If archiving from a Profile XP or Open SAN system, take the concurrent transfer limit into consideration. FlashNet's setting for concurrent transfers applies globally to all source/destination pairs. There is no setting on a server-by-server basis. To make the setting for "maximum number of concurrent transfers", you use a file named *C:\.dtool\_env* where you can specify "API\_MAX\_BACKUPS" and "API\_MAX\_RESTORES". The following is an example for an eight drive system:

```
API_MAX_BACKUPS      2
API_MAX_RESTORES     4
```

This example specifies that two concurrent jobs could be used for automation ingest into the archive, four concurrent jobs could be allowed for automation restore of archives, leaving two drives spare for emergency use or another function.

- The FlashNet MDI uses a file cache to support asset functionality. As the FlashNet device does not have any support for file system updates, the FlashNet MDI assumes that the MDI is the only gateway to the entire FlashNet file system. Any changes made outside the scope of the MDI will not be reflected in MDI immediately.
- Renaming of an asset is not supported in FlashNet.
- The FlashNet server installation must have the GENERATE UNIQUE NAME entry set to FALSE. Use *Configurator.exe* for FlashNet server configuration.
- A restore operation always defaults to highest "Time Critical" priority and archive operation defaults to "normal" priority.

### **DIVA preparations**

Check the following on the machine which runs DIVA software:

1. Login to the machine.
2. Verify that you can FTP from the DIVA server to the machine with the high-res online material:
  - If archiving from a Profile XP or Open SAN, verify that you can FTP from the DIVA server to the Profile on the Ethernet IP address and login as user *movie*.
  - If archiving from a NewsShare NAS, verify that you can FTP from the DIVA server to the NewsShare NAS on Gigabit Ethernet and login as user *vmfmovie*.

Consider the following when preparing to integrate DIVA with NewsBrowse:

- The DIVA MDI does not take any user specified name for a full restore. The clips are restored using the original name (from archive). The DIVA MDI does, however, allow a user specified name for a partial restore.
- DIVA has no fixed limit for concurrent transfers.
- If archiving from a Profile XP or Open SAN system, take the concurrent transfer limit into consideration. DIVA's setting for concurrent transfers applies to specific source/destination pairs. With the configuration utility/tool you can specify the concurrency limit on a server-by-server basis.
- The DIVA MDI makes an the assumption that the MDI is the only gateway to the



entire DIVA file system. Any changes made outside the scope of the MDI will not be reflected in MDI immediately.

- Renaming of an asset is not supported in DIVA.
- A restore operation always defaults to highest “Time Critical” priority and an archive operation defaults to “normal” priority.
- The source name specified in the DIVA configuration utility must be the same as the host table name of the machine with high-res online material.
- If the DIVA server is rebooted, the Thomson DIVA MDI service must be restarted. Refer to [“Accessing services” on page 54](#).

### **Network connectivity - all archive types**

To test network connectivity, ping all machines from all machines.

If archiving to/from a NewsShare NAS, ping these machines on the GigaBit network:

- NewsBrowse server
- Archive MDI host
- News MDI host
- The machine hosting the News FTP service
- Archive machine
- The NewsShare NAS system

If archiving to/from Profile XP/Open SAN systems, ping these machines on the GigaBit network:

- NewsBrowse server
- Archive MDI host
- Profile MDI host (MDI server)
- Archive machine
- All Profile XP or Open SAN systems from/to which media is archived/restored

If archiving to/from Profile XP/Open SAN systems, also use Fibre Channel IP addresses and ping these machines:

- Archive server
- All Profile systems from/to which media is archived/restored

## Configure ASK Location: Archive MDI host

**http://localhost:280 → ASK Location** Open this page locally on the machine that hosts the Archive MDI.

Do not modify

Advanced

Basic ✓

ASK Location

ASK

Host:  — Enter the name of the NewsBrowse server

Port:  — Port 9010 is required. See [“Ports and services mapping” on page 40.](#)

— Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

It is not necessary to restart a service to put these settings into effect.

This page tells the Archive MDI host where to look for the ASK service, which runs on the NewsBrowse server. If the Archive MDI host is a MDI server or other NewsBrowse machine this configuration has likely already been done.

## Configure Media Frame Core ASK: Archive

Make sure the Archive MDI is registered with the ASK software component, as explained in [“Configure Media Frame ASK: Register components” on page 58.](#)

## Configure Avalon Archive MDI

**http://localhost:280 → Managed Devices → Avalon MDI** Open this page locally from the Avalon Archive MDI host.

Do not modify Advanced Basic	Host Name: muskrat-idm <small>[Host name must have -idm appended to it (eg. 'archive-idm', where 'archive' is the name of the Server). Note: this must be a Host and not an IP Address.]</small>	Name of the Avalon Archive machine. Append <i>-idm</i> to the end of the name. This name (with <i>-idm</i> appended) must also be in the host table.
	Port: 9120	Enter <b>9120</b> . See “Ports and services mapping” on page 40.
	Padding (in Seconds): 2	Adds media to the clip to ensure correct long GOP structure. Leave at 2.
	Number of Instances: 1	The number of archive devices controlled by the MDI.
	Partial Restore: <input type="checkbox"/>	Select if using partial restore feature.
	Update	Saves changes. Changes are lost if you leave the configuration page without updating.
	Load Balancing: <input type="radio"/> Provided by Managed Device <input checked="" type="radio"/> Round-robin	The following settings define FTP for archive sources/destinations. Select <b>Provided by Managed Device</b> . Requires netsem configuration on Avalon. The remainder of this page is disabled. <sup>a</sup> -OR- Select <b>Round-robin</b> . Requires configuration in the following fields <sup>b</sup> :
	MDI Name: NEWS1	Select the News MDI name.
	FTP Server Host Name(s)/IP Address(es): news-ftp-1, news-ftp-2, news-ftp-3 <small>[If more than one FTP Server, enter Host Names separated by commas (eg., FTPServer1, FTPServer2, FTPServer3, ...)]</small>	Enter the hostname of the machine hosting the News FTP service. If multiple hostnames, enter with commas separating. <sup>c</sup>
	Add Configured FTP Servers: NEWS1 (news-ftp-1, news-ftp-2, news-ftp-3)	Adds a FTP server as a source/destination for archive operations. Currently added FTP servers.
Remove	Deletes the currently selected device.	

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Avalon Managed Device service.

<sup>a</sup> With Avalon configuration, you define FTP Servers and load balance when you configure netsem, so it is not necessary to enter any information on this page.

<sup>b</sup> If you do not use Avalon configuration, you must define FTP servers and load balance on this page.

<sup>c</sup> This defines the load balancing. The order of servers entered here is the order in which the MDI seeks an open channel for an archive job.

Open this page locally on the machine that hosts the Avalon Archive MDI software component. In this example settings are shown for archiving to/from a NewsShare NAS. This page tells the Avalon Archive MDI where to look for FTP transfer of high-res material.

Typically load balancing is configured using Round Robin on this page. If load balancing is provided by the managed device, when configuring netsem, make sure the netsem FTP server logical name matches the same FTP server MDI name.

## Configure FlashNet MDI

**http://localhost:280 → Managed Devices → FlashNet MDI** Open this page locally from the FlashNet MDI host.

**Flashnet MDI Settings**

**MDI Configuration**

MDI Name: Archive 1 — The name of the FlashNet MDI.

Port: 9124 — Enter **9124**. See “Ports and services mapping” on page 40.

**MDI Settings**

Flashnet Server Host Name or IP: nb-flashnet-1 — Name or IP address of the FlashNet machine.

Update — Saves changes. Changes are lost if you leave the configuration page without updating.

The following settings define FTP for archive sources/destinations.

**FTP Server Settings**

Load Balancing:  Provided by Managed Device  Round-robin — Load balancing settings are disabled as only Round Robin is supported.

MDI Name: NEWS1 — Select the MDI name for the News MDI.

FTP Server Host Name(s)/IP Address(es): news-ftp-1 — Enter the hostname of the machine hosting the News FTP service.

[If more than one FTP Server, enter Host Names separated by commas (eg., FTPServer1, FTPServer2, FTPServer3, ...)]

Add — Adds a FTP server as a source/destination for archive operations.

**Remove FTP Server Settings**

Configured FTP Servers: NEWS1 (news-ftp-1) — Currently added FTP servers.

Remove — Deletes the currently selected device.

Always click **Update...** buttons after making changes

Open this page locally on the machine that hosts the FlashNet MDI software component.

This page tells the FlashNet MDI where to look for FTP transfer of high-res material. In this example settings are shown for archiving to/from a NewsShare NAS. For NewsShare NAS systems, archive transfers are handled by a single FTP server.

## Configure DIVA MDI

Do not modify  
Advanced  
Basic

<http://localhost:280> → Managed Devices → DIVA MDI

Open this page locally from the DIVA MDI host.

**DIVA MDI Settings**

**MDI Configuration**

MDI Name: Archive 1 — Name of the DIVA MDI.

Port: 9122 — Enter **9122**. See “Ports and services mapping” on page 40.

**MDI Settings**

DIVA Host Name or IP: nb-diva-1 — Name of IP address of the DIVArchive machine.

DIVA Manager Port: 9000 — The port at which DIVA Manager listens for any active connection. By default this port is set to 9000.

Disk Array Names: Online-storage  
[Enter comma separated disk array names that is configured with DIVA e.g., Array1,Array2]

Timeout: 180  
(Number of seconds the MDI will try to connect before timing out) — Specify the name of the disk arrays that are currently configured with the DIVA system.<sup>a</sup>  
— The timeout value that controls any communication with the DIVA manager. Default value is set to 180 seconds.

Update — Saves changes. Changes are lost if you leave the configuration page without updating.

**FTP Server Settings**

The following settings define FTP for archive sources/destinations.

Load Balancing:  Provided by Managed Device  
 Round-robin — Load balancing settings are disabled as only Round Robin is supported.

MDI Name: NEWS1 — Select the News MDI name.

FTP Server Host Name(s)/IP Address(es): news-ftp-1 — Enter the hostname of the machine hosting the News FTP service.  
[If more than one FTP Server, enter Host Names separated by commas (eg., FTPServer1, FTPServer2, FTPServer3, ...)]

Add — Adds a FTP server as a source/destination for archive operations.

**Remove FTP Server Settings**

Configured FTP Servers: NEWS1 (news-ftp-1) — Currently added FTP servers.

Remove — Deletes the currently selected device.

Always click **Update...** buttons after making changes

<sup>a</sup> An array designates a collection of disks designated by their name as they are declared in the DIVArchive configuration.

Open this page locally on the machine that hosts the DIVA MDI software component.

This page tells the DIVA MDI where to look for FTP transfer of high-res media assets. In this example settings are shown for archiving to/from a NewsShare NAS. For NewsShare NAS systems, archive transfers are handled by a single FTP server.

## Configure Archive Services.

Do not modify  
Advanced  
Basic

http://root-nb-svr-n:280 → NewsBrowse Application → Archive Services

Annotations:

- Enter name for restore location, for display in the NewsBrowse application.
- Select the MDI for the high-res system that gets the restored clips.
- Select a location on the high-res system that gets the restored clips.<sup>a</sup>
- Select if restoring to mirrored high-res systems. This opens the following fields for mirrored restore operations.
- Select the MDI for the mirrored system that gets the restored clips.
- Select a location on the mirrored system that gets the restored clips.
- Click to add as a restore location.
- Lists currently added restore locations.
- Click to remove the currently selected restore location.

Restart the NewsBrowse application to put changes into effect.

<sup>a</sup> Profile location lists are automatically populated by reading bins and volumes, as in Media Manager, from the Profile whose MDI is selected from the field above.

This page tells the Archive MDI where to place high-res assets as they are restored from the archive device.

When you select “Enable Mirrored Destination...”, you can then enter the MDI and location for the mirrored high-res system. This allows you to define the pair of mirrored systems as a single restore location. When this single location is selected in the NewsBrowse application, clips are restored or deleted on both high-res systems simultaneously.

### Test: Archive stage

The following test exercises archive functionality. A successful test verifies that the archive configurations are correct.

Test description: Using the NewsBrowse application, archive and restore high-res media.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.
2. From the NewsBrowse server, open the NewsBrowse application.
3. From the **Find** tab, load an asset. After a short pause, the asset appears in the application interface.
4. On the **related** tab, verify that **online media** is listed as a Related Asset Component.
5. On the **mgmt** tab, verify the presence of the following links:
  - Modify Group Membership
  - Archive Selected Asset

The following links might also be present if the asset has already been archived:

- Restore Selected Asset
- Delete from Archive

Archive and Restore links are not present if the NewsBrowse user currently logged on is not assigned Archive and Restore roles. See [“Configure NewsBrowse Users” on page 110](#).

6. On the **mgmt** tab, click **Archive Selected Asset**. The Archive Selected Asset settings are displayed on the tab.
7. Select an **Archive Group**. This list comes from the archive device. This is the location to which the high-res clip is archived.
8. Select **delete online media following archive**.
9. Click **Submit**, then **Yes** to confirm and **Close**.
10. On the NewsBrowse launch page, click **Archive Status** to track the progress of the transfer. Once the transfer is complete the status reports as DONE and 100%.
11. On the NewsBrowse application **Find** tab, click **Go**. The asset list reloads. Verify that an amber dot is listed with the asset. Select the asset to reload it, then click the **related** tab and verify that **offline media** is now listed.
12. On the **mgmt** tab, click **Restore Selected Asset**. The Restore Selected Asset settings are displayed on the tab.
13. Select from the **Restore to Location** list. This is the location to which the archived clip is transferred.
14. Click **Submit**, then **Yes** to confirm and **Close**.
15. On the NewsBrowse launch page, click **Archive Status** to track the progress of the transfer. Once the transfer is complete the status reports as DONE and 100%.
16. On the NewsBrowse application **Find** tab, click **Go**. The asset list reloads. Verify that the amber dot is no longer listed with the asset. Select the asset to reload it, then click the **related** tab and verify that both **online media** and **offline media** are now listed.

## Checklist: Archive stage

Use the following check list to verify that the configuration and testing of the archive stage is complete.

- High-res material transfers (archives) to archive device.
- High-res material transfers (restores) from archive device to restore location.

## Deploy remaining machines for full system

For the basic configuration path, after you have worked through all the configuration stages and verified functionality at each stage, you deploy your remaining NewsBrowse machines.

Do the following tasks to deploy your remaining NewsBrowse machines, as appropriate for the machines included in your particular NewsBrowse system. For instructions, refer to the applicable configuration stages early in this chapter.

- Deploy remaining Advanced encoders. Refer to “Advanced encoder stand-alone stage” on page 71 and “Advanced encoder + Server stage” on page 81.
- Deploy remaining SmartBin encoders. Refer to “SmartBin encoder stage” on page 67.

## Add live monitor encoders

If your system uses live monitor encoders, add them to the system as follows:

1. If you have not already done so, cable and configure for network access similar to the NewsBrowse server.
2. Connect the audio/video feed for an ingest channel.
3. Add live monitor encoders on the Ingest Scheduler Live Feeds configuration page.

The screenshot shows the 'Live Feeds Settings' page in a web browser. The URL is `http://root-nb-svr:280 -> Ingest Scheduler -> Live Feeds`. On the left side, there is a vertical navigation menu with categories: 'Do not modify', 'Advanced', and 'Basic'. The 'Basic' category is expanded, showing a list of configuration items with checkmarks. The main content area is titled 'Live Feeds Settings' and contains the following elements:

- Add Live Feed** section:
  - Associate to Ingest Encoder Name:** `INGEST-CH2`. Annotation: "Select the Encoder (Transfer service) for the single-channel encoder (ingest channel) for which the live monitor encoder provides a video stream."
  - Host Name or IP:** `iron-nb-live-2`. Annotation: "Machine name of the live monitor encoder."
  - Port:** `8080`. Annotation: "Port 8080 required."
  - Add Feed** button. Annotation: "Adds the live monitor encoder as a live feed."
- Existing Live Feeds** section:
  - Text: `INGEST_CH1 mms://iron-nb-live-1:8080`. Annotation: "Currently added live monitor encoders."
  - Remove Feed** button. Annotation: "Removes the selected live monitor encoder."

At the bottom right, a note states: "To put changes into effect, start or restart the Thomson Ingest Scheduler service."

4. On each live monitor encoder, start Windows Media Encoder. There should be a Windows Media Encoder shortcut on the Windows desktop.
5. Open the NewsBrowse application and on the Ingest page verify that the video stream appears.

## Test system level interactions

Run the following tests to verify that all machines are available and will function correctly, especially during times of heavy system activity.



## **Multiple scavenge test**

This test verifies that scavenge operations can simultaneously control all Advanced encoders to optimize performance during times of heavy proxy asset creation.

To test multiple scavenge operations, do the following:

1. On the machine from which high-res media is scavenged, prepare a quantity of test clips, such that you have one more test clip than the number of Advanced encoders in your system. For example, if you have four Advanced encoders, prepare five test clips. You must prepare the test clips without triggering the NewsBrowse system to create any proxy assets. You can do this by recording media with a channel that is not associated with the NewsBrowse system for ingest, or by copying existing clips to a different bin or folder. In any case, the bin or folder in which these test clips are initially placed must not be a bin that is currently monitored by the NewsBrowse system for scavenge operations. Make the test clips at least a minute long.
2. On the NewsBrowse server, open Thomson Event Viewer.
3. Prepare a bin or folder (preferably one that is currently empty) for monitoring by the NewsBrowse system for scavenge operations. On the Advanced encoders, define rules to create MPEG proxy for high-res material that appears in the scavenge folder.
4. On the machine from which high-res media is scavenged, simultaneously copy all the test clips into the prepared bin.
5. In Event Viewer, verify that scavenge activities occur for each channel, and that all advanced encoders are encoding MPEG simultaneously.
6. With the NewsBrowse application, validate MPEG assets.

## **Profile XP ingest test**

This test verifies Profile XP ingest and creation of proxy assets for all channels simultaneously.

1. Make sure that the NewsBrowse system is not otherwise in use.
2. Make sure that all the Profile system channels for which NewsBrowse creates proxy media have an appropriate media feed.
3. On the NewsBrowse server, open Thomson Event Viewer.
4. In the NewsBrowse application, schedule ingest events on each channel to occur all at the same time.
5. Once the events start recording, select the find tab on the left side of the application and press the go button with no criteria specified. Assets with the event names should appear in the results list.
6. Select an asset from the results list to load the details on the right side of the application. Video should be visible.
7. After the recording is complete, reload assets and verify that thumbnails and storyboards are created as well. Depending on how your rules are set up, this can take up to two times the duration of the original media.

## Purge test

1. Select an asset from the results list to load details. Take note of the components associated with this asset. This can be done by looking at the Related tab in the details page. By using the mouse to hover over the entries in the related tab you can derive where the asset components exist in the system.
2. From the general tab on the details page edit the expiration date and select a date in the past.
3. The purge process polls at configured intervals. To expedite testing go to the Windows services panel and restart the Asset Manager process. This will cause the cycle to be reset and assets meeting expiration criteria will be processed immediately.
4. Refresh the search results list by pressing the go button with no criteria specified.
5. Verify that asset components noted earlier no longer exist in the system. You will have to look at the NAS for the specific paths to proxy asset components. The asset on the Profile should also be removed.

## Add NewsBrowse Clients

Do the following tasks to enable PCs to act as a NewsBrowse clients and run the NewsBrowse application.

- [“Connect server and NAS to customer LAN” on page 106](#)
- [“Set up client PCs” on page 107](#)
- [“Configure NewsBrowse Licenses” on page 107](#)
- [“Testing NewsBrowse client operations” on page 114](#)

If you are upgrading from NewsBrowse system version 1.5 to version 2.0 or higher, refer to *NewsBrowse Release Notes* for upgrade instructions regarding NewsBrowse clients.

## Connect server and NAS to customer LAN

The NewsBrowse server and NAS machines must have network access to the external LAN of the NewsBrowse client PCs. Work with the IT personnel at the customer site to configure Domain, DNS suffix, or any other settings required by the site’s LAN.

Also, make sure that permissions are correct for access to the NewsBrowse server website, which serves the NewsBrowse application. The website uses Integrated Windows Authentication.

Continue with the next procedure [“Set up client PCs”](#).

## Set up client PCs

The requirements for a NewsBrowse client PC are as follows:

- Network access to the NewsBrowse server
- Network access to NewsBrowse NAS machines. Refer to [“Prepare NAS - Windows Fastora” on page 47](#) for test procedures.
- DirectX 9.0c or higher. Enable “Download signed ActiveX controls” in Internet Explorer.
- NetTime

It is no longer necessary to install Live Feed Filter or Flash Player. They are now bundled together with the NewsBrowse Clip Player. Live Feed Filter and Flash Player automatically download when the application first runs.

To set up a PC to satisfy these requirements, do the following:

1. From a client PC, open Internet Explorer 6 and click **Tools | Internet Options**. The Internet Options dialog box opens.
2. Click **Security | Local intranet | Custom Level**. The Security Settings dialog box opens.
3. Under “Download signed ActiveX controls”, click **Enable**.
4. Browse to the following URL to open the NewsBrowse launch page:  
**<http://root-nb-srv/nbui>**.
5. From the NewsBrowse Launch page, click **Client Setup**. Follow the Client Setup on-screen instruction for Browser, DirectX, and (if you have not already done so) for NetTime. Also refer to [“Prepare NetTime” on page 44](#). For NewsShare NAS systems, NetTime is not required on NewsBrowse client machines.

After installation be sure to clear the browser cache on client machines to insure updated components are downloaded. To clear the browser cache in Internet Explorer go to **Tools | Internet Options**, from the **General** tab select the **Delete Files** button, check **Delete all offline content**, and click **OK**.

Continue with the next procedure [“Configure NewsBrowse Licenses”](#).


## Configure NewsBrowse Licenses

You must configure the NewsBrowse server as per your NewsBrowse license to allow user access to NewsBrowse application features.

To configure for NewsBrowse licenses, do the following:

1. From the NewsBrowse Launch page, click **License & User Management**. This requires that you log in as NewsBrowse administrator.
  - Login: `root-nb-srv\nbadmin`
  - Password: `*****`

The License Manager page opens.



2. Click **Licenses**. The Licenses page is displayed.

License	Roles	Session Count	
Browse	View	30	<a href="#">Set Session Count</a>
	MediaManager		
	Logger		
	IngestManager		
	IngestView		
	ArchiveTransfer		
	ArchiveRestore		
LiteEdit	Editor	20	<a href="#">Set Session Count</a>
AdvancedEdit	Editor	20	<a href="#">Set Session Count</a>

3. Click **Set Session Count** next to the applicable license. The Set Session Count for ... page is displayed.

**Set Session Count for AdvancedEdit License**

License Name: AdvancedEdit  
 Roles: Editor  
 Current Session Count: 20

New Session Count:

Authorization:

4. Enter the appropriate number of licenses purchased (be sure to include any previously purchased license counts). You must provide the proper password to change this value. Click **Update** to save changes.
5. On the NewsBrowse server, restart ISS services. Click **Start | Run** and run `issrestart`.

Users must be set up to allow access to the NewsBrowse application from a NewsBrowse client PC. To do this, you must continue with the next section [“Administering NewsBrowse user access”](#).

## Administering NewsBrowse user access

The NewsBrowse administrator sets up NewsBrowse users and can restrict their access to NewsBrowse application features and assets, as explained in the following procedures:

- [“Configure NewsBrowse Groups” on page 109](#)
- [“Configure NewsBrowse Users” on page 110](#)
- [“Managing NewsBrowse User sessions” on page 112](#)


### Configure NewsBrowse Groups

The purpose of NewsBrowse groups is to manage a user’s access to assets. The NewsBrowse administrator can create groups and assign the groups individually to users. Using the NewsBrowse application, groups can also be assigned to individual assets. In this way each user’s access is restricted to the assets in their assigned groups.

Configuring NewsBrowse groups is optional. If you do not configure NewsBrowse groups, users and assets are all assigned to the default group, so all users have access to all assets.

To configure NewsBrowse groups, do the following:

1. From the License Manager page, click **Manage Groups**. The Groups page is displayed.



Mask Bit	Name
0	default
1	test
2	Sports
3	Overnight stories
4	Weather
5	Entertainment
6	10pm
7	
8	
9	
10	
11	
12	
13	

Change the values of the fields to reflect the group names used for asset visibility and click update.

WARNING: Changing group names does not change group membership for users or assets. If an existing group's name is removed, the group's membership for users and assets will continue to exist but may not be used.

2. Enter names to define groups according to the workflow with which the system is used.
3. Click **Update** to save changes.

Continue with the next procedure [“Configure NewsBrowse Users”](#).

## Configure NewsBrowse Users

You must add NewsBrowse users before using the NewsBrowse application from any NewsBrowse client PC. The NewsBrowse application only allows access by users that have been added, as explained in the following procedure.

1. From the License Manager page, click **Users**. The Users page is displayed.

User Name	Roles	Groups	
critesb	Browse.View Browse.MediaManager Browse.Logger Browse.IngestManager Browse.IngestView Browse.ArchiveTransfer Browse.ArchiveRestore	0: default	<a href="#">Edit/Remove</a>
frankah	Browse.View Browse.MediaManager Browse.Logger Browse.IngestManager Browse.IngestView Browse.ArchiveTransfer Browse.ArchiveRestore LiteEdit.Editor	0: default	<a href="#">Edit/Remove</a>
hadley	Browse.View Browse.MediaManager Browse.Logger	0: default	<a href="#">Edit/Remove</a>

[Printer friendly view](#)

2. To add new NewsBrowse User, click **Add a User**. To modify an existing NewsBrowse user, click the **Edit/Remove** link for the user. The Update User page is displayed.

Username	Roles	Groups	
[enter name here]	<input type="checkbox"/> Browse.View <input type="checkbox"/> Browse.MediaManager <input type="checkbox"/> Browse.Logger <input type="checkbox"/> Browse.IngestManager <input type="checkbox"/> Browse.IngestView <input type="checkbox"/> Browse.ArchiveTransfer <input type="checkbox"/> Browse.ArchiveRestore <input type="checkbox"/> LiteEdit.Editor <input type="checkbox"/> AdvancedEdit.Editor	<input type="checkbox"/> 0 default <input type="checkbox"/> 1 test	<input type="button" value="Add"/> <input type="button" value="Delete"/> <input type="button" value="Cancel"/>

3. Enter the following:
  - Username — This must match the account with which the NewsBrowse client accesses the NewsBrowse application.
  - Roles — Select the NewsBrowse application functionality to which the user will have access. The Roles listed are dependent upon current licensing. The following table defines the Roles:

Role	Description
Browse.View	Lets you browse for video clips and view them.

Role	Description
Browse.MediaManger	Also lets you change the metadata including clip expiration; you can schedule and execute purge.
Browse.Logger	Also lets you modify custom fields and keywords.
Browse.IngestManager	Lets you schedule recording events.
Browse.IngestView	Lets you view the Ingest schedule in list view and in graphic view.
Archive.SendToArchive	Lets you transfer high-res assets from a Profile system to an archive device and optionally delete the high-res assets from the Profile system.
Restore.RestoreFrom Archive	Lets you restore high-res assets from an archive device to a Profile system.
LiteEdit.Editor	Lets you do cuts-only editing.
AdvancedEdit.Editor	Lets you use the Advanced Edit program, which lets you use the editing features of NewsEdit.


If you assign a Role to more users than the session count for which it is licensed, the Role is not available to all users at times when sessions exceed the count.

- Groups — Select the groups for which the user will be allowed to access media assets.
4. Click **Add** for new users, or **Update** to modify existing users. You can also click **Delete** to remove a user from the NewsBrowse system.
  5. Repeat the previous two steps to add additional users.
  6. Click **Update** to save changes.
  7. On the NewsBrowse server, restart ISS services. Click **Start | Run** and run `issrestart`.

## Managing NewsBrowse User sessions

The NewsBrowse administrator can view the current users with active sessions and force a session to be dropped, as follows:

1. From the License Manager page, click **Active Sessions**. The Active Sessions page is displayed.



2. Click the **drop** link to drop a user's current active session.

## Adding custom fields

The purpose of custom fields is to enhance site-specific management of assets. The NewsBrowse administrator defines a custom field to create an asset metadata-type that uniquely fits the site's workflow. The user of the NewsBrowse application can then assign metadata to an asset by entering text or making a selection in the custom field.

Adding custom fields is optional.

To configure custom fields, do the following:

1. From the NewsBrowse Launch page, click **Asset Management Administration**. This requires that you log in as NewsBrowse administrator.
  - Login: `root-nb-srv\nbadmin`
  - Password: `*****`



The Asset Management Administration page opens.

Field Name	Type	Options	Delete
Last_date_used	date		Delete
Suitability	text	Documentary Investigative Human Interest <a href="#">[edit options]</a>	Delete
Rating	number		Delete

2. For each custom field you add, do the following:
  - a. Enter a field name.
  - b. Select the type of field as follows:
    - Text — A free-entry text field or a drop down list of selections that you define, as explained in the next step in this procedure.
    - Number — A field in which only numbers can be entered.
    - Date — A field that, when clicked, opens a calendar from which a date can be selected.
  - c. Click **Add Field**.
3. If you are adding a text field, you have the following options:
  - To allow text to be freely entered in the field, no further configurations are necessary. Skip to the next step in this procedure.
  - To provide a pre-defined list of selections for the field, click **Edit Options** for the field. The Update Field Options page opens.

Field Option	delete
Documentary	<a href="#">delete</a>
Investigative	<a href="#">delete</a>
Human Interest	<a href="#">delete</a>

For each selection that is to be on the list, enter its text and click **Add**. You can also click **Delete** to remove a selection from the list. When the list is complete,

click **Done**.

4. Click **Add Field** and **Delete** as necessary to complete your custom fields. To view your latest changes, click **Refresh Page**.
5. Open the NewsBrowse application, select an asset, and click **Custom**. Your custom fields are available to assign metadata to the asset.

## Testing NewsBrowse client operations

To perform a quick check that the web and database services are accessible to a client PC, do the following:

1. Log in to a client machine.
2. Open Internet Explorer 6 and browse to the following URL:

**`http://iron-nb-svr/nbui`**.

In this example, **iron-nb-svr** is the host name or IP address of the NewsBrowse server.

3. Click **Launch NewsBrowse Application**. You are now logged into the NewsBrowse application website and should have assets available for browsing.

---

# Recovery Planning

Establish a recovery plan in the event a NewsBrowse machine fails, so that NewsBrowse services can be re-configured rapidly to minimize impact.

## Encoder failure considerations

Encoders provide redundancy through numbers. A plan should identify the critical encoders in the system and alternate encoders that can be reconfigured to substitute in the case of failure. There are no automated fail-over capabilities with NewsBrowse components. It is important to identify which machine(s) host Managed Device Interface services. These services can be pre-installed on secondary devices, although the server should not be configured to monitor them unless a failure of the primary service occurs. Managed Device Interface services can exist on any encoder and the server need only to be reconfigured to point to the new machine in case of failure.

Encoding jobs can be assigned to any available Advanced Encoder. N+1 redundancy is achieved by adding an extra Advanced Encoder.

## Server failure considerations

The SQL database should be backed up on a regular basis and stored in a safe location. In the case of server failure the database can then be restored to minimize data loss. If an off-line backup server is purchased it should be pre-configured to operate in the system so in case of primary server failure, minimal time will be spent bringing up the backup system. The backed up database could be restored to this backup server on a regular basis.

Newer NewsBrowse systems have redundant power supplies and mirrored disks to further protect the integrity of the system.

## Database maintenance and administration

NewsBrowse utilizes the SQL full recovery model and a maintenance plan is essential to keeping the database in working order. Not only does the database need to be backed up but the accompanying transaction log needs to be backed up as well. Failure to back up the transaction log can cause the database to become inoperable due to the transaction log file growing too large.

The transaction log is responsible for keeping track of all the edits to data until it reaches what is known as a checkpoint. Once the checkpoint is reached, the data should be permanently committed to the database. Problems arise when this checkpoint is reached, data is not committed to the database, and the transaction log continues to grow. If the transaction log reaches the capacity of growth it can render the database inoperable. In the event that the database has been rendered inoperable, a manual truncation of the transaction log will need to be performed, as explained in [“Repairing a database that is unusable due to transaction log size”](#) on page 116.

Adopt the following practices to keep the database healthy:

- Daily monitor the growth of the transaction log daily, as explained in [“How to](#)

[determine the size of the transaction log](#)” on page 116.

- When necessary, manually back up the database and the transaction log, then shrink the transaction log file to release disk resources to the operating system, as explained in [“Manually controlling transaction log growth”](#) on page 117.
- Set up a database maintenance plan. This automatically backs up the transaction log and the database. Refer to [“Setting up a database maintenance plan”](#) on page 118.

## Repairing a database that is unusable due to transaction log size

If the database is rendered inoperable due to the transaction log becoming too large, it is highly likely that the transaction log has never been backed up, a database maintenance plan has not been enabled on the system, or the SQL Server agent is not running to implement your maintenance plan. The following steps should resolve the problem:

1. Open SQL Query Analyzer
2. Make sure the database in question is selected in the top tool bar. (For this example the *MediaFrame* database will be used.)
3. First try to backup the transaction log without truncating it by running the following command:

```
BACKUP LOG MediaFrame TO Disk = 'filePath\fileName.trn'
```

Where filePath and fileName is user specified, (e.g. D:\Emergency Backups\MediaFrame\_tran\_12052003.trn) if the file does not already exist, you will need to create it. If the transaction log is full it is likely that this command will fail but it is important to try it to maintain database integrity.

4. Regardless if the previous command passes or fails, execute the following command to clear the transaction log:

```
BACKUP LOG MediaFrame WITH TRUNCATE_ONLY
```

5. To free unused resources to the operating system execute the following command:

```
DBCC SHRINKFILE(MediaFrame_log, 2)
```

## How to determine the size of the transaction log

When SQL is installed the space that it is allotted on the operating system is divided into two parts: 50% is given to store transaction logs and 50% is reserved for data. To identify the amount of space the transaction logs is taking up, open SQL Query Analyzer and execute the following command.

```
DBCC sqlperf(logspace)
```

This command will return the amount of space each database’s transaction log is taking up and the percentage of space the transaction log is using. The column that lists the percent of space the transaction log is taking up is misleading. NewsBrowse databases set the transaction log growth limit to 500MB. If one of the databases transaction logs is larger than 350MB, then follow the steps in the next procedure [“Manually controlling transaction log growth”](#).

## Manually controlling transaction log growth

Use this procedure when the transaction log is approaching its size limit. First back up the database and the transaction log to keep a record of its current state. Then flush and shrink the transaction log file to reduce its size. To do this open SQL Enterprise Manager and manually backup the database and transaction log of the database in question. The steps to do this are as follows:

### Back up the transaction log

The following procedure uses the default location of the transaction log backup, which is as follows:

```
C:\Program Files\Microsoft SQL Server\MSSQL\BACKUP\<database name>\
```

If your transaction log backups are in a different location, substitute the different path.

1. Open **Start | Programs | Microsoft SQL Server | Query Analyzer**.
2. Connect to the SQL Server which is hosting the NBIngest and MediaFrame databases. An empty query automatically opens.
3. To back up the transaction logs, type the following commands. In these examples the number string at the end of the command indicates May 31, 2005 at 12:00. Enter the actual year, month, date, hour, and minute in the indicated YYYYMMDDHHMM format.

- To back up the NBIngest transaction log, type:

```
BACKUP LOG NBIngest
TO DISK='C:\Program Files\Microsoft SQL
Server\MSSQL\BACKUP\NBIngest\_tlog_200505311200'
```

- To back up the MediaFrame transaction log, type:

```
BACKUP LOG MediaFrame
TO DISK='C:\Program Files\Microsoft SQL
Server\MSSQL\BACKUP\MediaFrame\_tlog_200505311200'
```

4. Continue with the next procedure [“Shrink the transaction log”](#).

### Shrink the transaction log

This must be done very soon after backing up the transaction log. This will reduce the transaction log to the size specified; the log will then grow as needed.

Use Query Analyzer, as in the previous procedure.

The command to shrink the NBIngest transaction log file is:

```
DBCC SHRINKFILE(NBIngestLog, 10)
```

The command to shrink the MediaFrame transaction log file is:

```
DBCC SHRINKFILE(MediaFrameLog, 10)
```

## Setting up a database maintenance plan

The best way to control the growth of transaction logs is to simply back them up, once a day at the very least. SQL 2000 makes it very easy to set up a database maintenance schedule. Before you begin implementing a database maintenance plan using the SQL 2000 Database Maintenance Planner wizard make sure that the SQLSERVERAGENT service is started and its properties are set to auto start for a local system account. If the SQLSERVERAGENT is not running, the database maintenance plan will not run. The following steps describe how to launch and configure the SQL 2000 Database Maintenance Planner:

1. Open SQL 2000 Enterprise Manager.
  2. Expand Microsoft SQL Servers, expand the SQL Server Group and select the SQL server.
  3. On the **Tools** menu, click **Database Maintenance Planner...**
  4. After the wizard launches click the **Next>** button.
  5. Select **These databases** radio button and select the **MediaFrame** and **NBIgest** databases.
  6. Click the **Next>** button to navigate to the **Update Data Optimization Information** page.
  7. Select the **Update statistics used by query optimizer. Sample** check box and set it to 10% of the database.
  8. Check the schedule to verify that the time scheduled will not conflict with peak usage of the system. If a schedule time change is needed, click the **Change...** button to modify the time. This option can be run daily but once a week is good.
  9. Click the **Next>** button to navigate to the **Database Integrity Check** page.
  10. Select the **Check database integrity** check box.
  11. Select the **Include indexes** radio button.
  12. Select the **Perform these checks before doing backups** check box.
  13. Check the schedule to verify that the time scheduled will not conflict with peak usage of the system. If a schedule time change is needed, click the **Change...** button to modify the time. This option can be run daily but once a week is good.
  14. Click the **Next>** button to navigate to the **Specify the Database Backup plan** page.
  15. Select **Back up the database as part of the maintenance plan** check box.
- NOTE: Do not select "Attempt to repair any minor problems".**
16. Select **Verify the integrity of the backup when complete** check box.
  17. Select the **Disk** radio button
  18. Change the schedule from once a week to daily by clicking the **Change...** button.
  19. Select the **Daily** radio button and set the interval to **Every 1 day(s)**.
  20. Select the **Occurs once at** radio button. If the default time of 2:00:00 AM is not good, change it to a more suitable time.

21. Make sure that the **Start Date is today's date** and that the **No end date** radio buttons are selected.
22. Click the **OK** button and verify the schedule.
23. Click the **Next>** button to navigate to the **Specify Backup Disk Directory** page.
24. Select the **Use the default backup directory** radio button, except if the site has a specific folder for database backup files. If that is the case, then select the **Use this directory** radio button and enter in the specified path. (Note: SQL can only see local drives and cannot see shared directories or disks that are not native to the machine.)
25. Select the **Create a subdirectory for each database** check box.
26. Select the **Remove files older than** check box and set the value to **1 week(s)**.
27. The backup extension should be set to **BAK**.
28. Click the **Next>** button to navigate to the **Specify Transaction Log Back up Plan** page.
29. Select **Back up the transaction log as part of the maintenance plan** check box.
30. Select **Verify the integrity of the backup when complete** check box.
31. Select the **Disk** radio button.
32. Click the **Change...** button to set the transaction log schedule.
33. Select the **Daily** radio button and set the interval to **Every 1 day(s)**.
34. Select the **Occurs every** radio button and set the interval to every **6 hours**.
35. Make sure that the **Start Date** is today's date and that the **No end date** radio button is selected.
36. Click the **OK** button and verify the schedule.
37. Click the **Next>** button to navigate to the **Specify Transaction Log Backup Disk Directory** page.
38. Select the **Use the default backup directory** radio button, except if the site has a specific folder for database backup files. If that is the case, then select the **Use this directory** radio button and enter in the specified path. (Note: SQL can only see local drives and cannot see shared directories or disks that are not native to the machine.)
39. Select the **Create a subdirectory for each database** check box.
40. Select the **Remove files older than** check box and set the value to **1 week(s)**.
41. The backup extension should be set to **TRN**.
42. Click the **Next>** button to navigate to the **Reports to Generate** page.
43. Click the **Next>** button to navigate to the **Maintenance Plan History** page.
44. Click the **Next>** button to navigate to the **Completing the Database Maintenance Plan Wizard** page.
45. Enter *NewsBrowse* for the name of the schedule.
46. Click the **Finish** button. (Note: If an error occurs, it is most likely that your SQLSERVERAGENT was not started. Start the service and start over.)

If the `SQLSERVERAGENT` is ever stopped, so is your maintenance plan. Make sure that the service is set to auto start in case of a reboot.

## Database Restoration

When NewsBrowse is installed, a maintenance plan should be implemented to schedule backups of the *MediaFrame* and *NBIngest* databases and transaction logs. The rule of thumb in restoring the database is to restore the last successful database backup and transaction log backups preceding system failure. Below is a given scenario of a system failure and the steps necessary to recover.

- 2:00:00 AM database back up performed by the maintenance plan
- 8:00:00 AM transaction log is backed up by the maintenance plan
- 2:00:00 PM transaction log is backed up by the maintenance plan
- 2:30:00 PM system failure occurs

The basic steps to recover are as follows:

1. Restore the database backup done at 2:00:00 AM
2. Restore the transaction backup done at 8:00:00 AM
3. Restore the transaction backup done at 2:00:00 PM

With a database maintenance schedule in place, SQL already recognizes the most recent database backup as well as the sequence of transaction log backups. To restore the NewsBrowse databases to the most current state before failure occurred, open SQL Enterprise Manager, expand the SQL Servers, expand the SQL Server Group, expand the server node, expand the databases directory and do the following:

1. Right mouse click the *MediaFrame* database
2. Select **All Tasks**.
3. Select **Restore Database...**
4. Select the **Database** radio button.

SQL automatically selects most recent database backup file and sequence of transaction logs.

5. Verify the date and time stamp.
6. Click the **OK** button.

SQL will first restore the database, then restore the first transaction log backup, then restore the proceeding transaction logs up until the point of failure. After restore has completed the database will be restored to the point in time of the last backed up transaction log. Repeat the above steps for the *NBIngest* database.



---

# Troubleshooting the NewsBrowse system

## Troubleshooting tools

The following troubleshooting utilities can be found on NewsBrowse machines in the Windows menu **Start | Programs | Thomson**.

### MediaFrame troubleshooting tools

**LogViewer** — This utility is available on all NewsBrowse machines and provides a log of information and errors for services running on that particular device.


**Asset System Client** — This utility on the MDI server provides a view of the events generated by Managed Device Interface services configured in the system. Refer to [“Test: MediaFrame stage” on page 66](#).

**Configuration Tool** — This tool can check network connectivity (ping) from the NewsBrowse server to all the machines in the NewsBrowse system. Open the configuration tool on the NewsBrowse server at **Start | Thomson | NewsBrowse | Utilities**.

**Remoting Host Controller** — This utility on the MDI server manages Profile Managed Device processes. Refer to [“Test: MediaFrame stage” on page 66](#).

**MediaFrame Explorer** — With this tool you have visibility via the MDIs to the media files on managed devices. You can also do a manual drag-and-drop transfer between devices in MediaFrame Explorer. Consider the following when using MediaFrame Explorer:

- Only Profile XP and M-Series iVDR systems are visible in MediaFrame Explorer.
- The PC on which MediaFrame Explorer is installed must be on the Production network to allow the required access to managed devices. For example, it might be helpful to install MediaFrame Explorer on a NewsEdit client machine.
- To install MediaFrame Explorer, enter the following URL in a browser:  
*http://<newsbrowse server name>/nbui/client\_setup/MediaFrameExplorer.msi*  
Download and open the .msi file to run the MediaFrame Explorer installer. You must enter the machine name where ASK is running as part of the install. Typically this would be the NewsBrowse server machine name.
- To open MediaFrame Explorer, click **Start | Programs | Thomson | MediaFrameExplorer**.



Browse each managed device and verify that files are visible. This confirms that the MediaFrame core level is functioning.

## Proxy troubleshooting tools

**Timecode Check** — This is a utility provided on encoders that will display the timecode being fed into the Adrienne timecode board. This is valuable for checking that house time is being read when setting up a single-channel encoder. No NewsBrowse services should be running when using this utility.

**Ingest Client** — This encoder utility exercises a single-channel encoder to test the ability to encode mpeg and initiate record on the high-res video server. Refer to [“Test: Encoder stand-alone stage” on page 148](#).

**Transfer Client** — This encoder utility is used to test scavenge and transcode operations. Refer to [“Test: Advanced encoder stand-alone stage - high-res source” on page 76](#).

**Router Gateway Client** — This utility allows you to test the connection between the Router Gateway and the router control system. Refer to [“Test: Router Gateway stand-alone stage” on page 157](#).

## Proxy troubleshooting tips

Use the following table to identify and resolve problems related to the creation and storage of low-res proxy assets.

Symptom	Solution
An operational NewsBrowse scavenge system (on an Open SAN) suddenly stops working or there is a drop in scavenge performance for more than an hour.	<p>Debug as follows:</p> <ol style="list-style-type: none"> <li>1. Copy and paste a short test clip into the scavenge folder, <b>note the name and time</b>.</li> <li>2. Profile MDI stage: Use the NewsBrowse event viewer on the machine running the Profile MDI, verify that the Profile MDI service reports the creation of the new clip. Look for a CREATE_CLOSE message. <ul style="list-style-type: none"> <li>- If the message doesn't show up, or there are errors in the MDI's log, restart the Profile MDI service.</li> </ul> </li> <li>3. Rules Wizard Stage: Look at the events on the NB server. You're looking for a message from the rules wizard that it received a CREATE_CLOSE message from the Profile MDI. You should then see follow-up messages as a new job is being created and sent to the Sequential encoder. <ul style="list-style-type: none"> <li>- If the message does not arrive, or the Rules Wizard does not send the job, restart the Rules Wizard service.</li> </ul> </li> <li>4. Sequential Encoder: Look at the events on the Sequential encoder. You'll see a new job showing up and the sequential encoder starting. <ul style="list-style-type: none"> <li>- If the job does not arrive, restart the Proxy Transfer Service.</li> </ul> </li> <li>5. Server: If the job arrives, but the sequential encoder can't start, check the connection to the target Profile: <ol style="list-style-type: none"> <li>a. Ping the Profile host name, make sure the ProLink server is running, make sure no other application (i.e. VdrPanel or ConfigManager) is trying to use the playout channel.</li> <li>b. If the connection the Profile appears okay, restart the ProxyTransfer service and run the test again with a new test clip.</li> <li>c. If scavenge still fails, there are a couple of possibilities: <ul style="list-style-type: none"> <li>- Profile is too busy to respond to request. This can happen if several MediaManager sessions are running in full refresh mode. If so, shut down these sessions.</li> <li>- ProNet is wedged. Restart the Profile.</li> </ul> </li> </ol> </li> </ol> <p>In general, don't reboot the system components such as the encoder or the NB server until you've tried the above</p>
The NewsBrowse client browse comes up with results but thumbnails are missing (broken link indicators where thumbnails should be). Video is also inaccessible.	<p>Check Ethernet connections from NAS to the client network.</p> <p>Check that the client account exists on the NAS. This is the account used to log into the client browse machine.</p>
The NewsBrowse client play back video but scrubbing is poor.	<p>There is too much traffic on the network. Try to isolate NewsBrowse from other network activity.</p> <p>Use a switch rather than a hub for connectivity.</p>
Recording does not start as scheduled for ingest.	<p>Check that encoder, server and client workstation PC clocks are synchronized to house timecode feed (reference NetTime setup instructions).</p> <p>Check that all Thomson services are running on server and encoders (use windows services panel from administrative tools).</p>

<b>Symptom</b>	<b>Solution</b>
Storyboard displays permissions denied error. Timecode does not display with video in clip player.	Check that the server has permissions to access the NAS.  Make an initial connection from the server to the NAS by mapping a drive. This establishes the connection for subsequent use - the mapped drive is not used directly.
Video does not load/play in the clip player.	Check that MPEG-1 exists by navigating to the "related" tab in the details display area. If an MPEG link appears, click on it. If video plays then install the "live feed filter" on the client. This can be found from the Client setup link on the NewsBrowse launch page. If video does not display, check that the client has permissions on the NAS.

## **NewsBrowse application troubleshooting tips**

Use the following table to identify and resolve problems related to the access and operation of the NewsBrowse user interface.


<b>Symptom</b>	<b>Solution</b>
Problem accessing the NewsBrowse application with Internet Explorer - cannot find server or DNS error.	Check the server name or IP address used in the browse address. Check that the server is running. Check that the server is connected to the client network. Check that connections are secure. Check that IIS is running on the server.
Web application is accessible using IP address but not server name	Host tables or DNS entries must be set to map name to IP address. This should be coordinated with facility IT personnel.
Problem Accessing the NewsBrowse application - permission denied	Check that the account used to log into the client workstation also exists on the server. This is done through the windows administrative tools.
General Browser Issues (esp. after reinstall).	Be sure to clear the browser cache by selecting Tools > Internet Options from the menu. Then from the General tab select the Delete Files button. Check the Delete all offline content checkbox and click OK.  Also be sure to update components from the client setup page provided with the NewsBrowse application. The client setup page can be accessed from the NewsBrowse launch page.



# Component Interaction Diagrams


This appendix provides diagrams and explanations of how the system software components interact.

## External Ingest Application




**1. Ingest Application.** An ingest application outside of the NewsBrowse system controls Profile XP or M-Series ingest via a protocol such as AMP. When hi-res media is ingested, the Profile XP or M-Series sends the media as a GXF stream and sends a notification about the newly ingested media to the SmartBin Ingest Interaction.

# SmartBin Ingest






# Metadata



**1. Metadata.** When the Rules Wizard or transfer service initiates the creation or modification of proxy, it notifies the Metadata Service. The Metadata Service gets the new or modified metadata from the MDI that has knowledge of the associated hires material and puts it in the metadata database.

# NewsBrowse Ingest: Proxy MPEG Creation



**1. Add Event.** The user enters event information via the web application user interface. The UI passes the event information to the Ingest Scheduler process which stores the event data and creates a metadata entry using the Metadata Services. Synchronized PC clocks are critical for scheduling and processing events.

**2. Process Event.** The Ingest Scheduler process finds events ready to be processed and sends the event info to the encoder (and to the Router Gateway if it's configured in the system) in advance of the actual start time. The router takes immediately while the encoder waits to execute based on the house time. The Ingest Control reads the timecode feed to determine when to execute the record event on the Video Server. The Ingest Control service controls a single Profile (either via serial control or ethernet API) or can optionally control two Profile servers (both via API only) and a backup VTR (serially). The Ingest Control creates mpeg video and writes it to the configured storage location. The Ingest Scheduler creates associations of the mpeg and high-res material with the previously entered metadata.

⌚ Synchronized PC clocks (via NetTime)


Not included in this diagram is the interaction whereby the Ingest Control notifies the Proxy MDI, which in turn notifies the Rules Wizard of the mpeg creation. The Rules Wizard then initiates the creation of thumbnail, storyboard, and Real Video proxy. Refer to the Scavenge Interaction for the flow by which the Rules Wizard initiates proxy creation.

# Scavenge

## 1. Material Created.

The MDI monitors the high-res system (Profile XP or News DSM). When hi-res material creation is detected the MDI notifies the Rules Wizard. If rules apply to the high-res material location, the Rules Wizard checks to see if the material already has proxy associated with it. If not, a job is created and stored in the database.

The Proxy MDI can also trigger this interaction by notifying the Rules Wizard of proxy MPEG creation.




\*MDIs can alternatively reside on encoders, ISS platforms, or a dedicated MDI server.

**3. Startup.** At server startup, the Rules Wizard gets from the MDIs a list of the material on the hi-res system and on the proxy system, to account for any material created when the server was not running. The Resolver is updated and if related proxy does not exist as defined by the Rules Wizard, jobs are created and stored in the Rules Wizard database.

**2. Rules Wizard Initiates Transfer.** When an appropriate Advanced encoder becomes available, jobs are pulled from the Rules Wizard database and a transfer is initiated. The transfer service streams (via FTP) the asset from the hi-res system and creates proxy (depending on the configured rules) to a configured storage location. If rules dictate, this proxy creation occurs while the high-res material is still recording. Then the transfer service communicates to the Resolver to associate the proxy and hi-res material. Once the proxy is created the transfer service notifies the Proxy MDI.


## EDL Export as Text File

This export functionality simply writes a text file (XML) to a hard drive. After the export, the applications, such as NewsBrowse and NewsEdit, have no knowledge of the text file.



## EDL Export to News database

This export functionality converts the NewsBrowse EDL into a NewEdit sequence. After the conversion the EDL is available to NewsEdit for modification.




**1. Export.** User creates a timeline from the NewsBrowse interface and exports it to NewsEdit. The system (IIS) requests that the News MDI transfers the EDL to the Conform Web Service. The Conform Web Service converts the NewsBrowse EDL to a NewsEdit compatible EDL and pushes the EDL to the News database.

**2. Identify as NewsBrowse asset.** The News database notifies the News MDI of the EDL. The News MDI updates the Resolver so the EDL asset, now on NewsEdit, is visible to NewsBrowse. The EDL is also available to NewsEdit.


## EDL NewsBrowse save

This save functionality retains the EDL in the NewsBrowse domain for further modification with the NewsBrowse application.



## EDL Conform on Profile


This conform functionality converts the EDL into a Profile XP complex movie. In the NewsBrowse application, the user can select a designated on-air destination, which places the finished complex movie on the on-air Profile XP.



1. User creates a timeline from the NewsBrowse interface and selects Conform.
2. The system (IIS) performs all the actions associated with the Save EDL interaction but to a temporary location.
3. The system (IIS) initiates a transfer of the EDL to a Profile MDI. This causes the conform to take place.
4. The EDL which was previously saved to a temporary location is deleted so that only the conformed high-res asset remains associated with the metadata record which was originally created for the EDL.
5. If a conform to air, the conformed material is transferred via Fibre Channel to the on air Profile.


## EDL Conform via NewsEdit

This conform functionality converts the EDL into a NewsEdit EDL and automatically places it on the designated on-air video server.





# Archive operations on Profile XP




**1. Archive operation control.** In the NewsBrowse application, the user selects an asset, navigates to the management tab, and selects the archive option. The system queries the ASK for available archive devices. (Also filters out for hi-res material that already exists in archive by querying the Resolver). The user then chooses an available archive. The system queries the archive MDI to obtain a list of available tape groups. The user then selects the target tape group and initiates the archive operation. IIS accepts the request and submits a transfer job to the Archive MDI. The Archive MDI gets details about the affected material from the Profile MDI. The Archive MDI initiates the archive operation on the archive device.

**2. Transfer material.** The archive device initiates the transfer of material to/from the Profile XP. Once the transfer is complete, the Archive MDI updates the Resolver to link the newly transferred hi-res material to the existing metadata record in the system. The MDI optionally initiates the removal of the online hi-res material from the Profile XP if the option to do so was initially selected.

During the archiving process the system displays the archive status which is retrieved from the Archive MDI.

# Archive operations on News system




\*MDIs can reside on a separate machine, such as the MDI server.

**1. Archive operation control.** In the NewsBrowse application, the user selects an asset, navigates to the management tab, and selects the archive option. The system queries the ASK for available archive devices. (Also filters out for hi-res material that already exists in archive by querying the Resolver). The user then chooses an available archive. The system queries the archive MDI to obtain a list of available tape groups. The user then selects the target tape group and initiates the archive operation. IIS accepts the request and submits a transfer job to the Archive MDI. The Archive MDI gets details about the affected material from the News MDI. The Archive MDI initiates the archive operation on the archive device.

**2. Transfer material.** The archive device initiates the transfer of material to/from the News system. Once the transfer is complete, the Archive MDI updates the Resolver to link the newly transferred hi-res material to the existing metadata record in the system. The MDI optionally initiates the removal of the online hi-res material from the News system if the option to do so was initially selected.

During the archiving process the system displays the archive status which is retrieved from the Archive MDI.

# Purge



\*MDIs can alternatively reside on encoders, ISS platforms, or a dedicated MDI server.


The Rules Wizard periodically queries the Metadata Service for a list of metadata records that are set to expire. The Metadata Service only returns assets that are set to expire and are not flagged as being on hold.

For each metadata record set to expire the Rules Wizard queries the ASK for related asset components (e.g. hi-res, storyboard, thumbnail, etc.).

For each asset component the Rules Wizard communicates the appropriate MDI to initiate a delete. The MDI communicates to the appropriate hi-res system (Profile XP, News NAS, etc.) to complete the delete.

Purge removes all associated components of an asset. The metadata record is the last component deleted, so that if for any reason any component fails to delete, its record is still intact and the component is visible to the NewsBrowse application.

# Consolidate



**1. New master clip from original master clip.** On NewsEdit, the user creates a new master clip from an existing master clip and then consolidates the media, which deletes the original clip. The News database communicates to the News MDI about the new clip. The News MDI notifies the Rules Wizard and passes along information about how the new clip relates to the original clip, including temporal references. The Rules Wizard updates the Resolver, associating the original clip's existing proxy\*\* with the new clip while remapping temporal references and thumbnails so that the proxy correctly represents the new clip. The Rules Wizard also triggers the Metadata Interaction so the new clip has the correct metadata.

\*\*If the original clip has no existing proxy, the Rules Wizard triggers the creation of proxy, as in the Scavenge Interaction. (not shown)


**2. Delete original clip.** After the updates to the Resolver and metadata are complete, the News database communicates to the News MDI that the original clip is deleted. The News MDI updates the Resolver and removes the record of the original clip. Since the original clip's proxy is now re-associated with the new clip, the proxy is not deleted.

# Appendix **B**

## Legacy systems

This appendix documents system architectures, hardware platforms, and software components that are no longer recommended for new NewsBrowse systems, but that are retained in existing NewsBrowse systems.


### Three tier system diagram



Systems that are upgrading from NewsBrowse version 1.5 to version 2.0 or higher can use the three tier network architecture. NewsBrowse version 1.5 required the three tier network, while NewsBrowse version 2.0 and higher supports either a two tier or a three tier network.


The system illustrated here includes all hardware platform types. Smaller systems might not include all types of hardware platforms. Consult the system design for your specific system to determine the hardware platforms you must install.

## Two tier system diagram version 2.0



This diagram illustrates the recommended architecture for NewsBrowse version 2.0. It includes devices that are no longer supported.

## Configuration overview - Profile XP/Open SAN



This flowchart illustrates the major tasks required for configuring a NewsBrowse system for the Profile XP/Open SAN.

Core configuration tasks are broken down into stages. You can work through the configuration stages in different ways, as follows:

If you are new to the NewsBrowse system, follow the **Basic** path. At each configuration page, configure only those settings documented in this manual as **Basic** ✓. This path allows you to learn the system and resolve configuration problems in stages, with a minimal number of configuration variables and machines added to the system at each stage. Then, after you have gained the understanding to make each stage of the system work properly, configure the remainder of the system and add all machines.


If you are experienced with the NewsBrowse system and you want the fastest possible configuration, follow the **Advanced** path and configure the entire system in one pass, adding all machines at each stage. At each configuration page, you can configure settings documented as **Advanced** ✓ as well as those documented as **Basic** ✓.

You can also choose a combination of Basic and Advanced paths to suit your level of understanding and the design of the particular NewsBrowse system you are configuring.

## Encoder stand-alone stage

For this configuration stage you configure and test one single-channel encoder, one NAS, and one Profile XP server to work together.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to [“System diagram - Profile XP Open SAN”](#) on page 13 for a view of the entire NewsBrowse system.

To do the basic configuration and testing of a single-channel encoder, do the following:

1. [“Configure ASK Location: Single-channel encoder”](#) on page 145
2. [“Configure Ingest Control: Single-channel encoder”](#) on page 145
3. [“Configure Proxy Asset \(NAS\): Single-channel encoder”](#) on page 146
4. [“Configure media server: Single-channel encoder”](#) on page 147
5. [“Configure MPEG encoder: Single-channel encoder”](#) on page 148
6. [“Test: Encoder stand-alone stage”](#) on page 148
7. [“Checklist: Encoder stand-alone stage”](#) on page 150



## Configure ASK Location: Single-channel encoder

Do not modify  
Advanced  
Basic

http://root-nb-enc-n:280 → ASK Location

Enter the name of the NewsBrowse server

Port 9010 is required. See [“Ports and services mapping” on page 40.](#)

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

It is not necessary to restart a service to put these settings into effect.

This page tells the single-channel encoder where to look for the ASK service, which runs on the NewsBrowse server. The function of the ASK is to store the location of other services in the NewsBrowse system that the encoder might need to access.

## Configure Ingest Control: Single-channel encoder

Do not modify  
Advanced  
Basic

http://localhost:280 → Single Channel Encoder → Ingest Control      Access this page from the local single-channel encoder.

Select the protocol that controls the Profile.

For Ethernet, enter IP Port **9330**. See [“Ports and services mapping” on page 40.](#) For Serial Port, select a COM Port.

360 minutes recommended

If using a backup VTR, select **Enable**

If using a backup VTR, select a COM port.

Adjust as required by the backup VTR<sup>a</sup>

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Control service on the single-channel encoder.

<sup>a</sup>. Tune at a later time to make sure the VTR start matches the Profile and encoder start time.

This page provides general information about the single-channel encoder and how it controls the Profile Media Server and (if you use one) a backup VTR.

## Configure Proxy Asset (NAS): Single-channel encoder

Do not modify  
 Advanced  
 Basic

<http://localhost:280> → Single Channel Encoder → Proxy Asset Information Access this page from the local single-channel encoder.

There is but one logical Proxy Managed Device in the system, named PROXY1.<sup>a</sup>

Select the path to the folder (\Media) on the NAS (or other storage location) that receives the MPEG this encoder creates.

Validates the current configurations with the Proxy MDI settings and saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Control service on the single-channel encoder.

<sup>a</sup> PROXY1 can have multiple folders (on multiple machines) defined as locations for assets.

This page specifies the location in which the single-channel encoder places the proxy MPEG it creates.

When this page opens and when you click a ... button, fields and lists are populated with valid information as currently defined on the ASK settings page and the Proxy MDI settings page.

If you have not yet configured Proxy MDI settings (as in the MediaFrame stage), you must type in the File System Folder path (\\root-nb-nas-n\Media) rather than using the ... button and then selecting from a list. In this case you can ignore error messages about the Proxy MDI information not being available.

## Configure media server: Single-channel encoder

Do not modify  
Advanced  
Basic

http://root-nb-enc-n:280 → Single Channel Encoder → Primary Media Server

Configure Primary Profile Media Server Information	
Live Record: <input checked="" type="checkbox"/> Enable	Leave this box checked unless the Profile is being taken off line. <sup>a</sup>
<b>Profile Control</b>	
Record using: API	Select API or VDCP (API is strongly recommended).
Host Name or IP: mpvs-1	For API, enter the machine name of the Profile. For VDCP, select the COM port connected. <sup>b</sup>
Channel: Vtr1	For API, select the Profile channel. For VDCP, enter the signal port connected. <sup>c</sup>
Delay: 0	For API, set to 0. For VDCP, enter delay frames, tuned for the channel so that the Profile and encoder start times are in sync. <sup>d</sup>
<b>Profile Asset Information</b>	
MDI Name: SAN1	Select the MDI name for the Profile specified under “Profile Control” above.
Profile Bin: EXT:/Ch1Ingest	Select a bin on the Profile. Upon ingest, the high-res asset is saved here. <sup>e</sup>
Update	Validates and saves the current configurations. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Control service on the single-channel encoder.

- <sup>a</sup> Normally the media server is enabled. Uncheck only when the Profile is off line, but if you still need a second Profile or backup VTR to run.
- <sup>b</sup> This field is dependent upon the API/VDCP selection above.
- <sup>c</sup> For API, this list is automatically populated by reading the channel names, as in Configuration Manager, from the Profile specified in the “Host Name...” field above.
- <sup>d</sup> This field is dependent upon the API/VDCP selection above.
- <sup>e</sup> This list is automatically populated by reading bins and volumes, as in Media Manager, from the Profile specified in the “Host Name...” field above

This page configures the connection between the single-channel encoder and the Profile channel it controls. Make sure that you correctly associate the MDI with the correct Profile Media Server.

If you have a backup Profile, return to the **Single Channel Encoder → Backup Media Server** link and configure similarly. On the backup server configuration page, you must check **Enable**, as it is unchecked by default.

## Configure MPEG encoder: Single-channel encoder

http://root-nb-enc-n:280 → Single Channel Encoder → MPEG Encoder

Do not modify

Advanced

Basic

Configure MPEG Encoder

Mpeg bit rate: 1000000 Leave at default of 1000000.

Mpeg delay (frames): 0 Leave at default of 0. Modify only to debug server/encoder timecode problems.

Video source:  S video  Composite Select **Composite**

Video standard: FPS\_5994 Select fields per second: **FPS\_5994** for drop-frame NTSC, **FPS\_60** for non-drop-frame NTSC, **FPS\_50** for PAL.

Audio Gain Level: 0.0 dB The MPEG encoder audio output. Adjust to calibrate Advanced Edit audio, or to improve the quality of the desktop audio (i.e. if the source is 'too hot')

Update Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Control service on the single-channel encoder.

This page configures the parameters the encoder uses when it creates the MPEG proxy assets.

### Test: Encoder stand-alone stage

The following test exercises system functionality exclusive to the basic configurations for the single-channel encoder. A successful test verifies that the basic configurations are correct.

Test description: A short test clip (high-res) is recorded on the Profile Media Server, while at the same time the low-res proxy asset is created on the NAS.

**NOTE: Run this test only in the stand-alone stage, with machines that have not yet been added as managed devices (as in the + Server stage). Once the server is connected, this test can result in corrupt database records.**


Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.

**NOTE: Running these tests will tie up a channel and could collide with commands from the Ingest Schedule page. Inform operators that they must not use the channels under test.**

2. Click **Start | Programs | Thomson | Event Viewer**. Event Viewer opens.

- Click **Start | Programs | Thomson NewsBrowse | Ingest Client**. The Ingest Client application opens.



If you open the Ingest Client application on an operational NewsBrowse system, you'll see the status messages of the last encode job.

- Configure as follows:
  - Host Name or IP: **localhost**
  - Port: **9330**
- Click **Connect** to establish a connection with the Ingest Control service that controls the target Profile. Look for the following report in the Status area to verify the connection:
  - State: **IDLE**
- Configure as follows to create a high-res and a low-res asset:
  - Asset Name: Enter a name for the test asset you are about to create.
  - Start Time: Enter **ASAP**. This starts recording immediately, similar to a crash record. Or you can enter a start time a few minutes ahead of the current time.
  - Duration: Enter **00.00.20.00** (this is 20 seconds, which is adequate for test purposes)
- Click **Ingest**. The ingest job is submitted and a ProNet session is established with the Profile. Watch the reports in the Status area to verify that the creation of the assets is progressing. Look for the following report to verify completion:

- State: SUCCEEDED

8. In Event Viewer, verify informational messages regarding the creation of the assets.

***NOTE: If you've not yet configured the MDIs, you may get some error messages in Event Viewer as the encoder attempts to communicate completion information to MDI services. In this case these messages can be ignored.***

9. In the Ingest Client application, click **Get Assets**. For both the high-res and the low-res assets, look for the following report:

- COMPLETE\_OK

10. On the Profile system, use Media Manager to verify that a clip with the correct duration was created. Note the location of the clip, as it is used in configuration stage tests later in this chapter.

11. On the NAS, use Windows Explorer to verify that the MPEG clip was created. Open and play the clip. Validate video and audio.

### **Checklist: Encoder stand-alone stage**


Use the following check list to verify that the basic configuration and testing of the single-channel encoder is complete.

- Audio/Video/Timecode connected properly
- NetTime server running
- Profile(s) record high-res
- Encoder writes to NAS
- MPEG playback with audio

## Encoder + Server stage

For this configuration stage you configure the NewsBrowse server to work together with the single-channel encoder, NAS, and Profile XP server from the Encoder stand-alone stage. MDI services are also required, as configured in the MediaFrame stage.

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to [“System diagram - Profile XP Open SAN”](#) on page 13 for a view of the entire NewsBrowse system.

To do the basic configuration and testing for the Encoder + Server stage, do the following:

1. [“Configure ASK Location: NewsBrowse server”](#) on page 152
2. [“Configure Media Frame Core ASK: Single-channel encoder”](#) on page 152
3. [“Configure Ingest Scheduler: NewsBrowse server”](#) on page 153
4. [“Set up NewsBrowse client for configuration stage tests”](#) on page 154
5. [“Test: Encoder + Server stage”](#) on page 154
6. [“Checklist: Encoder + Server stage”](#) on page 155

## Configure ASK Location: NewsBrowse server

Do not modify  
Advanced  
Basic

<http://localhost:280> → ASK Location

Open this page locally on the NewsBrowse server machine.

ASK Location

ASK  
Host: localhost

Port: 9010

Update

Enter **localhost**, since you are configuring on the NewsBrowse server itself.

Port 9010 is required. See [“Ports and services mapping” on page 40.](#)

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

It is not necessary to restart a service to put these settings into effect.

This page tells the NewsBrowse server where to look for the ASK service. Since the ASK service runs on the NewsBrowse server, you enter *localhost* for the ASK host location. On all other machines you must enter the name of the NewsBrowse server.

## Configure Media Frame Core ASK: Single-channel encoder

Make sure the single-channel encoder’s Ingest Control service is registered with the ASK software component with a logical name, as explained in [“Configure Media Frame ASK: Register components” on page 58.](#)



## Configure Ingest Scheduler: NewsBrowse server

Do not modify  
 Advanced  
 Basic

<http://localhost:280> → Ingest Scheduler → Scheduler

Open this page locally on the NewsBrowse server.

Scheduler Settings	
Purge Event: 7	Number of previous days of ingest history
Back to Back Delay: 29	Minimum back-to-back delay in seconds between records on the same channel. Default value is 29.
Video/Audio Router Gateway: Host Name or IP: iron-nb-rtr	Machine name of Router Gateway.
Port: 8065	8065 required.
<input type="button" value="Update"/>	Saves changes. Changes are lost if you leave the configuration page without updating.
<b>Add/Update Ingest Channel</b>	
Encoder Name: INGEST-CH2	Select the logical name for the encoder. This specifies the encoder as an ingest channel.
Display Name: Enc. Chan. 2	Enter a useful name for the channel. This is displayed in the NewsBrowse application.
<input type="button" value="Add/Update Channel"/>	Adds the above specified encoder as an ingest channel
<b>Existing Channels</b>	
INGEST-CH1,(Enc.Chan. 1) MXP21	Currently added ingest channels
<input type="button" value="Remove Channel"/>	Removes the currently selected ingest channel
<b>Update Date/Time Stamp</b>	
Date Stamp: <input type="radio"/> YYYYMMDD <input type="radio"/> YYMMDD <input type="radio"/> DDMMYY <input type="radio"/> DDMMYYYY <input checked="" type="radio"/> NONE	Adds the selected date suffix automatically to high-res clips
Time Stamp: <input type="radio"/> HHMMSS <input type="radio"/> HHMM <input checked="" type="radio"/> NONE	Adds the selected time suffix automatically to high-res clips
<input type="button" value="Update Date/Time Stamp"/>	Saves date stamp and time stamp changes

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Scheduler service.

The page defines resources available and operating parameters for ingest jobs.

Add the encoder as an ingest channel.

For “Video/Audio Router...” settings, refer to [“Add Router Gateway to Ingest Scheduler” on page 160](#). If you are configuring the basic Encoder + Server stage, do not yet configure these settings.

## Set up NewsBrowse client for configuration stage tests

Temporarily set up a PC as a NewsBrowse client. You can use the NewsBrowse server, except if the server is the HAFT platform.

***NOTE: It is no longer recommended to install Windows Media Player on the HAFT platform because of compatibility problems, so you can not run the NewsBrowse application locally on the HAFT platform.***

Setting up a NewsBrowse client is explained in “[Prepare NetTime clients](#)” on page 45 and in “[Set up client PCs](#)” on page 107. If you use the NewsBrowse server as a NewsBrowse client, it is only for the purpose of the staged configuration process. Once the entire NewsBrowse system is operating, you should no longer use the NewsBrowse server as a NewsBrowse client.

Other configurations normally required for NewsBrowse clients, such as NewsBrowse users and licenses, are not necessary when the NewsBrowse client runs on the NewsBrowse server, because you log into the server as NewsBrowse administrator.

To use an external PC as a NewsBrowse client, refer to “[Add NewsBrowse Clients](#)” on page 106 for the complete instructions.

## Test: Encoder + Server stage

The following test exercises system functionality exclusive to the basic configurations for the Encoder + Server stage. A successful test verifies that the basic configurations are correct.

Test description: Using the NewsBrowse user interface, one test clip is manually recorded (crash record) and one test clip is schedule recorded. The NewsBrowse system correctly controls the creation of (at the right time) the high-res material on the Profile Media Server and the low-res proxy assets on the NAS.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.

***NOTE: Running these tests will tie up a channel and could collide with commands from the Ingest Schedule page. Inform operators that they must not use the channels under test.***

2. From the NewsBrowse server, open the NewsBrowse application.
3. Click the **ingest** tab at the top of the NewsBrowse window. The Ingest page opens.
4. On the Ingest page, verify that you can see the single encoder with the correct channel name at the top of the column.
5. Make sure you are on today's schedule, and enable auto-refresh.
6. If not already running, start Event Viewer by clicking **Start | Programs | Thomson | Event Viewer**. You can view activity in Event Viewer as you run tests.
7. Do a crash record as follows:
  - a. On the Ingest page, click the red record button at the top of the channel column.

The Add Schedule Event window appears showing the current time as the start time of the record, with a default duration of 30 minutes.

- b. Enter a meaningful test clip name
  - c. Change the duration to one minute. Duration uses the SMPTE timecode format: hours:minutes:seconds:frames.
  - d. Click **Add Event**. The event gets added to the Ingest Schedule in the current time slot and begins recording.
  - e. Change to List View and track progress until the job reports COMPLETED.
8. Do a scheduled record as follows:
- a. On the Ingest page, double-click in the channel column at a time that is ahead of the current time. The Add Schedule Event window appears.
  - b. Enter a meaningful test clip name.
  - c. Change the start time to a time that is a few minutes ahead of the current time. Start Time uses a 24-hour clock.
  - d. Change the duration to one minute.
  - e. Click **Add Event**. The event is added to the Ingest Schedule in the specified time slot.
  - f. Change to List View, wait until the recording begins, and track progress until the job reports COMPLETED. Verify that the job starts at the correct time.
9. Check for the crash record and schedule record material as follows:
- a. Click the **browse** tab at the top of the NewsBrowse window.
  - b. On the find tab, verify that the crash record and scheduled record clips are listed.
  - c. For each of these clips, select it, then click the **related** tab. Verify that **online media** and **MPEG Video** are listed.

## **Checklist: Encoder + Server stage**

Use the following check list to verify that the basic configuration and testing of the single-channel encoder plus NewsBrowse server is complete.

- Clock synched
- Crash record successful
- Scheduled record on time
- New MPEG proxy in system

## Router Gateway stand-alone stage

For this configuration stage you configure the Router Gateway component for control of your router controller (if used in your system).

Refer to [“System diagram - Profile XP Open SAN” on page 13](#) for a view of the entire NewsBrowse system.

To do the basic configuration and testing of the Router Gateway stand-alone stage, do the following:

1. [“Add Router Gateway” on page 156](#)
2. [“Configure ASK Location: Router Gateway” on page 157](#)
3. [“Configure Router Gateway” on page 157](#)
4. [“Test: Router Gateway stand-alone stage” on page 157](#)
5. [“Checklist: Router Gateway stand alone stage” on page 158](#)

### Add Router Gateway

The machine that hosts the Router Gateway software component acts as the Router Gateway machine, as follows:

**Dedicated Router Gateway** — In some NewsBrowse systems, the Router Gateway software component is on a stand-alone Router Gateway machine. If your system has a dedicated Router Gateway machine, it comes from the factory with the Router Gateway software component installed, so you do not need to do any further installation. The Router Gateway machine requires only network connections in preparation for its use in the NewsBrowse system.

**MDI server as Router Gateway** — The Router Gateway software component can also reside on another NewsBrowse machine, such as the MDI server. If your system uses the MDI server as the Router Gateway host, you must first install the Router Gateway software component from the NewsBrowse server installation program. Run the installation program and install only **Router Gateway**. Refer to [“Install NewsBrowse software” on page 31](#).

## Configure ASK Location: Router Gateway

Do not modify  
Advanced  
Basic

<http://localhost:280> → ASK Location

Open this page locally from the machine hosting the Router Gateway Service.

Enter the name of the NewsBrowse server

Port 9010 is required. See [“Ports and services mapping” on page 40.](#)

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

It is not necessary to restart a service to put these settings into effect.

This page tells the Router Gateway where to look for the ASK service, which runs on the NewsBrowse server. The function of the ASK is to store the location of NewsBrowse components.

## Configure Router Gateway

Do not modify  
Advanced  
Basic

<http://localhost:280> → Router Gateway

Open this page locally from the machine hosting the Router Gateway Service.

Port 8065 is required. See [“Ports and services mapping” on page 40.](#)

Hostname of machine hosting Router Gateway service

**12345** is the standard port for the SMS7000 native protocol.

If using a backup host, enter machine name.

Use the standard port for router controller. Defaults to 12345.

Saves changes. Changes are lost if you leave the configuration page without updating.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Router Gateway service.

This page specifies the machine or (backup) machines that host the Router Gateway Service.

## Test: Router Gateway stand-alone stage

The following test triggers the Router Gateway component to send a control signal to the router controller. A successful test verifies that the basic configurations are correct.


Test description: Using the Router Gateway Client application, change the source and destination of the router.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.

**NOTE: Running these tests will tie up a channel and could collide with commands from the Ingest Schedule page. Inform operators that they must not use the channels under test.**

2. From the Router Gateway host, click **Start | Programs | Thomson | NewsBrowse | Diagnostic Tools | Router Gateway Client**. The Router Gateway Client application opens.



3. Configure as follows:
  - IP: **localhost**
  - Port: **8065**.
4. Click **Connect**. Verify that the Destinations and Sources drop-down lists are populated, which means the connection is successful.
5. Configure as follows to trigger the router controller:
  - Destinations: Select a destination from the list that is not the destination currently used by the router.
  - Sources: Select a source from the list that is not the source currently used by the router
6. Monitor the video and audio currently routed. Click **Take**. Verify that the video and audio changes.
7. Repeat previous steps to validate that takes work for all destinations that are configured to an ingest channel.

## Checklist: Router Gateway stand alone stage


Use the following check list to verify that the basic configuration and testing of the Router Gateway stand alone stage is complete.

- The machine hosting the Router Gateway software component connects to the router controller.
- The Router Gateway software component can change Destinations and Sources on the router controller.

## Router Gateway + Server stage

For this configuration stage you configure the Router Gateway component for control of your router controller (if used in your system).

The portion of the NewsBrowse system configured and tested in this stage is illustrated by the following diagram.



Refer to [“System diagram - Profile XP Open SAN”](#) on page 13 for a view of the entire NewsBrowse system.

To do the basic configuration and testing of the encoder plus server, do the following:

1. [“Add Router Gateway to Ingest Scheduler”](#) on page 160
2. [“Test: Router Gateway + Server stage”](#) on page 161
3. [“Checklist: Router Gateway + Server stage”](#) on page 161

## Add Router Gateway to Ingest Scheduler

Do not modify  
 Advanced  
 Basic

http://root-nb-svr:280 → Ingest Scheduler → Scheduler

Scheduler Settings	
Purge Event: 7	Number of previous days of ingest history
Back to Back Delay: 29	Minimum back-to-back delay between records on the same channel
Video/Audio Router Gateway: Host Name or IP: iron-nb-rtr	Hostname of machine hosting Router Gateway service
Port: 8065	<b>8065.</b> Refer to <a href="#">“Ports and services mapping”</a> on page 40.
<input type="button" value="Update"/>	Saves changes. Changes are lost if you leave the configuration page without updating.
Add/Update Ingest Channel	
Encoder Name: INGEST-CH2	Select the logical name for the encoder. This specifies the encoder as an ingest channel.
Display Name: Enc. Chan. 2	Enter a useful name for the channel. This is displayed in the NewsBrowse application.
<input type="button" value="Add/Update Channel"/>	Adds the above specified encoder as an ingest channel
Existing Channels	
INGEST-CH1,(Enc.Chan. 1) MXP21	Currently added ingest channels
<input type="button" value="Remove Channel"/>	Removes the currently selected ingest channel
Update Date/Time Stamp	
Date Stamp: <input type="radio"/> YYYYMMDD <input type="radio"/> YYMMDD <input type="radio"/> DDMMYY <input type="radio"/> DDMMYYYY <input checked="" type="radio"/> NONE	Adds the selected date suffix automatically to high-res clips
Time Stamp: <input type="radio"/> HHMMSS <input type="radio"/> HHMM <input checked="" type="radio"/> NONE	Adds the selected time suffix automatically to high-res clips
<input type="button" value="Update Date/Time Stamp"/>	Saves date stamp and time stamp changes

Always click **Update...** buttons after making changes

To put changes into effect, start or restart the Thomson Ingest Scheduler service on the NewsBrowse server.

This page make the Router Gateway machine available to the Ingest Scheduler service.

In the Router Gateway + Server stage, configure only Video/Audio Router Gateway and Add/Update Ingest Channel settings.



## Test: Router Gateway + Server stage

The following test triggers the router controller as part of Profile ingest. A successful test verifies that the basic configurations are correct.

Test description: Using the NewsBrowse application, use the Router option in conjunction with Profile ingest.

Run the test as follows:

1. Make sure that the NewsBrowse system is not in use.

***NOTE: Running these tests will tie up a channel and could collide with commands from the Ingest Schedule page. Inform operators that they must not use the channels under test.***

2. From the NewsBrowse server, open the NewsBrowse application.
3. Click the **ingest** tab at the top of the NewsBrowse window. The Ingest page opens.
4. Make sure you are on today's schedule, and enable auto-refresh.
5. Verify that the router option is available as follows:
  - a. On the Ingest page, click the red record button at the top of the channel column. The Add Schedule Event window appears showing the current time as the start time of the record, with a default duration of 30 minutes.
  - b. Verify that the **router source** list is present. Change the router source.
  - c. Enter a meaningful test clip name.
  - d. Change the duration to one minute. Duration uses the SMPTE timecode format: hours:minutes:seconds:frames.
  - e. Click **Add Event**. The event gets added to the Ingest Schedule in the current time slot and begins recording.
  - f. Verify that the router changes the video and audio signal correctly.

## Checklist: Router Gateway + Server stage

Use the following check list to verify that the basic configuration and testing of the Router Gateway + Server stage is complete.

- Router-control connections successful between NewsBrowse server and Router Gateway
- NewsBrowse application controls router at ingest

## Configure Profile MDI: Conform to air settings

Do not modify  
 Advanced  
 Basic

<http://localhost:280> → Profile MDI

Access this page locally on the MDI server.

Port 9100 is required. See [“Ports and services mapping” on page 40.](#)

All Domain names in the NewsBrowse system must be identical.

Saves changes. Changes are lost if you leave the configuration page without updating.

Select a Profile MDI.

Enter the hostname of the Profile for the MDI selected above.<sup>a</sup>

Enter the hostname of the backup Profile.<sup>b</sup>

The time that the Profile MDI waits before it informs the NewsBrowse system that a clip has finished recording. Leave at 2.

Automatically increments so each Profile MDI has a unique process port.

Click to add as an existing managed device. For stand-alone Profile Media Servers, add a MDI for each one. For Open SAN Profile Media Servers, add only one MDI per Open SAN.

Verify the MDIs currently on-line. A listing for a single Profile MDI includes the values from all four “Add Profile MDI” fields above.

Click to remove the selected managed device.

The following settings specify Profiles to which material can be transferred via Fibre Channel from other Profiles. This is used by Conform-To-Air EDL and other Fibre Channel transfers. Refer to [“Configure Profile MDI: Conform to air settings” on page 162.](#)

Select the MDI for a Profile to which material can be transferred.

Hostname of the Profile specified above.

Click to add as a transfer target. This makes the Profile available for selection from the NewsBrowse application as a transfer destination.

Profiles capable of receiving a Fibre Channel transfer.

Click to remove the selected transfer target.

Always click **Update...** buttons after making changes

To put changes into effect, start or restart Profile MDI Service on the MDI server.

<sup>a</sup>Make sure the Profile name is entered just as it is in the host table.

<sup>b</sup>Make sure the Profile name is entered just as it is in the host table.

This page configures the Managed Device Interface (MDI) for the Profile Media Servers that record and store the high-res media. The NewsBrowse system depends on the Profile MDI to make high-res media assets visible across the system.

For the EDL stage, configure the settings related to the EDL Conform to air feature. Specify one of more on-air Profiles as the targets to which conformed high-res clips can be transferred for playout.

For other settings, refer to [“Configure Profile MDIs” on page 63.](#)

## NewsBrowse server instructions: Axiom platform

The central component of the NewsBrowse system is the NewsBrowse server. Depending on the design of your system, it can host the following software components:

- The web-application for user interaction
- The Ingest Scheduler which drives the encoders
- The Rules Wizard for background processing
- The database and Managed Device Interface services for holding and relating assets in the system.


The server connects to all encoders and the Network Attached storage via the network. Refer to the system diagrams in [Chapter 1, System Overview](#). The client network is available for access to the web application.

Platform Specifications are as follows:

- P 3, 1Ghz or better (1 or 2 CPU)
- 512 MB RAM- CD-ROM Drive
- Minimum 20GB Program Drive
- Windows 2000 Server (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- Windows Media Player 7.1
- Flash Player 6 (6.0.65.0 update)
- Microsoft SQL Server (SP3)
- 100Tx LAN (x2)

Cable as illustrated.

### Axiom platform



Cable as illustrated and as follows:


- For systems with one unified Production Network, connect port 1 to the Production Network.
- For systems with a Production Network consisting of a media network and a control network, connect port one to the control network.
- For three tier networks, connect port 1 to the Private Network.
- Connect port 2 to the Client Network.

## Sequential encoder instructions

The sequential encoder creates MPEG-1 proxy versions of high-resolution video assets that already exist on a video server.

Single-channel encoders and sequential encoders both share the same hardware and are wired up identically except for timecode and video/audio sources.

If a NewsBrowse system uses single-channel encoders for the creation of MPEG, the sequential encoder can be an optional component.



Cable as illustrated and as follows:


- Connect a cable from the Video In port on the Encoder to the analog video feed source.
- Connect a cable from the Audio In port on the Encoder to the analog audio feed source.
- Connect a Timecode cable from the Timecode In port (RCA port) to the Profile Media Server Timecode Out port; the Profile port must be configured as a Timecode generator and should be free running time of day, closely reflecting the actual time of day.
- Connect two Ethernet cables from **LAN1** and **LAN2** ports on the Encoder to a network router or switch.
- Optionally connect a RS-422 control cable from the COM2 port on the encoder to the RS-422 port on the Profile Media Server (only if API is not used). Refer to [“RS-422 Cable Pinouts”](#) on page 29.

## Image Support Server (ISS) instructions

The NewsBrowse Image Support Server is host for the background metadata extraction services used within NewsBrowse. From the Image Support Server, NewsBrowse processes MPEG-1 proxy content and extracts thumbnail images to be used for proxy identification, extracts dynamic scene detection images for storyboard creation, and renders RealVideo for low bitrate proxy content.

Platform Specifications:

- Pentium 3 1Ghz or better (1 or 2 CPU)
- 256 MB RAM
- CD-ROM Drive
- Minimum 20GB Program Drive
- Windows 2000 Workstation (SP3)
- .NET Framework 1.1
- Internet Explorer 6 (SP1)
- Real Producer 8.5
- Mediaware hardware dongle



Cable as illustrated and as follows:

- Attach the Mediaware dongle to the parallel printer port on the back of the Image Support Server to enable generation of thumb-nails and storyboard extraction.
- Connect an Ethernet cable from the **LAN1** port on the ISS to a network router or switch.

## Prepare NAS - Linux Fastora

On Linux Fastora NAS devices, check the following configurations and modify settings as necessary.

1. Using Internet Explorer, browse to the NAS machine. For example:  
`http://root-nb-nas-n`
2. Login as administrator. The password is *triton*.
3. Navigate in left pane to **Server Configuration | Basic Configuration**.
4. Under the general tab set the following:
  - Server Name
  - Domain name (for client network)
  - DNS server (from customer IT dept.).
5. Under LAN Port 1 tab, do the following:
  - Select manual configuration
  - Set the IP address
  - Subnet mask is 255.255.255.0
6. Leave LAN Port 2 unchanged (disconnected)
7. Under LAN Port 3 tab, select **Get network configuration through DHCP**
8. At **Server Configuration | Date Setup**, set the date and time.
9. Click **Security Setup | Shared Folder Setup**. Select the **Windows/Apple/Novell privileges** tab. User privileges for the media folder should be as follows:
  - everyone - RO
  - nbadmin - RW
10. Click **Network Setup | Windows Network**. Check **Enable Windows Networking**.
11. Enter the following:
  - customer Domain
  - account and password (customer IT dept. will need to provide this)
  - enter the WINS server

## Host table files

Find host table files at `C:\WINNT\system32\drivers\etc`

Devices share a common host table, which lists out the Production Network IP settings. For security purposes, the IP addresses should be non-routable (i.e. 192.168.xxx.xxx) and be part of the same subnets used by the Profile/Open SAN systems. The customer may request a particular subnet (routable or not) depending on

the needs of the facility. The only client side IP address needed in the host table is for the client switch itself, which is useful for accessing the web management page from the NewsBrowse devices.

The following is an example of host table entries. Not shown are entries for Profile systems, UIMs, and other machines on the network. Refer to the documentation for these other machines for host table requirements.

```
#-----
#General Host Table
#-----

#NewsBrowse server

192.168.30.21      iron-nb-svr

#NewsBrowse MDI server

192.168.30.101    iron-nb-mdi

#NewsBrowse NAS

192.168.30.71     iron-nb-nas-1
192.168.30.72     iron-nb-nas-2

#NewsBrowse Advanced encoders

192.168.30.50     iron-nb-adv-1
192.168.30.51     iron-nb-adv-2

#NewsBrowse single-channel encoders

192.168.30.26     nb-enc-1          #Open SAN Profile mpvs-1 vtr 01
192.168.30.27     nb-enc-2          #Open SAN Profile mpvs-1 vtr 02
192.168.30.28     nb-enc-3          #Open SAN Profile mpvs-1 vtr 03
192.168.30.29     nb-enc-4          #Open SAN Profile mpvs-1 vtr 04

#NB Router Gateway

192.168.30.111    iron-nb-rtr

#The following Client LAN entries are included in this host table for
#reference only. Machines on client network use DNS lookup only.

#NewsBrowse live monitor encoder

10.16.37.91       iron-nb-live-1    #Client LAN
```

```
10.16.37.92      iron-nb-live-2      #Client LAN
#NewsBrowse Ethernet Switch
10.16.37.20      iron-nb-2950-client-1  #Client LAN
192.168.30.200   iron-nb-2950-prod-1
```

Host table tips:

- If you are exporting NewsBrowse EDLs to NewsEdit, the NewsEdit workstation must be able to resolve the Profile MDI name (present in the EDL) to the IP address of the Profile XP system to which the MDI connects. The recommended solution is to map the MDI name to the Profile IP address in the NewsEdit workstation's host table. Refer to [“MDI and Encoder logical names convention” on page 37](#).
- The NAS and NewsBrowse server IP address need to be resolved using the Client side IP address via DNS lookup, not the host table.
- If the server has a canonical name, the host table for any machine that runs MDIs that are subscribed to by the server must match case for the entire canonical name. E.g., if the server's canonical name is “NB-SERVER1.mycorp.net”, then the host table entry in the MDI server(s) must match; if the entry is “NB-SERVER1.MYCORP.NET”, then it will not work. Pinging will not show the problem. The problem doesn't show up until the MDIs attempt to notify the server.



# Index

---

## A

Advanced encoder

  cabling 23, 24

  configure 71

  test 76, 78, 84

API 147

archive

  configuring 93

  configuring MDI 99

  configuring services 102

  enter MDI name 59

  interaction explained 137, 138

  MDI installed on platforms 94

  MDI service 40

  NewsBrowse application 102

  preparing for NewsBrowse 95

  test 102

ASK

  configuring 57

  service 40

ASK location

  configure Avalon archive 98

  configure ISS 68, 72

  configure router gateway 157

Asset System Client application 121

audio

  connections 27, 28, 164

  feeds 16

audio, saving files 88

Avalon Archive

  configuring MDI 99

  MDI service 40

Axiom platform 17, 19, 26

## B

backup VTR, configure 145

## C

cabling

  Advanced encoder 23, 24

  HAFT platform 19

  ISS 165

  live monitor 27

  MDI server 21

  NAS 17, 19, 25, 26, 163

  NewsBrowse Server 17, 21, 163

  router gateway 30

  sequential encoder 164

  single-channel encoder 28

canonical names 168

clock, synchronizing 46

component interaction diagrams 127

configuration

  overview 36, 143

  production network 42

configuration pages

  accessing 54

  archive MDI 99

  archive services 102

  ASK location 145

  ASK settings 58

  conform services 89

  conform to air 162

  DIVA MDI 101

  export services 90

  FlashNet MDI 100

  ingest control 145

  ingest scheduler 153, 160

  live monitor, live feeds 104

  media server 147

  MPEG encoder 75, 148

  M-Series MDI 65

  News MDI 64

  NTFS MDI 88

  profile MDI 63

  proxy asset 75

  proxy MDI 62

  Real Media 76

  router gateway 157

  rules automation Advanced Encoder 82

  save EDL 91

Configuration Tool 121

conform, see EDL conform

consolidate interaction explained 140

conventions

  machine naming 37

  MDI naming 37

crash record 154

custom fields, adding 112

## D

- database
  - administration 115
  - recovery plan 115
  - SQL 17, 163
- destinations, router 158
- DHCP 41
- digital to analog conversion 16
- DIVArchive, configuring MDI 101
- DNS 41, 106, 166, 168
- Domains and nbadm 53

## E

- Edit Decision List, see EDL
- EDL
  - configure 87
  - NewsBrowse application 92
  - saving 88
  - test 92
- EDL conform
  - configure services 89
  - explained 87
  - interaction explained 135, 136
- EDL conform to air
  - configure 89, 162
  - explained 87
- EDL export
  - configuring 90
  - explained 87
  - interaction explained 132, 133
- EDL save
  - explained 87
  - interaction explained 134

## F

- fields, custom 112
- FlashNet archive, configuring MDI 100
- functional description 9

## G

- groups, administering 109

## H

- HAFT platform 19
- hardware platforms
  - Axiom and Dell 17, 19, 26
  - ISS 165

- live monitor 27
- MDI server 21
- NAS 25
- NewsBrowse server 17, 163
- router gateway 30
- single-channel encoder 28
- host table, example 166

## I

- Image Support Server (ISS) 165
- ingest
  - interaction explained 127
  - NewsBrowse application 154
- Ingest Client application 122, 149
- ingest control
  - configure 145
  - service 40
- ingest scheduler
  - configure 153, 160
  - service 40
- installation
  - cabling 16
  - rack-mounting 16
  - software 31
- Integrated Windows Authentication 106
- IP addresses
  - NAS 51, 166

## L

- Legacy systems 141
- License & User Management 107
- live monitor, configure 104
- logons
  - NAS 51, 166
  - NewsBrowse server 54
- LogViewer 121
- LTC 44

## M

- Marathon platform 19
- MDI
  - installed on platforms 60
  - server 21
  - test 66
- Media Frame Core ASK, configure 58, 152
- media server, backup 147
- Mediaware dongle 165

---

metadata interaction explained 129, 130  
Metadata service 40  
Migrating from 1.5 to 2.0 41  
MPEG encoder, configure 75, 148  
M-Series  
    configure MDI 65  
multiple channel ingest test 105

## **N**

name resolution 168  
naming conventions  
    machines 37  
    MDI 37  
NAS  
    cabling 25  
    preparing 50  
nbadmin and Domains 53  
NetTime 44, 107  
network  
    canonical names 168  
    client 42  
    connecting to customer LAN 106  
    DHCP 41  
    DNS lookup 41, 168  
    Domain 106  
    Domains and nbadmin 53  
    migrating from 1.5 to 2.0 41  
    NAS test 52  
    production 42  
    static IP 42  
    subnet mask 42  
    three tier diagram 141  
    two tier configuration 41  
    two tier diagram 11, 13  
    WINS 43  
    zoning 16  
News  
    configure MDI 64  
NewsBrowse application 154  
NewsBrowse clients  
    adding 106  
    on server 154  
    setting up PCs 107  
    test 114  
NewsBrowse launch page 54  
NewsBrowse server  
    configure 151  
    test 84, 85, 154, 161

NewsBrowse users 110  
NTFS MDI  
    configure 88  
    configuring 89  
    service 40

## **P**

passwords  
    NAS 51, 166  
    NewsBrowse server 54  
ports  
    numbers with services 40  
    Profile MDI 63, 65  
PortServer 46  
power supplies, NAS 20, 25, 26  
Profile  
    configure MDI 63  
    MDI service 40  
    Portserver 46  
    preparations necessary for NewsBrowse 46  
proxy asset, configure 75, 146  
Proxy MDI  
    configure 62  
    service 40  
proxy transfer  
    service 40  
Proxy Transfer Client application 77  
PROXY1 62  
purge interaction explained 139  
purge test 106

## **R**

rack mounting 16  
Real Media, configure 76  
recording, NewsBrowse application 155  
recovery plan 115  
registry key 46  
Remoting Host Controller application 121  
Resolver service 40  
roles 110  
router gateway  
    configuring 156  
    installed on platforms 156  
    service 40  
    test 157  
Router Gateway Client application 122, 158  
router source, NewsBrowse application 161  
RS-422

- pinouts 29
- sequential encoder 164
- single-channel encoder 29
- rules
  - configure rules automation 82
- rules wizard
  - on server 17, 163
  - service 40
  - test 85
  
- S**
- save EDL, configuring 91
- scavenge interaction explained 131
- scavenge test 105
- scheduled record 155
- security
  - NAS 166
  - NewsBrowse website 106
- server, MDI 21
- server, NewsBrowse 17, 163
- services
  - accessing 54
  - with ports 40
- sessions, dropping 112
- ShuttleAtMode 46
- single-channel encoder
  - configure 144
  - test 148
- SMS7000 Protocol 30
- software components, interactions explained 127
- software installation 31
- sources, router 158
- SQL
  - administration 115
  - Query Analyzer 116
  - recovery plan 115
  - transaction log 115
- subnet mask 42
- support, Grass Valley 8
- system overview
  - functional description 9
  - three tier network 141
  - two tier network 11, 13
  
- T**
- take, router 158
- Thomson services, see services
- timecode

- LTC 44
  - requirements 16
- Timecode Check application 122
- timeline, NewsBrowse application 92
- transaction log 115
- Transfer Client application 122
- troubleshooting
  - tips 123, 125
  - tools 121
  
- U**
- upgrading from 1.5 to 2.0, see migrating
- user access, administering 109
  
- V**
- VDCP 147
- VTR, configure backup 145
  
- W**
- website, NewsBrowse security 106
- WINS 43, 166
  
- Z**
- zoning, network 16