


# K2 Media Client Quick Start Guide

For SDA-00 models  
071-8576-00 July 3, 2007  
Before you begin, unpack the following items...



...and locate the documentation you need.

## Documentation path to install K2 Media Clients with internal storage



## Documentation path to install K2 Media Clients with (external) K2 Storage System




## 1. Make cable connections and, if necessary, configure network

### Quick Start networking options

**Use default settings** – DHCP is enabled and the chassis serial number is the hostname. If supported by your network, you can use these defaults.

**Configure network settings** – If necessary, power up the K2 Media Client and do the following:

- Access the Windows logon dialog. Use a locally connected keyboard, mouse, and monitor. If not locally connected, use Windows Remote Desktop Connection with default settings as above.
- Logon with the default Windows administrator account:  
Username: administrator  
Password: adminK2
- In Network Connections, for internal storage models configure **Control Connection #1**. For external storage models, configure **Control Team**.



If using LTC, connect inputs and outputs as needed per channel


If using analog audio, connect inputs and outputs as needed per channel

Refer to *K2 Media Client System Guide* for RS-422 connections.

Connect other cables as needed. Refer to the *K2 Media Client System Guide* for complete cabling and network instructions.

## 2. Power on

- 1 Press both bezel-release buttons and flip down front bezel.



- 2 Identify the following: Power LED, Service LED, Serial number, Standby switch

- 3 Press the standby switch to power on. At first startup, End User License Agreements appear on the screen. Accept the agreements to continue.

### Normal startup sequence

Power LED goes on and stays on. Service LED stays off. Startup processes complete in approximately two minutes and the K2 Media Client is ready for remote connection and operation.

Note: Add external storage models to a K2 Storage System before proceeding.


## 3. Install control point software

Note: You can skip ahead if you are:

- Using the Grass Valley control point PC. Skip to step 4.
- Accessing the K2 Media Client locally only. Skip to step 5.

- 1 Choose a network-connected PC as your control point.

### Control point PC




- 2 Insert CD, open the *Control Point* folder and run *setup.exe*.
- 3 Follow on-screen instructions, clicking **Next**, **Install**, and **Finish**.

### PC System requirements

Microsoft Windows XP Professional, Service Pack 2 (U.S. version)  
Pentium 4 or higher class processor, 2 GHz or greater  
Minimum 512 MB RAM, 1 GB recommended  
400 MB hard disk space  
Graphics acceleration with at least 128 MB memory  
Microsoft .NET Framework 1.1 (available on K2 System Software CD)  
MS XML 4, Service Pack 2 (available on K2 System Software CD)

## 4. Make remote connection


### Control point PC



Continue with Quick Start procedures on the reverse side.

## 5. Configure channels

- 1 Open AppCenter and logon with the K2 administrator account (K2admin/K2admin). If a licensing message appears, refer to *K2 Media Client Release Notes*.
- 2 Click **System | Configuration**.



**Analog/SDI channels**  
Configure input channels (R1 and R2) to receive either SDI or Analog Composite video input.

- 3 Click tabs, buttons, and scroll bar to locate settings.
- 4 Select from drop-down lists to make settings.
- 5 Click **OK** and **Yes** to save settings..


Find commonly modified settings...

And configure as follows:

- |                                      |   |
|--------------------------------------|---|
| <b>System</b> → Reference Standard:  | Select <b>NTSC</b> or <b>PAL</b> . Restart to put change into effect.   |
| <b>Channel</b> → R n → Input type:   | Select <b>SDI</b> or <b>Analog Composite</b> .                          |
| <b>Channel</b> → R n → Audio Input:  | Select <b>Analog</b> , <b>AES/EBU</b> , or <b>Embedded</b> .            |
| <b>Channel</b> → P n → Audio output: | Embedded output group(s): Select <b>Group 1</b> , <b>Group 2</b> , etc. |

## 7. Play a clip


- 1 Select a channel
- 2 Select the Player application
- 3 Double-click or drag a clip into the play channel
- 4 Play the clip
- 5 Eject the clip



Refer to the AppCenter Help menu for complete operating instructions. Refer to step 8. For more information.

## 6. Record a clip

- 1 Select a channel
- 2 Select the Recorder application
- 3 Adjust audio
- 4 Begin record
- 5 Stop record
- 6 Rename clip



**Timecode for Record**  
Click the **Options** button to open the Options dialog box, then click **Timecode** and select **VITC**, **LTC**, or **Internal** timecode for recording and display.


Click again to close the audio control

Use keyboard or on-screen keypad.

Refer to the AppCenter Help menu for complete operating instructions. Refer to step 8. For more information.

## 8. For more information...

In AppCenter, click **Help | AppCenter Help Topics** and read the complete documentation for operating and configuring K2 Media Client channels.




Find the complete documentation set for K2 products on the Documentation CD:



- User Guide
- System Guide
- Service Manual
- Storage System Manual
- RAID Instruction Manuals

Go to <http://www.thomsongrassvalley.com/support>, click **Troubleshooting/FAQ** and search the FAQ Knowledge Bank.



Use the following information to contact product support by phone during business hours. Afterhours phone support is available for warranty and contract customers.

International (France)	+800 80 80 20 20	Italy	+39 02 24 13 16 01
International (United States, Canada)	+33 1 48 25 20 20	Belarus, Russia, Ukraine	+39 06 87 20 35 42
Hong Kong, Taiwan	+800 547 8949	Tadzikistan, Uzbekistan	+7 095 258 09 20
Korea, Macau	+1 530 478 4148	Indian Subcontinent	+31 (0) 2 334 90 30
Australia, New Zealand	+852 2531 3058	Germany, Austria, E. Europe	+91 11 515 282 502
Central, South America	+61 1300 721 495	Near East, Africa	+49 6150 104 44
China	+55 11 5509 3440	Northern Europe	+33 1 48 25 20 20
Belgium	+861 066 0159 450	Japan	+31 (0) 35 62 38 421
Malaysia	+32 (0) 2 334 90 30	Malaysia	+45 45 96 88 70
Middle East	+81 3 5484 6868	Middle East	+65 6379 1313
	+603 7805 3884		+41 487 80 02
	+971 4 299 64 40		+44 118 923 0499



Copyright © 2007 Grass Valley, Inc.