



Release Notes Software Version 1.2.28

www.grassvalley.com

000 219 419 910 12. April 2011

## **Contacting Grass Valley**

International Support Centers	France 24 x 7	+800 8080 2020 or +33 1 48 25 20 20	United States/Canada 24 x 7	+1 800 547 8949 or +1 530 478 4148		
Local Support Centers (available during normal business hours)	Asia	China: +86 10 5883 7575 Hong Kong, Taiwan, Korea, Macau: +852 2631 3058 India: +91 22 676 10324 Japan: +81 3 6848 5561 Southeast Asia - Malaysia: +603 7492 3303 Southeast Asia - Singapore: +65 6379 1313 (Office main line)				
	Australia: 1300 721 495 New Zealand: 0800 846 676 For callers outside Australia or New Zealand: +61 3 8540 3650			Central/South America: +55 11 5509 3440		
	North America, Mexico, & Caribbean: +1 800 547 8949 (option 2) or +1 530 478 4148					
	Middle East: +971 4 299 64 40 Near East and Africa: +800 80 80 20 20 or +33 1 48 25 20 20					
	Europe	Belarus, Russia, Tadzikistan, Ukraine, Uzbekistan: +7 495 258 09 20 Benelux/Belgium: +32 (0) 2 334 90 30           Benelux/Netherlands: +31 (0) 35 62 38 421 France: +800 80 80 20 or +33 1 48 25 20 20           Germany, Austria, Eastern Europe: +49 6150 104 444           Northern Europe: +45 404 72 237 Southern Europe/Italy: +39 06 87 20 35 28           Southern Europe/Spain: +34 91 512 03 50           UK, Ireland, Israel: +44 118 230 499				

Copyright © Thomson, Inc. All rights reserved. This product may be covered by one or more U.S. and foreign patents.

#### **Grass Valley Web Site**

The <u>www.grassvalley.com</u> web site offers the following:

Online User Documentation — Current versions of product catalogs, brochures,



#### END-OF-LIFE PRODUCT RECYCLING NOTICE

Grass Valley's innovation and excellence in product design also extends to the programs we've established to manage the recycling of our products. Grass Valley has developed a comprehensive end-of-life product take back program for recycle or disposal of end-of-life products. Our program meets the requirements of the European Union's WEEE Directive, the United States Environmental Protection Agency, and U.S. state and local agencies.

Grass Valley's end-of-life product take back program assures proper disposal by use of Best Available Technology. This program accepts any Grass Valley branded equipment. Upon request, a Certificate of Recycling or a Certificate of Destruction, depending on the ultimate disposition of the product, can be sent to the requester.

Grass Valley will be responsible for all costs associated with recycling and disposal, including freight. However, you are responsible for the removal of the equipment from your facility and packing the equipment to make it ready for pickup.



For further information on the Grass Valley product take back system please contact Grass Valley at + 800 80 80 20 20 or +33 1 48 25 20 20 from most other countries. In the U.S. and Canada please call 800-547-8949 or 530-478-4148, and ask to be connected to the EH&S Department. Additional information concerning the program can be found at: www.thomsongrassvalley.com/environment

## Contents

Indigo Release Notes	5
Introduction	5
Changes	5
Known Restrictions in Software Version 1.2.28	6
User Manual and Quick Start Guide	6
Indigo Software Upgrade	7
Needed Parts	7
Procedure	7
More Information	9
Contacting Grass Valley Customer Service	9
HiRes Board Update	10
Upgrade Procedure	10

Contents



# Indigo Release Notes

## Introduction

This document includes notes for software installation and changes, and other information specific to INDIGO Release 1.2.28 software.

**Note** Please read this Release Notes before updating the software!

## Changes

- Auto Chroma Key no longer freezes when selecting lower quadrant in NTSC sources.
- Audio no longer occasionally crashes when microphone delay is enabled in the operation mode 6+2 or 7+4.
- Indigo functionality has not been changed from version 1.2.24.

### **Known Restrictions in Software Version 1.2.28**

Area	Known Problem		
Acappella	No Audio support		
Acappella	The integration of an Acappella router works only if both HD serial inputs are connected to the router outputs. VGA and DVI inputs cannot be used in parallel.		
Acappella	To avoid re-synchronizating of the Indigo's integrated scaler it is strictly recommended to connect a line or frame synchronizer between router output and Indigo's HD-SDI input.		
Acappella	If the router output cannot be synchronized after switching to a non-sync source, the internal scalers of the Indigo needs to be reset by temporary changing the HiRes input source, e.g. from HD-SDI to VGA or DVI.		
Acappella	Transitioning Acappella sources faster than two seconds apart will result in transition command being skipped.		
Keyer	In PiP mode if Transform is enabled and picture is rotated then edges becomes jagged. To make edges more soft go to the Crop/Border menu and add crop softness.		
Keyer	Border menu of HiRes Keyer is only available when keyer is set to PIP mode and Transform is enabled.	80276	
Media Player	Preroll is only activated when source is selected on PST bus and auto/cut transition is executed	79938	
Scaler	Downscaler doesn't work for 75Hz standards		
Setup	Fire Wire I/O's are supporting only DV25 consumer devices.		
Setup	SD-Flattened operation mode: Hi-Res program and preview outputs shows upscaled SD program (because of the hard- ware restrictions).		
Setup	<ul> <li>HR-Flattened operation mode:</li> <li>1. Downscaled Hi-Res program and preview are routed to the AUX1 and AUX2 (because of the hardware restrictions).</li> <li>2. If SD sources are selected on program and preview bus then preview shows same source as program (because of the hardware restrictions).</li> </ul>		
Setup	Audio: Embedding/deembedding is not implemented for DV.		
Setup	Video/Output: If Ext. Lock is enabled and H & V are adjusted with some H & V phases combinations, transformed PiP or key could be damaged. Adjusting the H & V phases of the external genlock during set up may cause a transformed key to no longer produce the expected image. Work around - reboot. After adjusting phases will bring key back to normal state.	74347	
USB	Because of the many different types offered worldwide sometimes an USB Flash Drive is not detected. Disconnecting and reconnecting the USB Flash Drive may solve this problem.	75759	

#### **User Manual and Quick Start Guide**

The latest versions of User Manual and Quick Start Guide can be downloaded from our web site http://www.grassvalley.com/docs/page

## Indigo Software Upgrade

The software of your INDIGO AV Mixer resides on a Compact Flash (CF) card. The CF card is installed in the slot under the lid found on the right side of the INDIGO.

#### **Needed Parts**

- **1**. PC with Compact Flash card reader.
- **2.** CF card with min. 128MB capacity which is formatted for FAT file system.

The CF card of your INDIGO can be overwritten, but you may want to keep the old software.

#### **Procedure**

- Download Indigo software <u>http://www.grassvalley.com/apps/kb\_page?p=/rnt/Switcher/</u> <u>switcher\_Indigo5.htm</u>
- 2. Save the settings of your INDIGO (Optional).
  - Insert a USB flash memory in one of the USB connectors
  - Go to the **Load/Save** menu
  - Select **Save** and give the saved data a meaningful name
  - Wait until the save is completed
  - Remove the USB flash memory
- Turn off your INDIGO. Open the lid on the right side and extract the CF card (or have another FAT format CF card ready).
- 4. Insert the CF card into the CF reader of the PC.
- **5.** On the PC, open the downloaded self-extracting .EXE file. It will automatically run the Software installation tool Indigo CD.

Indigo CD Ver.: 1.0.10
Install new software on Indigo device
Install n

Figure 1. Setup Audio Output

- **6.** Select **Install new Indigo Software on Indigo device** to copy the new software onto the CF card.
- 7. Wait until the copy process is completed. Then remove the CF card.
- **8.** While your INDIGO is still turned off, insert the CF card containing the new software into the slot on the upper side of the printed circuit board.
- 9. Close the slot.
- **10.** Turn on the INDIGO AV Mixer.
- **11.** Perform a Audio Fader calibration. For details refer to your User Manual.
- **12.** Restore the settings if your INDIGO (Optional).
  - Insert the USB flash memory with the saved data in one of the USB connectors
  - Go to the **Load/Save** menu
  - Select the saved data from the list and press Load
  - Wait until the load is completed
  - Remove the USB flash memory
- 13. Update the HiRes board. Refer to *HiRes Board Update* on page 10.
- **14.** Start working with the new software.

#### **More Information**

Please refer to the INDIGO AV Mixer User Manual (section 10/ Maintenance) for more information.

#### **Contacting Grass Valley Customer Service**

Contact Grass Valley Customer Service if you have questions or encounter any problems:

- North America: 1-800-547-8949 or 1-530-478-4148
- ERoW Call Center: +800 80 80 20 20 Accessible from the following countries: Belgium, Denmark, Finland, France, Germany, Ireland, Italy, Luxembourg, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland, United Kingdom
- +33 1 48 25 20 20 for all other countries outside North America
- E-mail: <u>indigo.support@grassvalley.com</u>

### **HiRes Board Update**

When updating from software earlier than version 1.2.19, an update for the HiRes option card is required as an additional step after upgrading the Indigo Software using CF Card.

This update provides a greater list of supported graphics standards to the PC connected via VGA/DVI. Not doing this update step does not cause harm to the unit. It can be done at any time.

#### **Upgrade Procedure**

Connect 2 DVI cables from the Indigo DVI outputs to the Indigo DVI inputs and power up the unit. As soon as the Indigo Menu appears the update process is finished. This will take few minutes.

Optionally this can be done using only 1 DVI cable and 2 power ups.